



AX PRO

Manual de usuario



Informacion Legal

©2022 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Acerca de este Manual

El Manual incluye instrucciones para el uso y manejo del Producto. Las imágenes, los gráficos, las imágenes y toda la demás información que se incluye a continuación son solo para descripción y explicación. La información contenida en el Manual está sujeta a cambios, sin previo aviso, debido a actualizaciones de firmware u otras razones. Encuentre la última versión de este Manual en el sitio web de Hikvision(https://www.hikvision.com/).Utilice este manual con la orientación y asistencia de profesionales capacitados para respaldar el producto.

Marcas registradas

HIKVISION y otras marcas comerciales y logotipos de Hikvision son propiedad de Hikvision en varias jurisdicciones.

Otras marcas comerciales y logotipos mencionados son propiedad de sus respectivos dueños.

Descargo de responsabilidad

EN LA MEDIDA MÁXIMA PERMITIDA POR LA LEY APLICABLE, ESTE MANUAL Y EL PRODUCTO DESCRITO, CON SU HARDWARE, SOFTWARE Y FIRMWARE, SE PROPORCIONAN "TAL CUAL" Y "CON TODAS LAS FALLAS Y ERRORES". HIKVISION NO OFRECE GARANTÍAS, EXPRESAS O IMPLÍCITAS, INCLUYENDO SIN LIMITACIÓN, COMERCIABILIDAD, CALIDAD SATISFACTORIA O IDONEIDAD PARA UN PROPÓSITO PARTICULAR. EL USO DEL PRODUCTO POR SU PARTE ES BAJO SU PROPIO RIESGO. EN NINGÚN CASO HIKVISION SERÁ RESPONSABLE ANTE USTED POR CUALQUIER DAÑO ESPECIAL, CONSECUENTE, INCIDENTAL O INDIRECTO, INCLUYENDO, ENTRE OTROS, DAÑOS POR PÉRDIDA DE GANANCIAS COMERCIALES, INTERRUPCIÓN COMERCIAL O PÉRDIDA DE DATOS, CORRUPCIÓN DE SISTEMAS O PÉRDIDA DE DOCUMENTACIÓN, YA SEA BASADO EN INCUMPLIMIENTO DE CONTRATO, AGRAVIO (INCLUIDA LA NEGLIGENCIA) RESPONSABILIDAD DEL PRODUCTO O DE CUALQUIER OTRA FORMA, EN RELACIÓN CON EL USO DEL PRODUCTO, INCLUSO SI HIKVISION HA SIDO ADVERTIDO DE LA POSIBILIDAD DE TALES DAÑOS O PÉRDÍDA. USTED RECONOCE QUE LA NATURALEZA DE INTERNET PROPORCIONA RIESGOS DE SEGURIDAD INHERENTES, Y HIKVISION NO ASUMIRÁ NINGUNA RESPONSABILIDAD POR EL FUNCIONAMIENTO ANORMAL, LA FUGA DE PRIVACIDAD U OTROS DAÑOS RESULTANTES DE ATAQUE CIBERNÉTICO, ATAQUE DE HACKER, INSPECCIÓN DE VIRUS U OTROS RIESGOS DE SEGURIDAD DE INTERNET; SIN EMBARGO, HIKVISION PROPORCIONARÁ SOPORTE TÉCNICO OPORTUNO SI ES NECESARIO. USTED ACEPTA UTILIZAR ESTE PRODUCTO DE CONFORMIDAD CON TODAS LAS LEYES APLICABLES, Y USTED ES EL ÚNICO RESPONSABLE DE ASEGURARSE DE QUE SU USO SE CUMPLA CON LA LEY APLICABLE., INCLUYENDO SIN LIMITACIÓN, DERECHOS DE PUBLICIDAD, DERECHOS DE PROPIEDAD INTELECTUAL O PROTECCIÓN DE DATOS Y OTROS DERECHOS DE PRIVACIDAD. NO UTILIZARÁ ESTE PRODUCTO PARA NINGÚN USO FINAL PROHIBIDO, INCLUYENDO EL DESARROLLO O PRODUCCIÓN DE ARMAS DE DESTRUCCIÓN MASIVA, EL DESARROLLO O PRODUCCIÓN DE ARMAS QUÍMICAS O BIOLÓGICAS, CUALQUIER ACTIVIDAD EN EL CONTEXTO RELACIONADA CON UN CICLO DE COMBUSTIBLE NUCLEAR EXPLOSIVO O INSEGURO, O EN APOYO A ABUSOS DE LOS DERECHOS HUMANOS.EN CASO DE CONFLICTO ENTRE ESTE MANUAL Y LA LEY APLICABLE, PREVALECE ESTA ÚLTIMA



Proteccion de datos

Durante el uso del dispositivo, se recopilarán, almacenarán y procesarán datos personales. Para proteger los datos, el desarrollo de los dispositivos Hikvision incorpora principios de privacidad por diseño. Por ejemplo, para un dispositivo con funciones de reconocimiento facial, los datos biométricos se almacenan en su dispositivo con un método de encriptación; para el dispositivo de huellas dactilares, solo se guardará la plantilla de huellas dactilares, lo que es imposible reconstruir una imagen de huellas dactilares.

Como responsable del tratamiento, se le recomienda que recopile, almacene, procese y transfiera datos de conformidad con las leyes y normativas de protección de datos aplicables, lo que incluye, entre otros, la realización de controles de seguridad para salvaguardar los datos personales, como la implementación de controles de seguridad físicos y administrativos razonables, la realización de revisiones periódicas y evaluaciones de la efectividad de sus controles de seguridad.



Convenciones sobre los símbolos

Los símbolos que se pueden encontrar en este documento se definen a continuación.

Simbolo	Descripcion
Peligro	Indica una situación peligrosa que, si no se evita, provocará o podría provocar la muerte o lesiones graves.
Precaucion	Indica una situación potencialmente peligrosa que, si no se evita, podría provocar daños en el equipo, pérdida de datos, degradación del rendimiento o resultados inesperados
i Nota	Proporciona información adicional para enfatizar o complementar puntos importantes del texto principal.

iNota

• Actualice el firmware a la última versión.

• Para los instaladores, se recomienda instalar y mantener dispositivos a través de Hik-ProConnect.



Información reglamentaria

EN 50131-1:2006+A1:2009+A2:2017

EN 50131-3:2009

EN 50131-6:2017

EN 50131-5-3:2017

EN 50131-10: 2014

EN 50136-2: 2013

Security Grade (SG): 2 Environmental Class (EC) : II DP2 Certified by KIWA



iNota :El etiquetado de conformidad con EN50131 debe eliminarse si se detectan configuraciones no conformes al uso.

Declaración de conformidad de la UE

CE	Este producto y, si corresponde, los accesorios suministrados también están marcados con "CE" y cumplen, por lo tanto, con las normas europeas armonizadas aplicables enumeradas en la Directiva EMC 2014/30/EU, la Directiva RE 2014/53/EU, la Directiva RoHS 2011/65/EU.
	2012/19/EU (directiva WEEE): Productos marcados con este símbolo no se pueden desechar sin clasificar en la UEuropea. Para un reciclaje adecuado, devuelva este producto a su proveedor local cuando compre un equipo nuevo equivalente, o deséchelo en los puntos de recolección designados. Para obtener más información, consulte: www.recyclethis.info
	2006/66/EC (directiva sobre baterías): Este producto contiene una batería que no se puede desechar como residuo municipal sin clasificar en la Unión Europea. Consulte la documentación del producto para obtener información específica sobre la batería. La batería está marcada con este símbolo, que puede incluir letras para indicar cadmio (Cd), plomo(Pb) o mercurio (Hg). Para un reciclaje adecuado, devuelva la batería a su proveedor oa un punto de recogida designado. Para obtener más información, consulte: www.recyclethis.info



Precaución Este es un producto de clase A. En un entorno doméstico, este producto puede causar interferencias de radio, en cuyo caso el usuario deberá tomar las medidas adecuadas.
Información de la FCC: Tenga en cuenta que los cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento pueden anular la autoridad del usuario para operar el equipo.Cumplimiento con la FCC: Este equipo ha sido probado y se encontró que cumple con los límites para un dispositivo digital de Clase B, de conformidad con la parte 15 de las Reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y, si NO se instala y usa de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencia dañina en la recepción de radio o televisión, lo que se puede determinar apagando y encendiendo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:
—Reoriente o reubique las medidas de la antena receptora:.
—Aumentar la separación entre el equipo y receptor
—Conectar el equipo a un tomacorriente en un circuito diferente de aquello a lo que está conectado el receptor.
—Consulte al distribuidor o a un técnico experimentado en radio/TV para ayuda.
Este equipo debe ser instalado y operado con undistancia mínima de 20 cm entre el radiador y su cuerpo.
Condiciones de la FCC Este dispositivo cumple con la parte 15 de las normas de la FCC. La operación es sujeto a las dos condiciones siguientes: 1. Es posible que este dispositivo no cause interferencias dañinas. 2. Este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan provocar un funcionamiento no deseado.



Contents

Cap ítulo	1 Instrucciones de instalación	9
1.1	Escenario tipico	9
1.2	Precaucion	.9
1.3	Instalacion FAQ	10
Cap ítulo	2 Introducción	11
Descripo	cion del sistema	11
Cap ítulo	3 Puesta en marcha	L 4
3.1	Gestión de autoridad	14
3.2	Activacion	15
	3.2.1 Activacion via LAN/SIM(4G/GPRS)	15
	3.2.2 Activacion con Wi-Fi	16
3.3	Desvincular el dispositivo	23
	3.3.1 Desvincular el dispositivo de su una cuenta	23
	3.3.2 Desvincular el dispositivo de otra cuenta	23
Chapter	4 Gestión de usuarios	26
4.1 G	estión de usuarios	26
	4.1.1 Invitar al Administrador	26
	4.1.2 Cancel Installer Access	27
	4.1.3 Add an Operator	28
	4.1.4 Delete an Operator	29
	4.1.5 Disable the Hik-Connect Service	30
	4.1.6 Invite the Installer	30
4.2	Access Entries	30
Chapter	5 Configuration	32
5.1	Set-up with Hik-Proconnect	32
	5.1.1 Use the Hik-Proconnect APP	32
	5.1.2 Use the Hik-ProConnect Portal	51
5.2	Set-up with Hik-Connect	54
5.3	Set-up with the Web Client	76



AX PRO Manual de usuario

5.3.1 Communication Settings77
5.3.2 Device Management91
5.3.3 Area Settings
5.3.4 Video Management103
5.3.5 Permission Management105
5.3.6 Maintenance106
5.3.7 System Settings
5.3.8 Check Status
5.4 Report to ARC (Alarm Receiver Center)122
Setup ATS in Transceiver of Receiving Center122
Setup ATS in Transceiver of the Panel123
Signaling Test
Chapter 6 General Operations126
6.1 Arming
6.2 Disarming127
6.3 SMS Control
A. Trouble Shooting128
A.1 Communication Fault128
A.1.1 IP Conflict
A.1.2 Web Page is Not Accessible
A.1.3 Hik-Connect is Offline128
A.1.4 Network Camera Drops off Frequently128
A.1.5 Failed to Add Device on APP128
A.1.6 Alarm Information is Not Reported to APP/4200/Alarm Center129
A.2 Mutual Exclusion of Functions129
A.2.1 Unable to Enter Registration Mode129
A.3 Zone Fault129
A.3.1 Zone is Offline
A.3.2 Zone Tamper-proof129
A.3.3 Zone Triggered/Fault129
A.4 Problems While Arming130



A.4.1 Failure in Arming (When the Arming Process is Not Started)	130
A.5 Operational Failure	130
A.5.1 Failed to Enter the Test Mode	130
A.5.2 The Alarm Clearing Operation on the Panel Does Not Produce the Alarm Report	• Clearing 130
A.6 Mail Delivery Failure	130
A.6.1 Failed to Send Test Mail	130
A.6.2 Failed to Send Mail during Use	131
A.6.3 Failed to Send Mails to Gmail	131
A.6.4 Failed to Send Mails to QQ or Foxmail	131
A.6.5 Failed to Send Mails to Yahoo	131
A.6.6 Mail Configuration	132
B. Input Types	133
C. Output Types	136
D. Event Types	137
E. Access Levels	138
F. Signalling	140
Detection of ATP/ATS Faults	140
ATS Category	140
G. SIA and CID Code	141
H. Communication Matrix and Operation Command	152



Capítulo 1 Instrucciones de instalación

1.1 Instalacion típica



Instalación típica Ubicacion de los dispositivos:

- 1. AX PRO Panel de control
- 2. Repetidor
- 3. Detector PIR
- 4. Sirena
- 5. Detector Magnetico

1.2 Precaucion

- 1. Evite instalar el dispositivo sobre superficies metálicas.
- 2. Evite colocar el dispositivo directamente en el suelo.
- 3. No envuelva el dispositivo en metal.
- 4. Evite las obstrucciones en un radio de 50 cm alrededor del dispositivo, excepto la superficie de instalación.

5. El repetidor debe instalarse entre el panel de control y el periférico.6. Verifique la intensidad de la señal antes de la instalación y se recomienda instalar el dispositivo en la zona indicada de color verde. (No envuelva el detector con las manos cuando compruebe la intensidad de la señal).

7. Se recomienda la instalación vertical de los dispositivos.



1.3 Instalación FAQ (Preguntas frecuentes)

Pregunta 1:¿Por qué la señal es normal durante la instalación, pero no es buena en el uso real?

Respuesta: Compruebe si el entorno de trabajo cambia durante la instalación y el uso real. Tales como obstrucciones causadas por puertas y ventanas cerradas.



Pregunta 2: Una vez completada la instalación, el periférico está fuera de línea.

Respuesta:-Ajuste la posición del panel de control y compruebe si la intensidad de la señal es adecuada para la instalación. -Instalar un repetidor entre el periférico fuera de línea y el panel de control.

-Compruebe al instalar dispositivos las precauciones indicadas.



Capítulo 2 Introducción

Descripción del Sistema

AX PRO es un sistema de alarma inalámbrico diseñado para proteger instalaciones para una protección adecuada como alarma de intrusión. Soporta LAN/Wi-Fi como red de transmisión primaria. El sistema es aplicable a distintos escenarios de mercado, tienda, casa, fábrica, depósito, oficina, etc.

•Innovadora tecnología inalámbrica bidireccional Tri-X.

•Comunicación bidireccional con cifrado AES-128.

•El espectro ensanchado por salto de frecuencia (FHSS) se usa para evitar interferencias, para evitar escuchas ilegales y para habilitar las comunicaciones de acceso múltiple por división de código (CDMA).

- Guía de voz para alerta de alarma, indicación de estado del sistema, solicitud de operación, etc.
- Envia la notificación de alarma a través de mensajes o llamadas telefónicas.

•Vea video a travez de Hik-Connect y clips de video de alarma a través de correos electrónicos, Hik-ProConnect y Hik-Conect.

- Cargar informes de alarmas a CRA.
- Protocolo SIA-DC09 y admite formato de datos Contact ID y SIA.
- •Batería de respaldo de litio de 4520 mAh con 12 H de duración en espera.



iNota

ISUP5.0: un protocolo de Internet de privacidad que se utiliza para acceder a la plataforma de terceros, que admite la carga de informes de alarma, la gestión de AX PRO y la carga de videos cortos.La priorización del mensaje y las indicaciones son las mismas. El AXPRO carga mensajes y da indicaciones de forma sincrónica.

iNota

Protocolo estándar DC-09:ADM-CID: El método de presentación de datos de DC-09 es CID, que no está encriptado y solo para cargar informes de alarma.*ADC-CID: El método de presentación de datos de DC-09 es CID, que está encriptado y solo para cargar informes de alarma.SIA-DCS: El método de presentación de datos de DC-09 es DCS (también llamado protocolo SIA), que no está encriptado y solo para cargar informes de alarma.*SIA-DCS: El método de DC-09 es DCS (también llamado protocolo SIA), que no está encriptado y solo para cargar informes de alarma.*SIA-DCS: El método de presentación de datos de DC-09 es DCS (también llamado protocolo SIA), que está encriptado y solo para cargar informes de alarma.



RSSI Instrucciones para Periféricos

Con respecto a EN 50131-5-3 4.2.2 Requisito de inmunidad a la atenuación.

Intensid de señal	RSSI Valor	Indicador	Observaci ón
Fuerte	>120	Verde	OK para instalar
Medio	81 to 120	Amarillo	OK para instalar
Débil	60 to 80	Rojo	No se recomienda instalar, puede funcionar
Invalida	0 to 59	Verde (flash)No se recomienda instalar,

_____ Nota

Instale periféricos solo si la intensidad de la señal es superior a 80. Para obtener un sistema mucho mejor, instálelo a 120 o más.

AX PRO Opciones de notificaciones

El AX PRO es adecuado para los siguientes requisitos de notificación junto con las sirenas requeridas

Fauino do		I&HAS Grado 2	
Equipo de	Opciones		
notificación	С	E	F
autoalimentado WD audible	2	1	Opcional
ATS	DP1	Opcional	DP2



Capitulo 3 Puesta en Marcha

3.1Gestion de Autoridad

Puede usar HPC (Hik-ProConnet, APP) o HC (Hik-Connect, APP) para activar el dispositivo. Después de la activación, puede administrar el dispositivo transfiriendo permisos entre aplicaciones. También puede usar la cuenta y la contraseña de todas las cuentas para iniciar sesión en el cliente WEB para configurar el dispositivo.



Para obtener más información, consulte el Capítulo 4 Administración de usuarios.



3.2 Activacion

Mientras inicializa el dispositivo con Hik-ProConnect o Hik-Connect, el AX PRO siempre debe agregarse primero a una cuenta de instalador. La cuenta del instalador invitará y transferirá la propiedad a la cuenta del administrador después de finalizar toda la configuración y prueba inicial. Siga los pasos a continuación para inicializar el sistema de alarma inalámbrico.Puede activar el dispositivo por WiFi, LAN o SIM (4G/GPRS).

3.2.1 Activación vía LAN/SIM(4G/GPRS)

Paso1 Crear un sitio (Solo para HPC)

Descargue Hik-ProConnect e inicie sesión con la cuenta del instalador. Cree un sitio donde se pueda agregar el dispositivo con el nombre y la dirección del sitio. El propietario del sitio sería un usuario final, generalmente considerado como administrador.

Paso2 Conectar a la red.

Conecte el dispositivo a Ethernet con LAN o SIM y encienda el dispositivo.

iNota

•Mientras el dispositivo está encendido, el LED de encendido se vuelve verde.

- •Una vez conectado a la red 🙆 El indicador LED se vuelve verde.
- •Asegúrese de que la tarjeta SIM que inserte pueda conectarse a la red.

Paso3 Agregar un dispositivo

1.Abra el sitio. (Solo para HPC)

iNota

Si inicializa el dispositivo con Hik-Connect, no es necesario que cree un sitio primero.

2.Toque+y escanee el código QR en la etiqueta del panel.

3. Toque Add.





4. Toque Next. Puede editar los parámetros del dispositivo o saltar para usarlo directamente.

El panel de control se agregará al sitio (HPC) creado y administrado por la cuenta del instalador, lo que también significa que la cuenta del instalador se creó en el panel.

El instalador ahora puede realizar la configuración y las pruebas del panel antes de implementarlo. Tanto Hik-ProConnect/Hik-ConnectService como el cliente web local pueden iniciar sesión con la cuenta de instalador de Hik-ProConnect/Hik-Connect.

iNota

Si bien inicializa el dispositivo con Hik-connect, no es necesario que cree un sitio primero. Descargue e inicie sesión en la aplicación y agregue el dispositivo escaneando el código QR o ingrese el número de serie del dispositivo.

3.2.2 Activacion con Wi-Fi

Step1 Create a site (Only for HPC)



Download the Hik-ProConnect and login with the installer account.

A site is the place where the alarm system deployed. Create a site where the device can be added to with it's site name and address. The owner of the site would be an end user, usually regarded as administrator.

Step2 Configure the Network on APP

1. Download Hik-Connect/Hik-ProConnect and log in.

2. Power on the AX PRO.

3. Connect your phone to your home Wi-Fi. Make sure that this Wi-Fi can access the Internet normally and the signal is stable.

4. Open the HC or HPC, click +, and select Scan QR Code.



5. Scan the QR code on the back of the control panel and wait for the result.







- 6. Tap **Next**.
- 7. Tap Wireless Connection.



8. Check The device is started. And then tap Next.



18:39		''II 🕹 💼
<	Initialize Device	
		tet.
	Ø	J
	MIKVISION	
	Q02046833	
Power on a sure it is the	nd wait until the device starts ne first time to set the device	s up. Make network.
•	The device is started.	
	Next	
If your devic	e has been used before, reset it first.	network for
	Reset Network	

9. The APP will automatically fill in the home WiFi currently used by the mobile phone into the page, as shown in the figure below. After confirming the WiFi password, tap **Next**.

<	Configure Wi-Fi Network for th	e Devi
	The 5G Wi-Fi is not supported.	
	AAAAAAA-5G 😣 🛛 💩 🗢	(i)
<u>Cha</u>	inge Network	
Net	work:linksys_test	
JC	CS54321	0
Not	required if there's no password.	
	Next	
	Wired Connection	

10. Tap Connect to a Network.





11. Tap **Join**. The mobile phone will disconnect the home Wi-Fi. After interacting information with the control panel, the mobile phone will automatically switch back to the home Wi-Fi.



As shown in the figure above, during the information interacting, the Wi-Fi connected to the mobile phone named "HAP_serial number" (AX PRO serial number)



12. After the control panel broadcasts the "Exit hotspot mode", the following page will appear.



<	Add Device
	Connecting to the Wi-Fi.

13. Wait for the device to join the home WiFi and log in the EZVIZ Cloud.

(1) When the home WiFi signal is good, the control panel will successfully log in to EZVIZ Cloud and complete the binding before the countdown ends.



(2) When the home Wi-Fi signal is unstable, the control panel may not be connected to the EZVIZ Cloud before the countdown ends, and the following page will appear:



<	Add Device	
1	Solid green indicator: Incorrect Wi-Fi password.	
	Reload	
2	Indicator turns off.	
	Refresh Network	
3	Try to reset. <u>How to Reset</u>	
	Cancel	
	Wired Connection	

If you make sure that the home Wi-Fi password is correct and quality is good, tap **Refresh Network**, the control panel will enter a new countdown. You can wait for the connection. If you want to change the home Wi-Fi, you should change the home Wi-Fi connected to the mobile phone first, then press the **RESET** button on the back of the control panel (marked in the figure below). After hearing the voice of "Enter hotspot mode", tap **Reload**. The interface will jump back step 9, you can configure the network again.



iNote

Once the device connected to the network, the 🖒 LED indicator turns green.



3.3 Unbind the Device

3.3.1 Unbind the Device from Your Own Account

When the device is bound to your own account, you can delete it directly.

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.

- 2. Tap 🔍 .
- 3. Tap Delete Device.

<	Settings					
	Device Model: DS-PWA64-L-WB Serial No Device Version: V1.2.6 build 220302					
8	User Management	>				
⊉	System	>				
۲	Network Camera >					
Ĩ	Area	>				
(എ)	Communication Parameters >					
K	Maintenance	>				
(((r	Configure Wi-Fi Network	>				
۵	Authorization Service	>				
	Delete Device					

3.3.2 Unbind the Device from Another Account

Make sure the control panel is in your hands.

The phone and device are on the same network segment.

- 1. Open HC/HPC and tap +.
- 2. Tap Scan QR Code.



3. Scan the QR code on the label of the device.





4. Press the **RESET** button twice quickly on the back of the device.



5. Tap Unbind Device.

<	Results
The device has	been added to the account 8615****47.
	Apply for Sharing
	Unbind Device
You can use	that account or ask the user to share the device to you.

5. Enter verification code and tap Finish.



	Finish	
ZR76	ZR 6-	Ċ
<	Unbind Device	

The device is unbound from the account. You can add it to your account now.



Chapter 4 User Management

4.1 User Management

iNote

- The users can be created in clients.
- The name and password of network user (web client and APP user)can be 1 to 32 characters and 8 to 16 characters.

4.1.1 Invite the Administrator

The administrator was known as site owner in Hik-ProConnect Service.

Shang		< Invite Site O
Dwner Invited	Invite Now	Email
evice Linkage Rule	Exception	Enter Email Account of Hik-Conn
AX PRO 1 Online		Apply for Permission
		Site Information Management
		Configuration
		🗸 AX PRO
		O Device Live View
		O AX PRO

After the initial configuration finished, the installer shall invite the site owner and apply permission of site management and device configuration from the administrator account. The administrator account would be an end user account in the Hik-Connect Service.

- 1. Press "**Invite Now**" Button and enter the email account or phone number account to transfer the site ownership to the administrator. At the same time, the installer will apply permissions from the site owner, such as configuration and management.
- 2. Optional: Check Allow Me to Disable Hik-Connect Service.



iNote

- If the check-box is checked, after you hand over the Site to your customer and your customer approves the request, you can disable Hik-Connect service for devices that you rent to your customer without her/his authorization If Hik-Connect service is disabled, your customer cannot operate on these devices via the Hik-Connect Mobile Client.
- 3. Open the Hik-Connect app and login with the administrator account. The installer service request will be received at notification page. Open the notification detail to accept the installer service and setup permissions. The control panel and other devices in the site will be displayed at your device list.

The administrator account will be added to the control panel, which could be used to login to Hik-Connect app and local web client.

Notificat	ion	 Site Permission 	on Application	• E •	Φ
Event • site permission application(s) Hikvision UK Limited Site:HQ:F-22 Devices Authorized to Installe	Service). 2020-04-02 14:58:41 #:AX PRO	Hikvision UK Limited The installer will be able to maintenance service and o configuring device external authorize site permission t Site ID:fc7513e5a8	provide remote ther services such as linkages after you o him/her.	AX PRO	« …
View Deta	ails	Site HQ-F-22 Devices Authorized to Inst. AX PRO Live View Co	aller All Permissions	DLDIOAAA	
		I have read and agree Policy	eed to Authorization	ALFV5762	
Hik-Connect Notification	n More	Reject	Agree	Hik-Connect Notifi	cation More

4.1.2 Cancel Installer Access

The administrator can cancel the access authorization of the installer.

- 1. Enter the page **More** and tap **Hik-ProConnect**. All sites that managed by the Hik-ProConnect Service are listed on the page.
- 2. Tap the option button at the top-right corner of the site details page, and tap **Cancel Authorization** in the prompt menu.
- 3. Confirm the operation, and the authorization of the installer will be canceled. Once the authorization is canceled, the installer need to apply it again if any access requirement.



Œ.	■ 🕑 🇊 🖑 💷 🖬 🖬 1009	6 🗔 1	7:55	+	🕐 🗘 奈 🏵 💷 🛛 🖸 🚈 🖓	17:56	+	🗘 🇊 🆫 Intil 🖬 2ntil 1009	17:57
	More			<	Hik-ProConnect	È	<	Site Details	
\odot	Pictures and Videos		>	HQ-F-	22		Hikvision	UK Limited	
6	Manage Sharing Settings		>	Installe Device:	r: Hikvision UK Limited AX PRO		The install maintenan configuring	er will be able to provide remote ce service and other services su g device external linkages after y	ch as ou
8	Account Management		>				authorize s	site permission to him/her.	
0	Settings		>				Site ID: fc/ View Detai		
0	Reset Device Password		>				Site: HQ-I	22	×.
	Configure Network		>				Device		
٨	Hik-ProConnect		>				Site:HQ-F-	22	
0	FAQ		>					Edit Permission	
?	Help		>					Site Handover	
Ø	Feedback		>					Cancel Authorization	
Н	lik-Connect Notification	More						Cancel	

4.1.3 Add an Operator

The administrator can share the device to other operators.

🕑 🕑 🌵 🛛 🎧 🌮 tall G zall 89% 💷 17:38	🗘 😭 🖑 tatil 🖬 zatil 96% 🛲 20:06	
• ≡ • •	Recipient	Sharing Details
My Device	Email Address/Mobile Phone Num	Recipient:david.j.xie@gmail.com >
AX PRO 🔩 🚥	david.j.xie@gmail.com	Remark:
		Device to Be Shared
		AX PRO (?)
AAA0IQJQ ••••		
ALFV5762		
Hik-Connect Notification More	Next	Finish

- 1. Tap the
- (share button) in the device list.

2. Enter the Hik-Connect account of the operator.

Administrator can also select which device to be shared.





A sharing message will be sent to the operator's account, and the operator can read the message in the Hik-Connect app.

3. Accept the invitation, and the device will be listed in the device list.

The operator account will be added to the control panel, which could be used to login to Hik-Connect app and local web client.

4.1.4 Delete an Operator

Administrator user can delete an operator.

- 1. Enter the page More and tap Manage Sharing Settings.
- 2. Delete the selected operator or remove it from the device.

	More		/ Managa Shar	ing Cottingo	<	Sharing Details	
\odot	Pictures and Videos	>	Manage Sharing Settings		Recipient: david.j.xie@gmail.com		
			My Device	Others' Devices	Remark:		>
œ	Manage Sharing Settings	>	david.j.xie@gmail.com	>	Device to Be Sha	ared	
8	Account Management		AX PRO				0
0	Settings	>			AX PRO		(?)
\bigcirc	Reset Device Password	>					
	Configure Network	>					
٨	Hik-ProConnect	>					
0	FAQ	>					
?	Help	>					
Ø	Feedback	>					
F	lik-Connect Notification N	fore	Share [Device		Delete	



4.1.5 Disable the Hik-Connect Service

iNote

- The site must be a rental site.
- The installer on the HPC side needs to check **Allow Me to Disable Hik-Connect Service** when inviting the administrator and the administrator on the HC side also accepts this option.

You can go to the **Device** tab to disable Hik-Connect service for one device or all devices in this Site by tapping \mathcal{P} or setting Hik-Connect Service switch to off. You can also delete the devices from the your customer's Hik-Connect account without her/his authorization.

4.1.6 Invite the Installer

1. In HC, tap < in the device list



- 2. Tap Share with Installer and enter the email address.
- 3. Tap **OK**.
- 4. Tap \checkmark \rightarrow Share with Installer \rightarrow Share QR Code
- 5. In HPC, select a site and tap Add Device.
- 6. Scan the QR Code.
- 7. In HC, the user will receive a device authorization application. Go to the application page and tap **Agree**.
- 8. Go to Cloud Service \rightarrow Device Authorization $\rightarrow \bullet \bullet \bullet \rightarrow$ Authorize More Devices
- 9. Select devices and permissions.
- 10. Tap **OK** and the devices will be authorized to the Installer and added to the Site.

4.2 Access Entries

The installer and operators of the AXPRO were assigned different access levels which define the system functions that an individual user can perform. Various user entries are provided for



different user roles with particular access level.

Access entries for Installers (Access Level 3)

• Hik-ProConnect Service

Hik-ProConnect is a service for installers that is used to manage customers' alarm systems located in various sites remotely. Control panels can be added to an installer account on the Hik-ProConnect Service and be managed in sites.

• Local Web Client

Visit the device IP address that can be found out with SADP tool. The installer can login with Hik-ProConnect service account after the panel was added.

• Other Entries

Keypad PINs and tags can be also assigned with installer user at particular access level to perform essential operations.

Access Entries for the Administrator and Operators (Access Level 2)

Hik-Connect Service

The Hik-Connect service can be used for end users to access and manage the devices.

• Local Web Client (for the administrator)

As soon as the panel was added to the end user account on Hik-Connect Service, the Hik-Connect account can be used to login to the web client build in.

Operators cannot login the web client.

Other Entries

Keypad PINs and tags can be also assigned with end user at particular access level to perform essential operations.



Chapter 5 Configuration

5.1 Set-up with Hik-Proconnect

5.1.1 Use the Hik-Proconnect APP

The installer can use the Hik-Proconnect to configure the AX PRO, such as activation, device enrollment etc.

Download and Login the Hik-ProConnect

Download the Hik-ProConnect mobile client and login the client before operating the AX PRO.

Steps

- 1. Download Hik-ProConnect mobile client.
- 2. Optional: Register a new account if it is the first time you use the Hik-ProConnect mobile client.

iNote

- For details, see User Manual of Hik-ProConnect Mobile Client.
- You need an invitation code for registration. Please ask technical supports.
- 3. Run and login the client.

Add AX PRO to the Mobile Client

Add AX PRO to the mobile client before other operations.

Steps

- 1. Power on the AX PRO.
- 2. Create or search a site.
 - Tap +, set site name, time zone, address, city, state/province/region and tap OK to create a site.
 - Enter site name in the search area and tap Search Icon to search a site.
- 3. Tap Add Device.
 - Tap **Scan QR Code** to enter the Scan QR code page. Scan the QR code on the AX PRO.

iNote

Normally, the QR code is printed on the label stuck on the back cover of the AX PRO.

Tap **Manual Adding** to enter the Add Device page. Enter the device serial No. and verification code to add the device.

4. Activate the **Device**.



Add Peripheral to the AX PRO

Add peripheral to the AX PRO.

Steps

- 1. Select a site.
- 2. Select a control device (AX PRO).
- 3. Tap the + icon.
 - Scan the QR code on the peripheral.

Main Page

You can view faults, arm and disarm areas, view device status, etc.

On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.





Enable Alarm

Tap (i) to select Audible Panic Alarm or Silent Panic Alarm.

View Faults

Tap (to view faults.

Area Management

Tap + to add an area. Tap Area to enter the area management page. Refers to **Set Arming/Disarming Schedule** for details.

Arm/Disarm the Area

Arm or disarm the area manually as you desired.

On the device list page, tap the AX PRO and then log in to the device (if required) to enter the Area page.

Operations for a Single Area



- Away Arming: Tap fix to away arm a single area. When all the people in the detection area leave, turn on the Away mode to arm all zones in the area after the defined dwell time.
- Stay Arming: Tap 1 to stay arm a single area. When all the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection set in all the zones of all areas.

Operations for Multiple Areas



- Select Areas: Tap 12° to select areas you want to operate. If you do not select areas, following operations will take effect for all areas.
- Away Arming: Tap for to away arm selected areas. When all the people in the detection area leave, turn on the Away mode to arm all zones in all areas after the defined dwell time.
- Stay Arming: Tap 🏠 to stay arm all areas. When the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection (such as perimeter detector, magnetic contacts, curtain detector in the balcony) set in all the zones of all areas. At the meantime, the detectors inside the detection area are bypassed (such as PIR detectors). People



can move inside the area and alarm will not be triggered.

- **Disarming**: Tap 1 to disarm all areas. In Disarm mode, all the zones of all areas will not trigger alarm, no matter alarm events happen or not.
- Silent Alarm: Tap 🧕 to silent alarms for all areas.

Zone Management

1. Tap **Device** to view linked zones.



- 2. Tap + to add a new zone.
- 3. Tap a zone to enter the management page. You can view device status (e.g. temperature, battery status, single strength, etc.).
- 4. Tap **o** on the upper right corner to enter the zone settings page.
- 5. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

Exit Delay: Exit Delay provides you time to leave through the defense area without alarm. Entry Delay: Entry Delay provides you time to enter the defense area to disarm the system without alarm.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keyboard for users.

iNote

- Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
- You can set Stay Arm Delay Time for the delay zone.


Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

ⁱNote

Two trigger types (by trigger times and by zone status) can be selected for the zone. If the zone status type is selected, set the trigger operation (trigger arming/disarming).

Disabled Zone

Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-Hour Zone

The zone activates all the time with sound/siren output when alarm occurs. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired. (1 to 599) Seconds. It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

6. Enable Cross zone, Silent Alarm, etc. according to your actual needs.

iNote

Some zones do not support the function. Refer to the actual zone to set the function.

Arm Mode

If the zone is a public zone (the zone is belongs to more than one areas), you can set arm mode.

And: When all linked areas are armed, the zone will arm. When any of linked areas is disarmed, the zone will disarm.

Or: When any of the linked areas is armed, the zone will arm. When all linked areas are disarmed, the zone will disarm. When the zone is in alarm, the disarmed areas linked with the zone cannot be armed.

Stay Arm Bypass

The zone will be automatically bypassed in stay arming.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.



If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.

Forbid Bypass on Arming

After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or continuously in a period of time, the alarm will be triggered.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

User Management

The installers (user of Hik-ProConnect) can manage users. If you are the administrator, you can add, edit, and delete users, and assign different permissions to the newly-added users.

Steps

iNote

There are four types of users for the AX PRO, including administrator (or owner), operator, and installer (or setter). Different types of users have different permissions for accessing the functionality of the AX PRO.

- 1. Enter the site, tap the AX PRO and then log in to the device (if required) to enter the AX PRO page.
- 2. Tap Next to invite the user.

Note

The recipient need to accept the invitation.



3. Tap \diamond \rightarrow User Management \rightarrow User.

- 4. Tap a user to enter the User Management page.
- 5. Optional: Perform the following operations if required.

User Permission	You can tap the target user on the user list and then tap Edit Icon set the permissions authorized to the target user.	
	i Note	
	Only the administrator can do such an operation.	
Set Linked Areas	If the target user is an operator, tap the target user on the user list and then tap Linked Areas to set the area linked to the target user.	
	i Note	
	Only the administrator can do such an operation.	
Change Keypad Password	If the target user is an administrator, an installer, or an operator, you can tap the target user on the user list and then tap Change Keypad Password to set the keypad password to the target user.	
Change Duress Password	If the target user is an administrator or an operator, you can tap the target user on the user list and then tap Change Duress Password to set the duress password to the target user.	
	i Note	
	If under duress, you can enter the duress code on the keyboard to arm and disarm area(s) and upload a duress alarm.	
Automation Control	An administrator, an installer or an operator can control the relay module, wall switch and smart plug.	

iNote

- Configuration items and user permission will vary according to the user type.
- You can view linked cards/tags and keyfobs of the user but you do not have permission to configure them.

Card/Tag Management

After adding cards/tags to the wireless AX PRO, you can swipe the card/tag to arm or disarm all



the detectors added to specific area(s) of the AX PRO, and silence alarms.

Note

The tag ID/PIN is a 32 bit long integer, and the variant could be 42949672956.

Steps

- 1. Enter the site, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ User Management \rightarrow Card/Tag to enter the Card/Tag page.
- 3. Tap + to add a Tag.
- 4. When hearing the voice prompt "Swipe Tag", you should present the Tag on the AX PRO Tag presenting area.
 - When hearing a beep sound, the Tag is recognized.
 - The Tag will be displayed on the Tag page.
- 5. Optional: Tap a Tag to enter the Setting Page.
- 6. Tap **Edit Icon** to edit the Tag name.

iNote

- If you log in as an installer, skip this step. Editing Tag name is only available to administrator.
- The name should contain 1 to 32 characters.

7. Slide Enable Tag.

- 8. Select a linked user.
- 9. Select the Tag type

iNote

Different linked users have different Tag permissions.

Operation Tag

You can swipe the Tag to arm or disarm.

Patrol Tag

When you swipe the Tag, the system will upload a record.

10. Optional: Tap **Delete** to delete the Tag.

Device Information

You can change language and select time zone.

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.

- 2. Tap $\bigcirc \rightarrow$ System \rightarrow Configuration to enter the page.
- 3. Select device language and time zone.



4. Enable DST according to your needs.

DST

Daylight saving time (also called summer time) is the practice of advancing clocks during the lighter months so that evenings have more daylight and mornings have less.

System Management

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.

2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow System Management to enter the page.

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are an active faults in a zone, the zone will be automatically bypass.

iNote

You should disable the arming function in the Advanced Settings page. Or the AX PRO arming with fault function cannot be valid.

Forced Arming

After enabled, when manual arming starts, if there are an active faults in a zone, the zone will be automatically bypass.

System Status report

If the option is enabled, the device will upload report automatically when the AX PRO status is changed.

Voice Prompt

If the option is enabled, the AX PRO will enable the text voice prompt. You can set detailed prompt: Fault Prompt On Arming, Fault Prompt On Disarming, Fault Prompt When Armed, Fault Prompt When Disarmed, Voice Prompt On Alarm.

System Volume

The available system volume range is from 0 to 10.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm.

Alarm Duration

The time duration of the panel alarm.

Wireless Supervision Loss



Set the maximum duration for polling loss. The system will report fault if the duration is over the limit.

Bypass on Re-Arm

While enabled, the zone with fault will be bypassed automatically when re-arming.

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.

Fault LED Stay On When Armed

When system is armed, the fault indicator is always on.

Arm LED Stay On

The arm LED is always on.

Hik-Connect Indicator

Enable the Hik-Connect indicator.

Motion Detector Restore

Motion detectors include all PIR detectors.

Power Save Mode

While enabled, the main power supply is off, Wi-Fi enters low power consumption, 4G closes, tag reading fails, LED off, and voice prompt off.

PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Fault Check

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow System Fault Check to enter the page.

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered.

Panel Battery Fault Check

If the option is enabled, when battery is disconnected or out of charge, the device will upload events.

LAN Fault Check



If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

Wi-Fi Fault Check

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Network Fault Check

If the option is enabled, when the cellular data network is disconnected or with other faults, the alarm will be triggered.

Main Power Lost

If the option is enabled, an alarm will be triggered when the main supply is disconnected.

AC Power Loss Delay

The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

Arm Options

Set advanced authority parameters.

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.

2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow Arm Options to enter the page.

You can set the following parameters:

Arm with Fault

Check the faults in the Enable Arming with Fault list, and the device will not stop the arming procedure when faults occurred.

Early Alarm

If you enable the function, when the zone is armed and the zone is triggered, the alarm will be triggered after the set delay time.

iNote

The early alarm will be taken effect only after the delayed zone is triggered.

3. Tap **Save**.

Enrollment Mode

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.



- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow Enrollment Mode to enter the page.
- 3. Tap Enter the Enrollment Mode. You can enroll the peripheral by triggering it.

Network Camera

Add Cameras to the AX PRO

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Network Camera \rightarrow Network Camera Channel to enter the page.
- 3. Tap Add Channel.
- 4. Enter IP address, port, the user name and password of the camera.
- 5. Tap Save Icon.
- 6. Optional: tap Edit or Delete to edit or delete the selected camera.

Set Video Parameters

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Network Camera \rightarrow Event Video Settings to enter the page.
- 3. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality.

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output.

Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.

Set Arming/Disarming Schedule

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.



- 2. Tap $\bigcirc \rightarrow$ Area to enter the page.
- 3. Tap an area in the list, enable the area and select linked areas.
- 4. Enable the auto arm/disarm function and set the auto arm time/auto disarm time. You can also set the late to disarm time, entry delay time, exit delay time, sounder delay time, weekend exception and excepted holiday.

Auto Arm

Enable the area to automatically arm itself in a specific time point.

Auto Arm Time

Set the schedule for the area to automatically arm itself.

Auto Disarm

Enable the area to automatically disarm itself in a specific time point.

Auto Disarm Time

Set the schedule for the area to automatically disarm itself.

Late to Disarm

Enable the device to push a notification to the phone or tablet to remind the user to disarm the area when the area is still armed after a specific time point.

iNote

You should enable the Panel Management Notification function on the Web Client of **Communication Parameters** \rightarrow **Event Communication** before enabling the Late to Disarm function.

Late to Disarm Time

Set the time point mentioned in Late to Disarm.

Auto Arm Sound Prompt

After disabled, the buzzer will not beep before auto arming.

Weekend Exception

If enabled, Auto Arm, Auto Disarm, and Late to Disarm are disabled on the weekend.

Holiday Excepted

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling.

iNote

Up to 6 holiday groups can be set.



Communication

Wired Network

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Wired Network to enter the page.
- 3. Set the parameters.
- Automatic Settings: Enable **DHCP** and set the HTTP port.
- Manual Settings: Disabled DHCP and set IP Address, Subnet Mask, Gateway Address, DNS Server Address.
- 4. **Optional**: Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
- 5. Click Save.

Cellular Data Network

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Cellular Data Network Settings to enter the page.
- 3. Enable Cellular Data Network.
- 4. Tap to select a SIM card. Tap **Parameter Configuration** → **Edit Icon** and set parameters including the user name, access password, APN, MTU and PIN code.
- 5. Tap Save Icon.
- 6. Enable Data Usage Limit.
- 7. Edit Data Used This Month and Data Limited per Month.

Access Number

Input the operator dialing number.

iNote

Only the private network SIM card user needs to enter the access number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Usage Limit

You can enable the function and set the data threshold every month. If data usage is more



than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.

Data Used This Month

The used data will be accumulated and displayed in this text box.

Push Notifications

When an alarm is triggered, if you want to send the alarm notification to the mobile phone, you can set the notification push parameters.

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Push Notification(s) to enter the page.
- 3. Enable the target notification.

Zone Alarm/Lid Opened

The device will push notifications when the zone alarm is triggered or the zone lid opened is triggered or restored.

iNote

You need to set event filtering interval time for phone calling.

Peripherals Lid Opened

The device will push notifications when lid opened of any peripherals is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened of the control panel is triggered or restored.

Panic Alarm

The device will push notifications when panic alarm is triggered or restored by zones, keypads or keyfobs.

Medical Alarm

The device will push notifications when medical alarm is triggered.

Fire Alarm

The device will push notifications when gas alarm is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when the zone status is changed.

Peripherals Status

The device will push notifications when any peripheral status is changed.



Panel Operation

The device will push notifications when the user operates the AX PRO.

Smart Alarm Event

The device will push notifications when the alarm is triggered in thermal cameras.

- 5. Tap Phone Call and SMS.
- 6. Tap + Add Phone Number to enter the phone number.
- 7. Tap the added phone number to enable Phone Call and SMS according to your need.
- 8. (For Phone Call) Set Numbers of Calling.

9. (For SMS) Set Arming Permission, Disarming Permission and Alarm Clearing Permission for areas.

General Hint

You can enter **Common Message.** When the alarm is triggered, your customized content will be added at the beginning of the message sent by the system.

You can import **Common Voice.** When the alarm is triggered, your customized voice will be added at the beginning of the content of the phone dialed by the system.

iNote

Only WAV format is supported, up to 512 KB and 15 s.

10. Check notifications.

Alarm Receiving Center (ARC)

You can set the alarm receiving center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. In the site, tap the AX PRO and then log in to the device (if required).

2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Alarm Receiving Center (ARC) to enter the page.

3. Select an ARC and enable it.

Protocol Type

Select the Protocol Type as ADM-CID, ISUP, SIA-DCS, *SIA-DCS, *ADM-CID or CSV-IP to set uploading mode.

Companies

Select the support company as None, Hungary-Multi Alarm Receiving Company or French Alarm Receiving Company.

Address Type

Select the Address Type as IP Address and Domain Name. Enter server address/domain name,



port number and account code.

Transmission Mode

Select the Transmission Mode as TCP or UDP. UDP is recommended by the SIA DC-09 standard.

Retry Timeout Period

After the selected time, the system will retry to transmit.

Attempts

Set the number of retry attempts.

Polling Option

Set the polling rate with the range from 10 to 3888000 seconds.

Periodic Test

Enter the periodic test interval.

GMT

Enable the Greenwich Mean Time.

Cloud Service Settings

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Cloud Service Settings to enter the page.
- 3. Select the **Communication Mode**.

Auto

The system will select the communication mode automatically according to the sequence of, wired network, Wi-Fi network, and cellular data network. Only when the current network is disconnected, will the device connect to other network.

Wired Network & Wi-Fi Priority

The connection priority order from high to low is: wired network, Wi-Fi, cellular data network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

4. Enable Periodic Test. Enter the periodic test interval.



5. Tap **Save**.

Notification by Email

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Notification by Emails to enter the page.
- 3. Enable **Email**.
- 4. Enter the sender name, sender email address, SMTP server address, SMTP port, user name and password.
- 5. Select the encryption type as **None**, **SSL** or **TLS**.
- 6. Enable Server Authentication.
- 7. Enter receiver name and receiver email address. Tap **Test Receiver Email Address** to test whether the email address is correct.
- 8. Tap **Save**.

FTP Settings

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow FTP Settings to enter the page.
- 3. Select Preferred FTP or Alternated FTP, and enable FTP.
- 4. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.

Server Address and Port

The FTP server address and corresponding port.

User Name and Password

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can check Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server. 4. Tap **Save**.

NAT

Universal Plug and Play (UPnP[™]) is a networking architecture that provides compatibility among



networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow NAT to enter the page.
- 3. Drag the slider to enable UPnP.
- 4. **Optional**: Select the mapping type as **Manual** and set the HTTP port and the service port.
- 5. Click Save to complete the settings

Intercom Service

You can configure the Intercom service for an intercom sounder.

Before You Start

You should enroll an intercom sounder first. Only one sounder can be set as the intercom sounder.

Steps

- 1. Tap **Communication** \rightarrow **Intercom Service** to enter the page.
- 2. Slide to enable the function.
- 3. Set intercom type.

SIP

The control panel will use ARC and SIP server.

IP Receiver Pro

- The control panel will user cloud service.
- 4. Select a sounder and tap Save.

Device Maintenance

You can reboot the device.

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Maintenance \rightarrow Device Maintenance to enter the maintenance page.
- 3. Tap **Test**, and tap **Start Walk Test** to test the whether the device works properly or not.
- 4. Tap Maintenance \rightarrow Reboot Device. The AX PRO will reboot.
- 5. Tap $\bigcirc \rightarrow$ Maintenance \rightarrow Device Upgrade to enter the upgrade page. The AX PRO will upgrade to the latest version.



5.1.2 Use the Hik-ProConnect Portal

For AX PRO security control panel, you can perform operations including arming/disarming area, silence alarm, bypassing zone etc., and remotely configure the control panel on the Portal. You can also apply for PIN (required for upgrading the firmware of AX PRO) and switch the language of AX PRO.

Click **Site** to enter the site list page, and then click the name of a site to enter site details page.

Remotely Operate AX PRO

Click the AX PRO to open the operation panel. And you can perform the following operations.

Operation	Description	
Stay Arm a Specific Area	Select the Area tab, and then click Stay Arming to stay arm the area.	
Away Arm a Specific Area	Select the Area tab and then click Away Arming.	
Disarm a Specific Area	Select the Area tab and then click Disarm.	
Stay Arm Multiple Areas	Select the Area tab, and then select areas and click 🏠.	
Away Arm Multiple Areas	Select the Area tab, and then select areas and click f .	
Disarm Multiple Areas	Select the Area tab, and then select areas and click ^ .	
Silence Alarms of Multiple Areas	Select the Area tab, and then select areas and click Q	
Filter Peripheral Device by Area	Select the Device tab, and then click \checkmark and select an area to only display the peripheral devices linked to the selected area, or select All to display all the peripheral devices linked to all the areas.	
Control Relay	Select the Device tab, and then select a wireless output expander to display the sirens linked to it, and then select siren(s) to enable/disable them.	
Bypass Zone	Select the Device tab, and then select a zone (i.e., detector) and turn on the Bypass switch to bypass the zone.	

Table 4-3 Operation Description





Remotely Configure AX PRO

You can click 🕸 to enter the web page of the security control panel to configure the device.

iNote

For details about security control panel configuration, see the user manual of the device.

Apply for a PIN

You can click $\bullet \bullet \bullet \rightarrow \blacksquare$ to open the Apply for a PIN window, and then PIN code will be



displayed.

Apply for a PIN	×
PIN is used for upgenter the PIN.	grading AX PRO. The upgrade will start once you
Device Name	AX PRO12
Device Serial No.	Q98
PIN	4
	Close
	Close

Switch Language

iNote

You should have applied for a PIN.

You can click $\bullet \bullet \bullet \Rightarrow \Rightarrow$ to open the Language window, and then set the device language and enter the PIN.

Language		×
Make sure a power when switching lan	failure or network outage does not happen guage. Otherwise, the device may be crashed.	
Device Name	AX PRO12	
Device Serial No.	Q9899	
Device Language	English 🗸	
* PIN		
	OK Cancel	

Health Monitoring

1. Enter the Hik-ProConnect Portal web site, and click **Health Monitoring** \rightarrow **Health Status** to enter



the page.

2. Select a site.



3. Click Health Check, and click Check Now.

When checking is completed, you can view the status and reports of devices. You can also export the report.

Health Check			×
	新加坡PE线上验证		
	Device Name	Status	
	热成像DS-2TD2617B-6-PA(E38709	Abnormal View Report	
	iDS-7216HQHI-M2-FA(D93795654)	Abnormal View Report	
	AX PRO	Normal View Report	
checking completed	DB1(D93265096)	Normal	
Note	客流DS-2CD3726G2T-IZS(E41491	Normal View Report	
During health check, the system will check the status and performance of the devices. Do NOT perform operations for devices in this site during health check, including adding, deleting, upgrading, remote configuration, etc.			
	Run in	Background Export Report	

4. Click 🮯 to get the latest device status.

5.2 Set-up with Hik-Connect

The operator can use the Hik-Connect to control the device, such as general arming/disarming operation, and user management etc.



Download and Login the Mobile Client

Download the Hik-Connect mobile client and login the client before operating the AX PRO.

Steps

- 1. Download Hik-Connect mobile client.
- 2. Optional: Register a new account if it is the first time you use the Hik-Connect mobile client.

iNote

For details, see User Manual of Hik-Connect Mobile Client.

3. Run and login the client.

Add AX PRO to the Mobile Client

Add an AX PRO to the mobile client before other operations.

Steps

- 1. Power on the AX PRO.
- 2. Select adding type.

Tap $+ \rightarrow$ Scan QR Code to enter the Scan QR code page. Scan the QR code on the AX PRO.

iNote

Normally, the QR code is printed on the label stuck on the back cover of the AX PRO.

Tap $+ \rightarrow$ Manual Adding to enter the Add Device page. Enter the device serial No. with the Hik-Connect Domain adding type.

- 3. Tap 📄 to search the device.
- 4. Tap Add on the Results page.
- 5. Enter the verification code and tap **OK**.
- 6. After adding completed, enter the device alias and tap **Save**.
- 7. Optional: Tap $\bigcirc \rightarrow$ **Delete Device** to delete the device.
- 8. Optional: Tap $\mathbf{0} \rightarrow \mathbf{0}$ to edit the device name.

Add Peripheral to the AX PRO

Add peripheral to the AX PRO.

Steps

- 1. Select a control device (AX PRO).
- 2. Tap + .
 - Tap Scan QR Code to enter the Scan QR code page. Scan the QR code on the peripheral.



Main Page

You can view faults, arm and disarm areas, view device status, etc.

On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.



Enable Alarm

Tap (i) to select Audible Panic Alarm or Silent Panic Alarm.

View Faults

Tap (to view faults.

Area Management

Tap + to add an area. Tap Area to enter the area management page. Refers to **Set Arming/Disarming Schedule** for details.

Arm/Disarm the Area

Arm or disarm the area manually as you desired. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the Area page.

Operations for a Single Area



Area	1	\bigcirc
Away		

- Away Arming: Tap fix to away arm a single area. When all the people in the detection area leave, turn on the Away mode to arm all zones in the area after the defined dwell time.
- Stay Arming: Tap 1 to stay arm a single area. When all the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection set in all the zones of all areas.

Operations for Multiple Areas



- Select Areas: Tap $\leq B$ to select areas you want to operate. If you do not select areas, following operations will take effect for all areas.
- Away Arming: Tap fix to away arm selected areas. When all the people in the detection area leave, turn on the Away mode to arm all zones in all areas after the defined dwell time.
- Stay Arming: Tap 🛕 to stay arm all areas. When the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection (such as perimeter detector, magnetic contacts, curtain detector in the balcony) set in all the zones of all areas. At the meantime, the detectors inside the detection area are bypassed (such as PIR detectors). People can move inside the area and alarm will not be triggered.
- **Disarming**: Tap 1 to disarm all areas. In Disarm mode, all the zones of all areas will not trigger alarm, no matter alarm events happen or not.
- Silent Alarm: Tap 🖸 to silent alarms for all areas.

Zone Management

1. Tap **Device** to view linked zones.





- 2. Tap + to add a new zone.
- 3. Tap a zone to enter the management page. You can view device status (e.g. temperature, battery status, single strength, etc.).
- 4. Tap 💿 on the upper right corner to enter the zone settings page.
- 5. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

Exit Delay: Exit Delay provides you time to leave through the defense area without alarm. Entry Delay: Entry Delay provides you time to enter the defense area to disarm the system without alarm.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keyboard for users.

iNote

- Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
- You can set Stay Arm Delay Time for the delay zone.

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

iNote

Two trigger types (by trigger times and by zone status) can be selected for the zone. If the zone status type is selected, set the trigger operation (trigger arming/disarming).

Disabled Zone



Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-Hour Zone

The zone activates all the time with sound/siren output when alarm occurs. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired. (1 to 599) Seconds. It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

6. Enable Cross zone, Silent Alarm, etc. according to your actual needs.

iNote

Some zones do not support the function. Refer to the actual zone to set the function.

Arm Mode

If the zone is a public zone (the zone is belongs to more than one areas), you can set arm mode.

And: When all linked areas are armed, the zone will arm. When any of linked areas is disarmed, the zone will disarm.

Or: When any of the linked areas is armed, the zone will arm. When all linked areas are disarmed, the zone will disarm. When the zone is in alarm, the disarmed areas linked with the zone cannot be armed.

Stay Arm Bypass

The zone will be automatically bypassed in stay arming.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.

If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.

Forbid Bypass on Arming



After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or continuously in a period of time, the alarm will be triggered.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

- 7. If required, link a PIRCAM or a camera for the zone.
- 8. Click **OK**.

View Status

Tap Status to view peripherals' status.

Bypass Zone

When the area is armed, you can bypass a particular zone as you desired.

Before You Start

Link a detector to the zone.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the Area page.
- 2. Tap **Device**.
- 3. Tap a zone in the Device tab.
- 4. Tap 💿 to enter the Settings page.
- 5. Enable **Bypass** and the zone will be in the bypass status.

Bypass Status

The detector in the zone does not detect anything and you will not receive any alarm from the zone.

User Management

The administrator and the installers can manage users. If you are the administrator, you can add,



edit, and delete users, and assign different permissions to the newly-added users.

Steps

iNote

There are four types of users for the AX PRO, including administrator (or owner), operator, and installer (or setter). Different types of users have different permissions for accessing the functionality of the AX PRO.

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the AX PRO page.
- 2. Tap < to enter the Recipient Page.
- 3. Select a user to invite.
 - Scan QR code to invite a user.
 - Enter email address/mobile phone number to invite a user.
 - Select a user in the list.
- 4. Tap Next to invite the user.

i Note

The recipient need to accept the invitation.

5. Tap \diamond \rightarrow User Management \rightarrow User.

- 6. Tap a user to enter the User Information Page.
- 7. Optional: Perform the following operations if required.
 - User PermissionYou can tap the target user on the user list and then tapImage: Comparison of the setthe permissions authorized to the target user.

iNote

Only the administrator can do such an operation.

Set Linked AreasIf the target user is an operator, tap the target user on the user list
and then tap Linked Areas to set the area linked to the target user.

iNote

Only the administrator can do such an operation.

Change KeypadIf the target user is an administrator, an installer or an operator, youPasswordcan tap the target user on the user list and then tap Change KeypadPassword to set the keypad password to the target user.



	i Note
	The password (PIN code) is allowed to be 4 to 6 digits. No number is disallowed, with 10,000 to 100,000 differs, and no limit of the digit combination.
	After you add one keypad, you can add PIN code (Keypad Password) in the user menu. When you click in the input box, there will be indication shows that 4 to 6 numbers allowed. This is the same for each user
Change Duress Password	If the target user is an administrator or an operator, you can tap the target user on the user list and then tap Change Duress Password to set the duress password to the target user.
	i Note
	If under duress, you can enter the duress code on the keypad to arm and disarm area(s) and upload a duress alarm.
Automation Control	An administrator, an installer or an operator can control the relay module, wall switch and smart plug.
Ti Note	

- Configuration items and user permission will vary according to the user type.
- You can view linked Card/Tag and Wireless Keyfob of the user but you do not have permission to configure them.

8. Optional: (Only for the administrator) Click + to add a user.

Card/Tag Management

After adding cards/tags to the wireless AX PRO, you can swipe the card/tag to arm or disarm all the detectors added to specific area(s) of the AX PRO, and silence alarms.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ User Management \rightarrow Card/Tag to enter the page.
- 3. Tap + to add a card/tag.
- 4. When hearing the voice prompt "Swipe Tag", you should present the card/tag on the AX PRO card/tag presenting area.
 - When hearing a beep sound, the card/tag is recognized.



- The Tag will be displayed on the card/tag page.
- 5. Optional: Tap a card/tag to enter the Setting Page.
- 6. Tap 🗹 to edit the Tag name.

iNote

- If you log in as an installer, skip this step. Editing Tag name is only available to administrator.
- The name should contain 1 to 32 characters.

7. Slide Enable Card/Tag.

- 8. Select a linked user.
- 9. Select the tag type

iNote

Different linked users have different tag permissions.

Operation Tag

You can swipe the tag to arm or disarm.

Patrol Tag

When you swipe the tag, the system will upload a record.

10. Optional: Tap **Delete** to delete the tag.

Device Information

You can change language and select time zone.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow Configuration to enter the page.
- 3. Select device language and time zone.
- 4. Enable DST according to your needs.

DST

Daylight saving time (also called summer time) is the practice of advancing clocks during the lighter months so that evenings have more daylight and mornings have less.



System Management

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow System Management to enter the page.

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are an active faults in a zone, the zone will be automatically bypass.

iNote

You should disable the arming function in the Advanced Settings page. Or the AX PRO arming with fault function cannot be valid.

Forced Arming

After enabled, when manual arming starts, if there are an active faults in a zone, the zone will be automatically bypass.

System Status report

If the option is enabled, the device will upload report automatically when the AX PRO status is changed.

Voice Prompt

If the option is enabled, the AX PRO will enable the text voice prompt. You can set detailed prompt: Fault Prompt On Arming, Fault Prompt On Disarming, Fault Prompt When Armed, Fault Prompt When Disarmed, Voice Prompt On Alarm.

System Volume

The available system volume range is from 0 to 10.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm(lid opened alarm).

Alarm Duration

The time duration of the panel alarm.

Wireless Supervision Loss

Set the maximum duration for polling loss. The system will report fault if the duration is over the limit.

Bypass on Re-Arm

While enabled, the zone with fault will be bypassed automatically when re-arming.

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.



Fault LED Stay On When Armed

When system is armed, the fault indicator is always on.

Arm LED Stay On

The arm LED is always on.

Hik-Connect Indicator

Enable the Hik-Connect indicator.

Motion Detector Restore

Motion detectors include all PIR detectors.

Power Save Mode

While enabled, the main power supply is off, Wi-Fi enters low power consumption, 4G closes, tag reading fails, LED off, and voice prompt off.

PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Fault Check

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow System Fault Check to enter the page.

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered.

Panel Battery Fault Check

If the option is enabled, when battery is disconnected or out of charge, the device will upload events.

LAN Fault Check

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

Wi-Fi Fault Check

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Network Fault Check

If the option is enabled, when the cellular data network is disconnected or with other faults, the



alarm will be triggered.

Main Power Lost

If the option is enabled, an alarm will be triggered when the main supply is disconnected.

AC Power Loss Delay

The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

Arm Options

Set advanced authority parameters.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow Arm Options to enter the page.

You can set the following parameters:

Arm with Fault

Check the faults in the Enable Arming with Fault list, and the device will not stop the arming procedure when faults occurred.

Early Alarm

If you enable the function, when the zone is armed and the zone is triggered, the alarm will be triggered after the set delay time.

iNote

The early alarm will be taken effect only after the delayed zone is triggered.

3. Tap **Save**.

Enrollment Mode

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ System \rightarrow System Options \rightarrow Enrollment Mode to enter the page.
- 3. Tap Enter the Enrollment Mode. You can enroll the peripheral by triggering it.

Network Camera

Add, edit and delete network camera channels.



Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ Network Camera \rightarrow Network Camera Channel to enter the page.
- 3. Tap + Add Channel, and enter IP address, user name, password to add the channel.
- 4. Tap the Camera. You can view its parameters or tap **Delete** to delete it.
- 5. Tap 🖸 to edit parameters.

Set Video Parameters

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Network Camera \rightarrow Event Video Settings to enter the page.
- 3. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality.

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output.

Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.

Before Alarm

The recording time length before the alarm.

After Alarm

The recording time length after the alarm.

Set Arming/Disarming Schedule

Steps

1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.

- 2. Tap $\bigcirc \rightarrow$ Area to enter the page.
- 3. Tap an area in the list, enable the area and select linked areas.



4. Enable the auto arm/disarm function and set the auto arm time/auto disarm time. You can also set the late to disarm time, entry delay time, exit delay time, sounder delay time, weekend exception and excepted holiday.

Auto Arm

Enable the area to automatically arm itself in a specific time point.

Auto Arm Time

Set the schedule for the area to automatically arm itself.

Auto Disarm

Enable the area to automatically disarm itself in a specific time point.

Auto Disarm Time

Set the schedule for the area to automatically disarm itself.

Late to Disarm

Enable the device to push a notification to the phone or tablet to remind the user to disarm the area when the area is still armed after a specific time point.

iNote

You should enable the Panel Management Notification function on the Web Client of **Communication Parameters** \rightarrow **Event Communication** before enabling the Late to Disarm function.

Late to Disarm Time

Set the time point mentioned in Late to Disarm.

Auto Arm Sound Prompt

After disabled, the buzzer will not beep before auto arming.

Weekend Exception

If enabled, Auto Arm, Auto Disarm, and Late to Disarm are disabled on the weekend.

Holiday Excepted

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling.

iNote

Up to 6 holiday groups can be set.



Communication

Wired Network

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Wired Network to enter the page.
- 3. Set the parameters.
- Automatic Settings: Enable **DHCP** and set the HTTP port.
- Manual Settings: Disabled DHCP and set IP Address, Subnet Mask, Gateway Address, DNS Server Address.
- 4. **Optional**: Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
- 5. Click Save.

Cellular Data Network

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Cellular Data Network Settings to enter the page.
- 3. Enable Cellular Data Network.
- 4. Tap to select a SIM card. Tap **Parameter Configuration** → **Edit Icon** and set parameters including the user name, access password, APN, MTU and PIN code.
- 5. Tap Save Icon.
- 6. Enable Data Usage Limit.
- 7. Edit Data Used This Month and Data Limited per Month.

Access Number

Input the operator dialing number.

iNote

Only the private network SIM card user needs to enter the access number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Usage Limit

You can enable the function and set the data threshold every month. If data usage is more



than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.

Data Used This Month

The used data will be accumulated and displayed in this text box.

Push Notifications

When an alarm is triggered, if you want to send the alarm notification to the mobile phone, you can set the notification push parameters.

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Push Notification(s) to enter the page.
- 3. Select an ARC or the APP.
- 4. Enable the target notification.

Zone Alarm/Lid Opened

The device will push notifications when the zone alarm is triggered or the zone lid opened is triggered or restored.

iNote

You need to set event filtering interval time for phone calling.

Peripherals Lid Opened

The device will push notifications when lid opened of any peripherals is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened of the control panel is triggered or restored.

Panic Alarm

The device will push notifications when panic alarm is triggered or restored by zones, keypads or keyfobs.

Medical Alarm

The device will push notifications when medical alarm is triggered.

Fire Alarm

The device will push notifications when gas alarm is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when the zone status is changed.

Peripherals Status



The device will push notifications when any peripheral status is changed.

Panel Operation

The device will push notifications when the user operates the AX PRO.

Smart Alarm Event

The device will push notifications when the alarm is triggered in thermal cameras.

- 5. Tap Phone Call and SMS.
- 6. Tap + Add Phone Number to enter the phone number.
- 7. Tap the added phone number to enable **Phone Call** and **SMS** according to your need.
- 8. (For Phone Call) Set Numbers of Calling.

9. (For SMS) Set Arming Permission, Disarming Permission and Alarm Clearing Permission for areas.

General Hint

You can enter **Common Message.** When the alarm is triggered, your customized content will be added at the beginning of the message sent by the system.

You can import **Common Voice.** When the alarm is triggered, your customized voice will be added at the beginning of the content of the phone dialed by the system.

iNote

Only WAV format is supported, up to 512 KB and 15 s.

10. Check notifications.

Alarm Receiving Center (ARC)

You can set the alarm receiving center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. In the site, tap the AX PRO and then log in to the device (if required).

2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Alarm Receiving Center (ARC) to enter the page.

3. Select an ARC and enable it.

Protocol Type

Select the Protocol Type as ADM-CID, ISUP, SIA-DCS, *SIA-DCS, *ADM-CID or CSV-IP to set uploading mode.

Companies

Select the support company as None, Hungary-Multi Alarm Receiving Company or French Alarm Receiving Company.

Address Type

Select the Address Type as IP Address and Domain Name. Enter server address/domain name,


port number and account code.

Transmission Mode

Select the Transmission Mode as TCP or UDP. UDP is recommended by the SIA DC-09 standard.

Retry Timeout Period

After the selected time, the system will retry to transmit.

Attempts

Set the number of retry attempts.

Polling Option

Set the polling rate with the range from 10 to 3888000 seconds.

Periodic Test

Enter the periodic test interval.

GMT

Enable the Greenwich Mean Time.

Cloud Service Settings

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Cloud Service Settings to enter the page.
- 3. Select the **Communication Mode**.

Auto

The system will select the communication mode automatically according to the sequence of, wired network, Wi-Fi network, and cellular data network. Only when the current network is disconnected, will the device connect to other network.

Wired Network & Wi-Fi Priority

The connection priority order from high to low is: wired network, Wi-Fi, cellular data network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

4. Enable Periodic Test. Enter the periodic test interval.



5. Tap **Save**.

Notification by Email

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow Notification by Emails to enter the page.
- 3. Enable **Email**.
- 4. Enter the sender name, sender email address, SMTP server address, SMTP port, user name and password.
- 5. Select the encryption type as **None**, **SSL** or **TLS**.
- 6. Enable Server Authentication.
- 7. Enter receiver name and receiver email address. Tap **Test Receiver Email Address** to test whether the email address is correct.
- 8. Tap **Save**.

FTP Settings

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow FTP Settings to enter the page.
- 3. Select Preferred FTP or Alternated FTP, and enable FTP.
- 4. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.

Server Address and Port

The FTP server address and corresponding port.

User Name and Password

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can check Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server. 4. Tap **Save**.

NAT

Universal Plug and Play (UPnP[™]) is a networking architecture that provides compatibility among



networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Communication Parameters \rightarrow NAT to enter the page.
- 3. Drag the slider to enable UPnP.
- 4. **Optional**: Select the mapping type as **Manual** and set the HTTP port and the service port.
- 5. Click Save to complete the settings

Intercom Service

You can configure the Intercom service for an intercom sounder.

Before You Start

You should enroll an intercom sounder first. Only one sounder can be set as the intercom sounder.

Steps

- 1. Tap **Communication** \rightarrow **Intercom Service** to enter the page.
- 2. Slide to enable the function.
- 3. Set intercom type.

SIP

The control panel will use ARC and SIP server.

IP Receiver Pro

The control panel will user cloud service.

4. Select a sounder and tap Save.

Device Maintenance

You can reboot the device.

- 1. In the site, tap the AX PRO and then log in to the device (if required).
- 2. Tap $\bigcirc \rightarrow$ Maintenance \rightarrow Reboot Device. to enter the maintenance page. The AX PRO will reboot.
- 3. Tap **◎** → **Maintenance** → **Device Upgrade** to check the system version. The AX PRO will upgrade to the latest version.



technical support will be able to collect logs relating to the device remotely and upload them to our server for troubleshooting. You can set the validity period according to actual needs. This function will be disabled after the set validity period.

Wi-Fi Connection

You can make the AX PRO connect to Wi-Fi through APP.

Steps

- 1. On the device list page, tap the AX PRO and then log in to the device (if required) to enter the page.
- 2. Tap $\bigcirc \rightarrow$ Configure Wi-Fi Network.
- 3. Follow the instructions on the page and change the AX PRO to the AP mode. Tap Next.
- 4. Select a stable Wi-Fi for the device to connect.
- 5. Back to configuration page to enter the Wi-Fi password and tap **Next**.
- 6. Tap Connect to a network and wait for connection.

After the connection is completed, the AX PRO will prompt to exit AP mode and automatically switch to STA mode.

Check Alarm Notification

When an alarm is triggered, and you will receive an alarm notification. You can check the alarm information from the mobile client.

Before You Start

- Make sure you have linked a zone with a detector.
- Make sure the zone is not bypassed.
- Make sure you have not enabled the silent zone function.

Steps

1. Tap Notification in the mobile client to enter the page.

All alarm notifications are listed in Notification page.

2. Select an alarm and you can view the alarm details.



	Event(40)	•••
10-25	Mon	
03:22	Disarmed AX PRO-myM2H(Area 1: mydev Operation)	
9 03:18	Panic Alarm AX PRO-myM2H(mydev Alarm)	
9	Panic Alarm AX PRO-myM2H(mydev Alarm)	
02:58	Away Armed AX PRO-myM2H(Area 1: mydev Operation)	•
02:58	Armed in Home mode AX PRO-myM2H(Area 1: mydev Operation)	•
02:58	Disarmed AX PRO-myM2H(Area 1: mydev Operation)	•
10-22	Fri	
O Hik-Cont	vert Cloud Service Natification	

- 3. **Optional**: If the zone has linked a camera, you can view the playback when the alarm is triggered.
- 4. **Optional**: Tap **T** to search events by dates or devices.

5.3 Set-up with the Web Client

Steps

- 1. Connect the device to the Ethernet.
- 2. Search the device IP address via the client software and the SADP software.
- 3. Enter the searched IP address in the address bar.
- 4. Use the activation user name and password to login.

iNote

- Only the administrator and the installer can login to the web client.
- The user name and the password are the ones when activating via Hik-Connect or Hik-ProConnect.

You can view the user, device, and area status on the overview page.





5.3.1 Communication Settings

Wired Network

You can set the device IP address and other network parameters.

Steps

iNote

Functions varied depending on the model of the device.

1. Click **Communication**→ **Wired Network** to enter the page.



Wired Network Settings				
DHCP				
IP Address	10.22.98.134			
Subnet Mask	255.255.255.0			
Gateway Address	10.22.98.254			
MAC Address	98:df:82:98:ac:f0			
DNS1 Server Address	10.1.7.97			
DNS2 Server Address	10.1.7.98			
HTTP Port	80			
	Save			

- 2. Set the parameters.
- Automatic Settings: Enable **DHCP** and set the HTTP port.
- Manual Settings: Disabled DHCP and set IP Address, Subnet Mask, Gateway Address, DNS Server Address.
- 3. **Optional**: Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
- 4. Click Save.

Wi-Fi

You can set the Wi-Fi parameters if there are secure and credible Wi-Fi networks nearby.

Steps

1. Click **Communication** \rightarrow **Wi-Fi** to enter the Wi-Fi page.



Status of	STA/AP Swit						
	Switch Mode:	STA Mode					
Wi-Fi							
	SSID Wi-Fi	NETGEAR91					
	Wi-Fi Password						
	Encryption Mode	WPA2-personal		-			
Network L	ist						
		Name	Channel	. Signal S	Encryption Mode	Operation	
		NETGEAR91	13	55	WPA2-personal	Disconnect	^
		HAP_Q02737101	11	70	WPA2-personal	Connect	
		HAP_Q01786103	11	60	WPA2-personal	Connect	
		HAP_Q02630875	11	59	WPA2-personal	Connect	
		HUAWEI-B311-8E54	5	58	WPA2-personal	Connect	
		HAP_Q01877075	11	58	WPA2-personal	Connect	
		HAP_Q98998931	11	56	WPA2-personal	Connect	~
		Save					

- 2. Connect to a Wi-Fi.
- Manually Connect: Input the SSID Wi-Fi and Wi-Fi Password, select Encryption Mode and click Save.
- Select from Network List: Select a target Wi-Fi from the Network list. Click Connect and input Wi-Fi password and click Connect.
- 3. Click **WLAN** to enter the WLAN page.

Wi-Fi Settings	WLAN	
D	НСР	
IF	P Address	192.168.1.138
S	ubnet Mask	255.255.255.0
G	ateway Address	192.168.1.1
N	IAC Address	80:9f:9b:0a:46:67
D	NS1 Server Address	192.168.1.1
D	NS2 Server Address	
		Save

4. Set IP Address, Subnet Mask, Gateway Address, and DNS Server Address.



If enable DHCP, the device will gain the Wi-Fi parameters automatically.

5. Click Save.

Cellular Network

Set the cellular network parameters if you insert a SIM card inside the device. By using the cellular network, the device can upload alarm notifications to the alarm center.

Before You Start

Insert a SIM card into the device SIM card slot.

Steps

1. Click **Communication** → **Cellular Data Network** to enter the Cellular Data Network Settings page.

Cellular Data Network Settings	
Enable	
SIM Card1	
Access Number	*99***1#
	For accessing private network, you need to enter the accessing number.
User Name	
Access Password	
APN	
MTU	1400
PIN Code	
Data Usage Limit	
Data Used This Month	0.0 M
Data Limited per Month	0 M
SIM Card2	

iNote

Only the private network SIM card user needs to enter the access number.

- 2. Enable the function.
- 3. Set the cellular data network parameters.

Access Number

Input the operator dialing number.



Only the private network SIM card user needs to enter the access number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Usage Limit

You can enable the function and set the data threshold every month. If data usage is more than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.

Data Used This Month

The used data will be accumulated and displayed in this text box.

4. Click Save.

Alarm Center

You can set the alarm center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. Click **Communication** \rightarrow **Alarm Receiving Center** to enter the Alarm Receiving Center page.



ARC1	ARC2		
Enable			
Protoco	і Туре	ADM-CID	r
GMT			
Address	s Type (Alarm Receiver Server)	IP	r
Server	Address (Alarm Receiver Server)	0.0.0.0	
Port No	. (Alarm Receiver Server)	0	
Account	t Code		
Transm	ission Mode	ТСР	r
Impulse	e Counting Time	20	s
Attempt	s	3	
Polling	Rate		s Enable
Periodio	c Test		
Compar	nies	None	r
Intruder	Verification as a Service		
		Save	

2. Select the **ARC** as **1** or **2** for configuration, and slide the slider to enable the selected alarm receiver center.

Note

Only if the alarm receiver center 1(ARC1) is enabled, you can set the alarm receiver center 2 as the **backup channel** and edit the channel parameters.

3. Select the **Protocol Type** as **ADM-CID**, **ISUP**, **SIA-DCS**, ***SIA-DCS**, ***ADM-CID**, **CSV-IP**, or **FSK Module** to set uploading mode.

iNote

Standard DC-09 Protocol

ADM-CID: The data presenting method of DC-09 is CID, which is not encrypted and only for uploading alarm report.

*ADM-CID: The data presenting method of DC-09 is CID, which is encrypted and only for uploading alarm report.

SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is not encrypted and only for uploading alarm report.

*SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is encrypted and only for uploading alarm report.



ADM-CID or **SIA-DCS**: You should select the **Alarm Receiver Type** as **IP** or **Domain name**, and enter the IP address, port number, account code, impulse counting time, attempts, polling rate.

iNote

Set the polling rate with the range from 10 to 3888000 seconds.

ISUP, CSV-IP, or FSK: You do not need to set the protocol parameters.

***SIA-DCS** or ***ADM-CID** You should select the **Alarm Receiver Type** as **IP** or **Domain name**, and enter the IP address, port number, account code, impulse counting time, attempts, polling rate, encryption arithmetic, password length and secret key.

iNote

Set the polling rate with the range from 10 to 3888000 seconds.

4. Click Save.

Use PIRCAM to Upload Pictures or Videos

You can enable the PIRCAM function to upload pictures or videos.

1. Upload Pictures

You can choose to upload 1 to 20 pictures.

- (1) Click **Communication** \rightarrow **Alarm Receiving Center** to enter the page.
- (2) Slide the slider to enable the selected alarm receiver center.
- (3) Select the **Protocol Type** as **SIA-DCS**.
- (4) Select the Companies as French Alarm Receiving Company.
- (5) Click Save.

Alarm Receiving Center	1	*			
Enable					
Protocol Type	ADM-CID	•			
GMT					
Address Type (Alarm	IP	•			
Server Address (Alarm	0.0.0.0				
Port No. (Alarm Receiv	0				
Account Code					
Transmission Mode	ТСР	•			
Retry Timeout Period	20	s			
Attempts	3				
Polling Rate		s Enable			
Periodic Test					
Companies	French Alarm Receiving Company	×			
PIRCAM Picture Uploa	Picture	•			
HTTP Data Transmission	Default				
	Destination IP or Host Name	URL	Protocol	Port	Test
	0.0.0.0	1	HTTP	80	Test
	0.0.0.0	1	HTTP	80	Test

(6) Configure SMTP or FTP parameters.
 Configure SMTP parameters:
 Click Communication → Notification by Email.



Enable **Video Verification Events** and set corresponding parameters. For details, see Notification by Email. Click **Save**.

Notification by Email		
Video Verification Events		
Sender Name		
Sender's Address		
SMTP Server address		
SMTP Port	25	
Encryption Type	None -	
Server Authentication		
User Name		
Password		
Confirm Password		
Receiver Name		
Receiver		Receiver Address Test
	Save	

Configure FTP parameters:

Click **Communication** \rightarrow **FTP** to enter the FTP Settings page.

Slide the slider to enable FTP and set corresponding parameters. For details, see FTP. Click **Save**.

ttings		
FTP Type	Preferred FTP	-
Enable FTP		
Address Type	IP	•
FTP Server		
Port No.	21	
Protocol Type	FTP	•
Enable Anonymity		
User Name		
Password		
Directory Structure	Save in Root Directory	•
Parent Directory	Custom	•
Secondary Directory	Custom	•

2. Upload Videos

In this condition, when the PIRCAM is set to catch more than two pictures, videos will be uploaded.

- (1) Click **Communication** \rightarrow **Alarm Receiving Center** to enter the page.
- (2) Slide the slider to enable the selected alarm receiver center.
- (3) Select the **Protocol Type** as **SIA-DCS**.



- (4) Click Save.
- (5) Configure SMTP or FTP parameters as same as Upload Photos.

Notification Push

When an alarm is triggered, if you want to send the alarm notification to the client, alarm center, cloud or mobile phone, you can set the notification push parameters.

Steps

1. Click Communication \rightarrow Event Types Notification.

iVMS-4200	Alarm Receiving Center	APP	Phone Call and SMS	
	Zone Alarm/Lid Opened			
	Peripherals Lid Opened			
	Panel Lid Opened			
	Panic Alarm			
	Medical Alarm			
	Fire Alarm			
	Gas Alarm			
	Panel Status			
	Zone Status			
	Peripherals Status			
	Panel Operation			
	Smart Alarm Event			
			Save	

2. Enable the target notification.

Zone Alarm/Lid Opened

The device will push notifications when the zone alarm (on web client, software client or mobile client) is triggered or the zone peripherals alarm is triggered or restored.

Peripherals Lid Opened

The device will push notifications when lid opened alarm of any peripheral is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened alarm of the control panel is triggered or restored.

Panic Alarm



The device will push notifications when panic alarm on keypads or keyfobs is triggered or restored.

Medical Alarm

The device will push notifications when medical alarm on keypads is triggered.

Fire Alarm

The device will push notifications when fire alarm on keypads is triggered or a user presses the fire alarm key on the keypad.

Gas Alarm

The device will push notifications when gas alarm on keypads is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when any zone status is changed.

Peripherals Status

The device will push notifications when any peripheral status is changed.

Panel Operation

The device will push notifications when the user operate the control panel.

Smart Alarm Event

The device will push notifications when alarm is triggered in network cameras.

- 3. **Optional:** For **Alarm Receiving Center**, you need to select center number before settings.
- 4. **Optional:** If you want to send the alarm notifications to the mobile client, you should set **Phone Call and SMS** parameters.



iVMS-4200	Alarm Receiving Center APP Ph	one Call and SMS	
	Mobile Phone Index	1	*
	Mobile Phone Number		(+86XXXXXX)
	Message Settings	Telephone	Message
		Voice Call	
		Filtering Interval Time	10min - 0
		Number of Calls	2 -
		Zone Alarm/Lid Opened	
		Peripherals Lid Opened	
		Panel Lid Opened	
		Panic Alarm	
		Medical Alarm	
		Fire Alarm	
		Gas Alarm	
		Panel Status	
		Zone Status	
		Peripherals Status	
		Smart Alarm Event	
	General Hint		
	O Common Voice		Import Clear
		Please upload a WAV audio file of less	s than 512KB, single channel and 8KHz sampling rate.
	O Common Message		
	-		

- (1) Set the Mobile Phone Index and Mobile Phone Number.
- (2) Check Voice Call on Telephone page.
- (3) Select time of Filtering Interval Time and Number of Calls.
- (4) Check SMS on Message page.
- (5) Select areas that have arming, disarming or alarm clearing permission.

General Hint

You can import **Common Voice.** When the alarm is triggered, your customized voice will be added at the beginning of the content of the phone dialed by the system.

iNote

Only WAV format is supported, up to 512 KB and 15 s.

You can enter **Common Message.** When the alarm is triggered, your customized content will be added at the beginning of the message sent by the system.

5. Click Save.



For mobile phone notification:

- You need to press * to finish the call.
- It is required to add control code when entering the mobile phone number.

Cloud Service

If you want to register the device to the mobile client for remote configuration, you should set the mobile client registration parameters.

Before You Start

- Connect the device to the network via wired connection, dial-up connection, or Wi-Fi connection.
- Set the device IP address, subnet mask, gateway and DNS server in the LAN.

Steps

1. Click **Communication** \rightarrow **Cloud Service** to enter the Hik-Connect Registration Settings page.

Cloud Service Setting	<u>js</u>		
Reg	gister to Hik-Connect		
Hik-Cor	nnect Connection Status	Online	
Custom	Server Address		
Server /	Address		88. 199
Commu	inication Mode	Wired Network & Wi-Fi Priority -	
Verifical	tion Code	•••••	
		The code should contain 6 to 12 characters	
		(it is recommended to be more than 8	
		characters and the combination of numeric	
		and letter) .	
Periodic	c Test		
Periodic	c Test Interval	60	s
		Savo	
		Jave	

2. Check Register to Hik-Connect.

iNote

By default, the device Hik-Connect service is enabled.

You can view the device status in the Hik-Connect server (www.hik-connect.com).

3. Enable Custom Server Address.

The server address is already displayed in the Server Address text box.



4. Select a communication mode from the drop-down list according to the actual device communication method.

Wired Network & Wi-Fi Priority

The connection priority order from high to low is: wired network, Wi-Fi, cellular data network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

5. Optional: Change the verification code.

iNote

- By default, the verification code is displayed in the text box.
- The verification code should contain 6 to 12 letters or digits. For security reasons, an 8character password is suggested, which containing two or more of the following character types: uppercases, lowercases, and digits.
- 6. Enable Periodic Test. Enter the periodic test interval.
- 7. Click Save.

Notification by Email

You can send the alarm video or event to the configured email.

Steps

- 1. Click **Communication** \rightarrow **Notification by Email** to enter the page.
- 2. Select **Email 1** or **Email 2**. (Email 2 is a backup for Email 1.)
- 3. Enable Video Verification Events and Server Authentication.
- 4. Enter the sender's information.

iNote

It is recommended to use Gmail and Hotmail for sending mails.

Only if the zone is linked with a network camera, the alarm email will be attached with alarm video.

- 5. Enter the receiver's information.
- 6. Click Receiver Address Test and make sure the address is correct.
- 7. Click Save.



NAT

Universal Plug and Play (UPnP[™]) is a networking architecture that provides compatibility among networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps

1. Click **Communication** \rightarrow **NAT** to enter the page.

NAT Settings						
	Enable UPnP					
	Mapping Type	Auto		-		
Port Type						
	HTTP Port	80				
	Service Port	8000				
Status						
		Port Type	External Port	External IP Ad	Internal Port	UPnP Status
		HTTP Port	80	0.0.0.0	80	Inoperative
		Service Port	8000	0.0.0.0	8000	Inoperative

- 2. Drag the slider to enable UPnP.
- 3. Optional: Select the mapping type as Manual and set the HTTP port and the service port.
- 4. Click Save to complete the settings

FTP

You can configure the FTP server to save alarm video.

Steps

- 1. Click **Communication** \rightarrow **FTP** to enter the page.
- 2. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.



FTP Server and Port No.

The FTP server address and corresponding port.

User Name and Password

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can check Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server.

Intercom Service

You can configure the Intercom service for an intercom sounder.

Before You Start

You should enroll an intercom sounder first. Only one sounder can be set as the intercom sounder.

Steps

- 1. Click **Communication** \rightarrow **Intercom Service** to enter the page.
- 2. Slide to enable the function.
- 3. Set intercom type.

SIP

The control panel will use ARC and SIP server.

IP Receiver Pro

The control panel will user cloud service.

4. Select a sounder and click Save.

5.3.2 Device Management

You can manage the enrolled peripherals including detector, sounder, keypad, etc. in this section.

Zone

You can set the zone parameters on the zone page.

Steps

1. Click **Device** \rightarrow **Zone** to enter the Zone page.

Zone	Device Number	Name	Main Device	Channel No	Device Types	Silent Alarm	Chime	Linked Camera	Operation
1	3	Wireless Zone 1	1	1	Instant	Disable	Disable	1	区综前
2	4	Wireless Zone 2	1	/	Instant	Disable	Disable	1	区 ۞ 前

2. Select a zone and click 🗹 to enter the Zone Settings page.



	Zone Settings		
	Linked Area	Active Functions	
		Area 1	
	Detector Type	Wireless PIR Curtain Detector +	
	Zone Type	Instant -	
	Stay Arm Bypass		
	Forbid Bypass on Arming		
	Chime		
	Silent Alarm		
	Sounder Delay Time	0 * s	
	Double Knock		
	Cross Zone	None -	
	Link Pircam	Not Link -	
. Edit the zone name.			

4. Check linked areas.

iNote

- Only enabled areas will be listed.
- The newly added peripheral is linked to area 1 by default.

5. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

Exit Delay: Exit Delay provides you time to leave through the defense area without alarm. Entry Delay: Entry Delay provides you time to enter the defense area to disarm the system without alarm.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keyboard for users.

iNote

- You can set 2 different time durations in **System Options** \rightarrow **Schedule & Timer**.
- Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
- You can set Stay Arm Delay Time for the delay zone.



Panic Zone

The zone activates all the time. It is usually used in the sites equipped with panic button, smoke detector and glass-break detector.

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

Keyswitch Zone

The linked area will arm after being triggered, and disarm after being restored. In the case of the tampering alarm, the arming and disarming operation will not be triggered.

iNote

Two trigger types (by trigger times and by zone status) can be selected for the zone. If the zone status type is selected, set the trigger operation (trigger arming/disarming).

Disabled Zone

Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-hour Zone

The zone activates all the time with sound/siren output when alarm occurs. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired. (1 to 599) Seconds. It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

6. Enable Cross zone, Silent Alarm, etc. according to your actual needs.

iNote

Some zones do not support the function. Refer to the actual zone to set the function.

Arm Mode

If the zone is a public zone (the zone is belongs to more than one areas), you can set arm mode.

And: When all linked areas are armed, the zone will arm. When any of linked areas is disarmed, the zone will disarm.

Or: When any of the linked areas is armed, the zone will arm. When all linked areas are disarmed, the zone will disarm. When the zone is in alarm, the disarmed areas linked with the zone cannot be armed.

Stay Arm Bypass



The zone will be automatically bypassed in stay arming.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.

If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.

Forbid Bypass on Arming

After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or continuously in a period of time, the alarm will be triggered.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

7. If required, link a PIRCAM or a camera for the zone.

8. Click **OK**.

iNote

After adding the transmitter, you can click **Device** \rightarrow **Zone** \rightarrow **Enroll** to add a wired zone. Select the **Relate Mode** as Wired, the **Device Source** as Single or Multi Transmitter, the Channel and click **OK**.

After setting the zone, you can enter **Maintenance** \rightarrow **Device Status** \rightarrow **Zone Status** to view the zone status.

9. **Optional**: Click **Device** \rightarrow **Zone** and click Detector Settings. You can set detector parameters.



Detector Settings			×
LED			
Swinger Limit Activations	3	Ŧ	
Polling Rate	5min	•	
		ОК	Cancel

Sounder

The sounder is enrolled to the AX PRO via the wireless receiver module, and the 868 Mhz wireless sounder can be enrolled to the hybrid AX PRO via the wireless receiver that is at the address of 9.

Steps

- 1. Click **Device** \rightarrow **Sounder** to enter the Sounder page.
- 2. Click 😳 to enter the Sounder Settings page.

Sounder Settings	Х
Alarm Volume	2 •
Alarm Duration	90 s
Alarm Strobe Flash	
Alarm Buzzer	
Lid Open When Disarmed	
Arm/Disarm Indicator	
Arm/Disarm Buzzer	
Chime Indication	
Buzzer Indicate on Delay Zone	
Intercom Service	
Intercom Duration	10 min -
Polling Rate	5 min 👻
	OK Cancel ~

3. Set the alarm name, the volume and the duration.



The available alarm volume range is from 0 to 3 (function varies according to the model of device).

The available alarm duration range is from 10 to 900 s.

4. Select the linked area.

iNote

- Only enabled areas will be listed.
- The newly added peripheral is linked to area 1 by default.

5. Select to enable Alarm Strobe Flash, Alarm Buzzer, Lid Open When Disarmed, Arm/Disarm LED Indicator, and Arm/Disarm Buzzer.

Alarm Strobe Flash

Enable alarm strobe light.

Alarm Buzzer

Enable alarm buzzer.

Lid Open When Disarmed

When the linked area is disarmed, there is a lid opened alarm triggered by a peripheral, and the sounder will also be triggered.

Arm/Disarm Indicator

Enable arm/disarm LED indicator.

Arm/Disarm Buzzer

Enable arm/disarm buzzer.

Chime Indicator

Enable chime.

Buzzer Indicator on Delay Zone

When the area entry delay or exit delay, in addition to the control panel, the sounder will also give an alarm.

Intercom Service

Enable intercom service. Only one sounder can enable this function.

- 6. Set the Polling Rate.
- 7. If required, enable Enroll Wireless Sounder.
- 8. Click **OK**.



After the sounder is configured, you can click **Maintenance** \rightarrow **Device Status** \rightarrow **Sounder Status** to view the sounder status.

Keypad

You can set the parameters of the keypad that is enrolled to the AX PRO.

Steps

- 1. Click **Device** \rightarrow **Keypad** to enter the page.
- 2. Click 💮 to enter the Keypad Settings page.

Configuration		×
Function Buttons		^
Linked Area	Active Functions	
	Area 1	
	Area 2	
Arming Without Password		
Buzzer		
Active on Entry Delay		
Backlight Off Time	00:00 📸 to 00:00	🔁 🛛 Backlight
Silent Panic Alarm		
Silent Medical Alarm		
Polling Rate	5min -	
Enroll Wireless Keypad		
		Cancel

- 3. Set the keypad name.
- 4. Enable the function of buzzer, silent panic alarm, silent medical alarm, and keypad button.
- 5. Enable the function of arming without password and active on entry delay.
- 6. Check the **Enable** check box of Back-light Off Time, and set the duration of light off.
- 7. Set the polling rate.
- 8. Select the keypad linked area.

iNote

- Only enabled areas will be listed.
- The newly added peripheral is linked to area 1 by default.
- 9. Set whether to cancel the enrollment of the keypad or not. If the link is enabled, the device will be deleted.

10. Click **OK**.



- After the keypad is configured, you can click Maintenance → Device Status → Keypad Status to view the keypad status.
- You can set the keypad password on the page of User \rightarrow User Management \rightarrow Operation.

Tag Reader

You can set the parameters of the tag reader.

Steps

- 1. Click **Device** \rightarrow **Automation** to enter the page.
- 2. Click Enroll, enter the serial No. to add a tag reader.
- 3. Click 😳 to edit the tag reader parameters.

Name	Tag Reader 1	
Serial No.	Q03045297	
Tag Reader	1	
Linked Area	 Active Functions 	
	Area 1	
Operation Mode	Standard Mode 🛈	
	Simple Mode	
Buzzer		
Polling Rate	5min -	
Link to Wireless Tag Reader		
	ОК	Cancel

- 4. Edit device name.
- 5. Check linked areas.
- 6. Select operation mode.

Standard Mode

Area selection and fault confirmation are supported when swiping tag to arm or disarm.

Simple Mode

No Area selection and fault confirmation when swiping tag to arm or disarm.

- 7. Choose whether to enable the **Buzzer**. After disable the buzzer, there will be no beep when swiping the tag.
- 8. Set Polling Rate.



9. Optional: Enable Link to Wireless Tag Reader.

10. Click **OK**.

Automation

You can set the parameters of the relay outputs that is enrolled to the AX PRO.

Steps

- 1. Click **Device** \rightarrow **Automation** to enter the page.
- 2. Click Enroll, enter the serial No. and select the device type to add a relay output device.
- 3. Click 💮 to edit the relay information.

Automation			×
	Area1		^
Access Module Type	Multi Transmitter	•	
Channel No	1		
Original Status Scenario Setting	Normally Closed	Parameter Setting	d
	 Alarm Schedule Arm Disarm Silence Alarm Fault Manual 	Activation Mode Pulse • Pulse Duration • 5 s Range 5-600 s	
Linked		OK Cancel	

- Set the name of the relay output device.
- Select the linked area for output.

iNote

- Only enabled areas will be listed.
- The newly added peripheral is linked to area 1 by default.
- The function varies according to different relay types
- Set the original status as Normally Closed or Normally Open.
- Set the event for being triggered.
- Set the activation after being triggered.
- Set whether to link to the relay output device or not. If the link is enabled, the device will be deleted.



Repeater

The repeater can amplify signals between the control panel and the peripherals.

Steps

- 1. Click **Device** \rightarrow **Repeater** to enter the page.
- 2. Click **Enroll**, enter the serial No. and select the device type to add a repeater.
- 3. Click **Enter Paring Mode** to make the repeater enter the mode of device paring.
- 4. When the distance between the peripheral and the control panel is far, the repeater can be used as a transfer station for pairing. The pairing mode lasts for 3 minutes and cannot be interrupted. After the pairing is successful, a list of connected devices will be displayed.



5. Click 💮 to edit the repeater information.

Enable	Pairing Mode + Er	iroll		
Repeater	Serial No.	Name	Enroll Wireless Repeater	Connected Device List Settings
1	Q02858402	Repeater 1	Repeater Settings	×
			Name	Repeater 1
			Serial No.	Q02858402
			Repeater	1
			Polling Rate	5min -
			Enroll Wireless Repeater	
				OK Cancel

- Set the name of the repeater.
- Set the polling rate of the repeater.
- Set whether to cancel the enrollment of the repeater or not. If the link is enabled, the device will be deleted.
- 6. Click 🚳 to enter the Manual Retransmission Rules page.



Manual Potransmission Pules			~
			×
Device Type	All Devices		•
Retransmit Device	 Active Functions 		
		ОК	Cancel

- Select the **Device Type**.
- Check Active Functions.
- Click **OK**, then the devices can be manually retransmitted.

Transmitter

You can set the parameters of the transmitter.

- 1. Click **Device** \rightarrow **Transmitter** to enter the page.
- 2. Click Enroll, enter the Serial No. and select the device model to add a transmitter.
- 3. Click 💮 to edit the transmitter information.

Parameter Setting		×
Transmitter	1	
Name	Multi Transmitter 1	
Serial No.	Q86860014	
Polling Rate	5min -	
Linked Area	Active Functions	
	Area 1	
	Area 2	
Enroll Wireless Transmi		
	ОК	Cancel

- 4. Set the name of the transmitter.
- 5. Set the polling rate of the transmitter.
- 6. Enable Enroll Wireless Transmission.
- 7. Click **OK**.



Network Camera

You can add network cameras in the system.

Steps

- 1. Click **Device** \rightarrow **Camera** to enter the page.
- 2. Click Enroll, enter the IP address, user name and password to add a camera.

Video Verification Network Camera I Video Verification	Verification Network Camera P Network C	Camera Connection Stat	
	Add Network Camera		×
	Device Enroll Mode	IP +	
	IP Address		
	Protocol Type	HIKVISION -	
	Port No.	8000	•
	User Name		8
	Password]
		ОК	Cancel

You can also click	🖉 Edit	to edit the camera,	or click	前 Delete	to delete the camera.
--------------------	--------	---------------------	----------	----------	-----------------------

5.3.3 Area Settings

Basic Settings

You can link zones to the selected area.

- 1. Click **Area** \rightarrow **Basic Settings** to enter the page.
- 2. Select an area.
- 3. Check Enable.
- 4. Click Edit Linked Zone and Edit Linked Peripheral to check linked zones or peripherals.
- 5. Click **Save** to complete the settings.



5.3.4 Video Management

You can add two network cameras to the AX PRO, and link the camera with the selected zone for video monitoring. You can also receive and view the event video via client and Email.

Add Cameras to the AX PRO

Steps

1. Click **Device** \rightarrow **Network Camera** to enter the network camera management page.

+ Enroll ta s	ADP Scanning	🖉 Edit 💼				
Video Verificati	Device Number	Network Came	Camera Chann	Network Came	Network Ca	amera Connection
	Add Network Ca	mera				×
	Device Enro	II Mode	IP		-	
	IP Address					
	Protocol Typ	pe	HIKVISION		-	
	Port No.		8000			
	User Name					
	Password					
				O	к	Cancel

- 2. Click **Enroll**, and enter the basic information of the camera, such as IP address and port No., and select the protocol type.
- 3. Enter the user name and password of the camera.

SADP Scanning

Scan all network cameras in the same LAN. A list will pop up after scanning. You can directly check to add cameras in the list.

- 4. Click **OK**.
- 5. Optional: Click Edit or Delete to edit or delete the selected camera.

Link a Camera with the Zone

- 1. Click **Device** \rightarrow **Zone** to enter the configuration page.
- 2. Select a zone that you wish to include video monitoring, and click 🐵.
- 3. Select the Link Camera.
- 4. Click **OK**.



Only if the zone is linked with a network camera, the alarm email will be attached with alarm video.

Set Video Parameters

Steps

1. Click **Device** \rightarrow **Network Camera** \rightarrow **Video Parameters** to enter the page.

Network Camera Management	Video Parameters			
Link Camera			-]
Stream Type			-]
Bitrate Type			÷]
Resolution			*	
Video Bitrate				Kbps
Length of Cached	Vide		Ŧ	s
Length of Cached	Vide		Ŧ	s
		Save		

2. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality.

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output.

Video Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.



5.3.5 Permission Management

Add/Edit/Delete Keyfob

You can add keyfob to the AX PRO and you can control the AX PRO via the keyfob. You can also edit the keyfob information or delete the keyfob from the AX PRO.

Steps

- 1. Click **Device** \rightarrow **Keyfob** to enter the Keyfob Management page.
- 2. Click **Enroll** and press any key on the keyfob.
- 3. Set the keyfob parameters.

Name

Customize a name for the keyfob.

Permission Settings

Check different items to assign permissions.

Single Key Settings

Select from the drop-down list to set I key and II key's functions

Combination Keys Settings

Select from the drop-down list to set combination keys' functions.

- 4. Click **OK**.
- 5. Optional: Click \square to edit the keyfob information.
- 6. Optional: Delete a single keyfob or check multiple keyfobs and click **Delete** to delete the keyfobs in batch.

Note

The communication of wireless devices like keyfob was identified by the SN number, which will be encrypted during transmission. The SN number was leading with character Q to Z, and following 8 digits, like Q02235774. Allowing for a maximum number of 100,000,000 (10 to the power of 8 [digits]).

Add/Edit/Delete Tag

You can add tag to the AX PRO and you can use the Tag to arm/disarm the zone. You can also edit the tag information or delete the tag from the AX PRO.

iNote

The communication of tag was identified by the SN number, which will be encrypted during transmission. The SN number was leading with 32 digits, and there are at most 4,294,967,296 SN numbers can be identified.



Steps

- 1. Click **Device** \rightarrow **Tag** to enter the management page.
- 2. Click Enroll and place a Tag on the Tag area of the AX PRO.
- 3. Customize a name for the Tag in the pop-up window.
- 4. Select the Tag type and Tag linked area.
- 5. Select the permission for the Tag.

iNote

You should allocate at least a permission for the Tag.

6. Click **OK** and the tag information will be displayed in the list.

iNote

The Tag supports at least 20-thousand serial numbers.

7. Optional: Click \square and you can change the Tag name.

8. Optional: Delete a single Tag or check multiple Tags and click **Delete** to delete Tags in batch.

5.3.6 Maintenance

Device Information

You can view device name and other information.

Click **Maintenance** \rightarrow **Device Information** to enter the page.

You can view device model, device serial No., device firmware version, web version or click **About** \rightarrow **View Licenses** to view the source software licenses.

You can go to **System** \rightarrow **System settings** to change the device name.

Local Log Search

You can search the log on the device.

Click **Maintenance** \rightarrow **Log** to enter the Local Log Search page.



Log									
Primary I	Event	All Type		Secondar	/ Event	All Type		Filte	f
Start Tirr	ne	2021-05-	31 00:00:00	End Time		2021-05-31 2	3:59:59 🖺	Expo	rt Reset
No.	Date a	nd Time	Primary Ev	Secondary Event	User	Remote Ho	Managed	Param	Additional Inf
						То	tal 0 Items	<< < (/0 > >>

Select a primary event and a secondary event from the drop-down list, set the log start time and end time and click **Filter**. All filtered log information will be displayed in the list. You can also click **Reset** to reset all search conditions.

Test

The AX PRO supports walk test function.

Steps

1. Enter **Maintenance** \rightarrow **Device Maintenance** \rightarrow **Test** to enable the function.

Test			
Test Mode	Zone No.	Name	Test Result
	1	Wireless Zone 1	Invalid zone.
	2	Wireless Zone 2	Invalid zone.
	Save	Refresh	


iNote

Only when all the detectors are without fault, you can enter the mode TEST mode.

- 2. Enable Test to start walk test.
- 3. Click Save to complete the settings.
- 4. Trigger the detector in each zone.
- 5. Check the test result.

System Maintenance

You can reboot the device, restore default settings, import/export configuration file, or upgrade the device remotely.

Select the device and click 3 in the client software, or enter the device IP address in the address bar of the web browser. Click **Maintenance** \rightarrow **Device Maintenance** \rightarrow **Maintenance** to enter the Upgrade and Maintenance page.

stem Management	
Reboot	Reboot
Restore Default Settings	Partly Restore
	Restore All
Import Configuration File	View
	Import
Export Configuration File	Export
Tamper Alarm on HPC Login	If enabled, when logging in to HPC, the
	system will give an alarm when the device
	tamper is triggered.

Reboot

Click **Reboot** to reboot the device.

Restore Default Settings

Click **Partly Restore** to restore all parameters except for device time zone information, user parameters, wired network, Wi-Fi network, HC information detector information, detector information enrolled in the zone and enrolled wireless peripheral information to default ones. Click **Restore All** to restore all parameters to the factory settings.

Import Configuration File

Click **View** to select configuration file from the PC and click **Import Configuration File** to import configuration parameters to the device. Importing configuration file requires entering the password set at the time of exporting.

Export Configuration File

Click **Export Configuration File** to export the device configuration parameters to the PC.



Exporting configuration file requires a password to be used for file encryption.

Tamper Alarm on HPC Login

After this function is enabled, the device lid opened alarm (tamper alarm) takes effect when installer login. (By default, the lid opened alarm (tamper alarm) does not take effect when the installer login.)

Export File

You can export debugging file to the PC.

Steps

```
1. Click Maintenance \rightarrow Device Maintenance \rightarrow Export File to enter the page.
```

Debugging Log		
File Format	Debugging Log	-
	Export	
	Save	

- 2. Slide to enable the function.
- 3. Click **Export** to save the debugging file in the PC.

Security Audit Log

You can add the Security Audit Server to the system. The device will upload web logs to the server.

Steps

2. Click System Maintenance → Device Maintenance → Security Audit Log to enter the page.

Advanced Settings		
Enable Log Upload Server		
Server Settings		
Log Server IP	0.0.0.0	
Log Server Port	0	
CA Certificate		
Install		View
	Install	
	Save	

- 3. Check Enable Log Upload Server.
- 4. Enter log server IP and port.
- 5. Click View to select a certificate.



iNote

Formats include ca.crt、 ca-chan.crt、 private.txt are allowed.

- 6. Click Install.
- 7. Click Save.

5.3.7 System Settings

Time Settings

You can set the device time zone, synchronize device time, and set the DST time. The device supports time synchronization via **Hik-Connect Guarding Vision** server.

Time Management

Click System \rightarrow System Settings \rightarrow Time Management to enter the Time Management page.

System Settings	DST Management
Time Zone	(GMT+00:00) Dublin, Edinburgh, London
Time Synchronization	
Synchronization Mode	O NTP Time Sync. Manual Time Sync
Date and Time	2021-05-31 08:29:56
PC Sync	2021-05-31 08:29:31 🔀 🗌 Sync. With Computer Time
	Save

You can select a time zone from the drop-down list.

You can synchronize the device time manually with NTP. Check the check box of **NTP Time Sync.**, enter the server address and port No., and set the synchronization interval.

You can synchronize the device time manually. Or check **Sync. with Computer Time** to synchronize the device time with the computer time.

iNote

While you synchronize the time manually or with the computer time, the system records the log "SDK Synchronization".

DST Management

Click System \rightarrow System Settings \rightarrow DST Management to enter the Time Management page.



System Settings	Time Management	DST Manage	ement								
Ena	able DST										
DS	T Bias		60 Minute(s	;)			-				
Sta	rt Time		April	•	First	-	Sunday	•	02	•	
End	d Time		October	-	Last	•	Sunday	•	02	*	
			Save								

You can enable the DST and set the DST bias, DST start time, and DST end time.

Authority Management

Set the authority options.

Click System \rightarrow System Options \rightarrow System Management to enter the page.

ystem Manage	ement Schedu	ule & Timer	System Fault Check	c Arm Options	Device Enr	roll Mode
F	Forced Auto Arm					
F	Forced Arming		(
s	System Status Rep	port	•			
V	/oice Prompt		•			
				Fault Prompts On	Arming 1	The system will not be compliant with the
					E	Europe EN50131-1 standard after you
					c	disable this configuration option.
				Fault Prompts Wr	ien Armed	
				Fault Prompts On	Disarming	The system will not be compliant with the
						Europe EN50131-1 standard after you
						disable this configuration option.
				Fault Prompts Wr	ien Disarme	d
				Voice Prompts Or	n Alarm	
s	System Volume			0		1 Range 0-10
A	Audible Tamper Al	larm	•			
F	Panel Lockup Butt	on	(
E	Bypass On Re-Am	n	(
F	Polling Loss Times	5		0		4 Range 3-10
F	Fault LED Stay On	When Armed	(
E	Ezviz Indicator		•			
Α	Arm LED Stay On		(
N	Notion Detector R	estore		Disable		-
J	lamming Sensitivit	ty Settings		High		-
E	Energy Save Mode	2	(
s	Smoke Detector R	eset		Reset		
E	Enable PD6662		(

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are an active faults in a zone,



the zone will be automatically bypass.

iNote

You should disable the arming function in the Advanced Settings page. Or the AX PRO arming with fault function cannot be valid.

Forced Arming

After enabled, when manual arming starts, if there are an active faults in a zone, the zone will be automatically bypass.

System Status report

If the option is enabled, the device will upload report automatically when the AX PRO status is changed.

Voice Prompt

If the option is enabled, the AX PRO will enable the text voice prompt.

System Volume

The available system volume range is from 0 to 10.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm.

Panel Lockup Button

Enable/disable the lockup button for the control panel.

Bypass on Re-Arm

While enabled, the zone with fault will be bypassed automatically when re-arming.

Polling Loss Times

Set the maximum duration for polling loss. The system will report fault if the duration is over the limit.

Fault LED Stay On When Armed

When system is armed, the fault indicator is always on.

Ezviz Indicator

Enable the Ezviz indicator.

Arm LED Stay On

The arm LED is always on.

Motion Detector Restore

Motion detectors include all PIR detectors.

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.



Energy Save Mode

While enabled, the main power supply is off, Wi-Fi enters low power consumption, 4G closes, tag reading fails, LED off, and voice prompt off.

Enable PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Schedule and Timer Settings

You can set the alarm schedule. The zone will be armed/disarmed according to the configured time schedule.

Steps

```
1. Click System \rightarrow System Options \rightarrow Schedule & Timer to enter the Schedule & Timer page.
```

System Management	Schedule & Timer	System Fault Check	Arm Options	Device Enroll Mode
Area		Area1		-
Enal	ble auto Arm			
		Time	00:00	1
Enal	ble auto Disarm			
		Time	00:00	
Late	to Disarm			
		Time	00:00	2
Wee	ekend Exception			
Holid	day Exception			
Auto Arr	m Sound Prompt			
Panel A	larm Duration	90		s
		Sa	ve	

- 2. Select an area.
- 3. Set the following parameters according to actual needs.

Enable Auto Arm

Enable the function and set the arming start time. The zone will be armed according to the configured time.

iNote

- The auto arming time and the auto disarming time cannot be the same.
- The buzzer beeps slowly 2 minutes before the auto arming starts, and beeps rapidly 1 minute before the auto arming starts.
- You can select to enable forced arming on the System Options page. While the function is



enabled, the system will be armed regardless of the fault.

Enable Auto Disarm

Enable the function and set the disarming start time. The zone will be disarmed according to the configured time.

iNote

• The auto arming time and the auto disarming time cannot be the same.

Late to Disarm

Enable the function and set the time. If the alarm is triggered after the configured time, the person will be considered as late.

iNote

You should enable the Panel Management Notification function in **Communication Parameters** \rightarrow **Event Communication** before enabling the Late to Disarm function.

Weekend Exception

Enable the function and the zone will not be armed in the weekend.

Holiday Exception

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling.

iNote

Up to 6 holiday groups can be set.

Auto Arm Sound Prompt

After disabled, the buzzer will not beep before auto arming.

Panel Alarm Duration

The time duration of the panel alarm.

iNote

The available time duration range is from 10 s to 900 s.

5. Click Save.

Fault Check

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Click System \rightarrow System Options \rightarrow System Fault Check to enter the page.



Detect Network Camera Disconnection	
Panel Battery Fault Check	
LAN Fault Check	
WiFi Fault Check	
Cellular Fault Check	
Main Power Lost	
Main Power Loss Delay	10 s
	Save

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered.

Panel Battery Fault Check

If the option is enabled, when battery is disconnected or out of charge, the device will upload events.

LAN Fault Check

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

Wi-Fi Fault Check

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Network Fault Check

If the option is enabled, when the cellular data network is disconnected or with other faults, the alarm will be triggered.

Main Power Lost

If the option is enabled, an alarm will be triggered when the main supply is disconnected.

Main Power Loss Delay

The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

Arm Options

Set advanced authority parameters. Click **System** \rightarrow **System Options** \rightarrow **Arm Options** to enter the Advanced Settings page.



Arm With Faults		The system will not be compliant with the Europe EN50131-1 standard after you disable this configuration option.
	Checklist	Arm With Fault
Device Lid Opened	>	
Zone/Peripherals Poll Failure/Offline		
Zone/Peripherals Low Battery		
Zone Triggered		
Detect Network Camera Disconne	V	
Panel Battery Fault Check		
LAN Fault Check	V	
WiFi Fault Check	V	
Cellular Fault Check	V	
Main Power Lost	>	
Early Alarm		
Early Alarm Time	30	s
	Sav	e

You can set the following parameters:

Arm with Fault

Check the faults in the Arm with Fault list, and the device will not stop the arming procedure when faults occurred.

Fault Checklist

The system will check if the device has the faults in the checklist during the arming procedure.

Early Alarm

If you enable the function, when the zone is armed and the zone is triggered, the alarm will be triggered after the set delay time.

iNote

The early alarm will be taken effect only after the delayed zone is triggered.



Device Enroll Mode

Click Enter the Enrollment Mode to make the panel enter the enroll mode.

Wireless Device Enrollment Mode Enter the Enrollment Mode	

Security Settings

SSH Settings

Enable or disable SSH (Secure Shell) according to your actual needs. Click **System** \rightarrow **System** Security \rightarrow SSH Settings to enter the SSH Settings page and you can enable or disable the SSH function.

SSH Settings	Locking User Settings	Module Locking Settings	
E	nable SSH		
		Save	

Locking User Settings

The device will be locked 90 s after 3 failed credential attempts (can be set in Retry Time before Auto-Lock) in a minute.

You can view the locked user or unlock a user and set the user locked duration.

iNote

To compliant the EN requirement, the system will only record the same log 3 times continuously.

Steps

 Click System → System Security → User Lockout Attempts to enter the Locking User Settings page.



Retry Times Before Auto-lock	3 -		
Auto-lock Time	1800	s	
No.	IP Address		Unlock
Save	lock All		

2. Set the following parameters.

Retry Times before Auto-Lock

If the user continuously input the incorrect password for more than the configured times, the account will be locked.

iNote

The administrator has two more attempts than the configured value.

Auto-lock Time

Set the locking duration when the account is locked.

iNote

The available locking duration is 5s to 1800s.

3. Click \square to unlock the account or click **Unlock All** to unlock all locked users in the list.

4. Click Save.

Module Lock Settings

Set the module locking parameters, including the Max Failure Attempts, and locked duration. The module will be locked for the programmed time duration, once the module authentication has failed for the amount of configured times.

Steps

 Click System → System Security → Module Locking Settings to enter the Module Lock Settings page.



No.	Device Type	Retry Times Before	Auto-lock Time	Status	Operation	
1	Keypad	3	90	Unlocked	ŝ	^
2	Keypad	3	90	Unlocked	÷	
3	Keyj Con	figuration				×
4	Key					
5	Key;	Device Type	Keypad		•	
6	Key	No.	1			
7	Key	Datny Timas Bafora Aut	2			
8	Key;	Relly Times Delore Aut	5			
1	Tag Re	Auto-lock Time	90		S	
2	Tag Re			ОК	Cancel	
3	Tag Reauci	5	50	OHIOCKEU	502	
4	Tag Reader	3	90	Unlocked	£33	
5	Tag Reader	3	90	Unlocked	63	~

- 2. Select a module from the list, and click the 🛞 icon.
- 3. Set the following parameters of the selected module.

Retry Times before Auto-Lock

If a user continuously tries to authentication a password for more than the configured attempts permitted, the keypad will be locked for the programmed duration.

Auto-lock Time

Set the locking duration when the keypad is locked. After the configured duration, the keypad will be unlocked.

- 4. Click **OK**.
- 5. Optional: Click the **Lock** icon to unlock the locked module.

Device Upgrade

Get Manufacture PIN

To upgrade the device, a manufacture PIN is needed for authentication. The manufacture PIN can only get from the Hik-ProConnect service, which means that the installer, who authorized by administrator at access level 2, has authorized the access at level 4. The manufacture PIN can only work once.

• Get PIN from Hik-ProConnect Service



English The ProConnect	Your Choice of Efficient Management for Security Business
Welcome Email	
Password Forqot Password Register Login Hik-ProConnect is a platform for	
Installers and you cannot login with the Hik-Connect account.	
	Scan QR code or go to app store to download mobile client.
	© 2020 Hikvision Europe 8.V. All Rights Reserved.

Login with the installer account and enter the page of the device to be upgraded. Click **More Menu** at the lower right side of the page, and apply a PIN.

0 1 Encoding Device	ccess Control Device	0 Video Intercom Device	O Doorbell	
Device Linkage Rule Exception	Permission			
AX PRO	Apply for a PIN PIN is used for u enter the PIN. Device Nam	upgrading AX PRO. The upgrade will : ne AX PRO	start once you	
Device Type: Security Control Panel Permission: Configuration		N 1406	Close	©

• Get PIN from HIKVISION tech-support

It is better to use remote desktop to access the local web client of control panel. The PIN will be authorized according to the standard tech-support procedure.

Firmware Upgrade

Steps:

- 1. Click **Maintenance** \rightarrow **Device Information** to enter the page.
- 2. Click Remote Upgrade.



HIKVISION		🛓 🕞 Exit
	Device Information About	
R User	Device Name	AX PRO
🗂 System	Device Model:	DS-PWA96-M-WE
Device	Device Serial No	
BB Area	Device Sena No.	D31 WA3018-WE20200413AAWIX001877100W0
🖗 Communication	Device Firmware Version:	V1.0.0 build 200407
🛱 Maintenance	Web Version:	V4.25.1 build 200407
Device Information		Remote Upgrade
Device Status		
Log		
Device Maintenance		

- 3. Choose the hub or the peripheral for upgrade, and select the **Upgrade Type**.
- 4. Click **View** to find the firmware file with the name digicap.dav.
- 5. Click **Upgrade** to complete.

Remote Upgrade		
Synchronization Mode	Hub O Peripheral	
Upgrade Type	AX PRO -	
Upgrade File	View	

Both of the users and configuration information will be retained after upgrade finished.

5.3.8 Check Status

After setting the zone, repeater, and other parameters, you can view their status. Click **Maintenance** \rightarrow **Device Status**. You can view the status of AX PRO control panel, zone, sounder, automation, repeater, keypad, Tag reader, keyfob and transmitter.



AX PRO Status	Zone Status	Sounder Status	Automation	Repeater Status	Tag Reader Status	Keypad Status	Transmitter
Battery	Status						
Bat	ttery Charge			0%]	
Commu	nication Status						
Wi	red Network			Normal]	
Wi-	-Fi			Network Disconne	ected]	
Wi-	-Fi Signal Streng	th		None]	
(GF	PRS/3G/4G)Netw	vork		Network Disconne	ected]	
Cel	Ilular Data Netwo	ork Signal Strength		None]	
Us	ed Data					м	
Clo	oud Connection S	Status		Network Disconne	ected]	
				Refresh			

5.4 Report to ARC (Alarm Receiver Center)

AX PRO wireless control panel is designed with transceiver built in following the guidance of EN 50131-10 and EN 50136-2. Category DP2 is provided with primary network interface of LAN/WiFi and secondary network interface of GPRS or 3G/4G LTE. ATS (Alarm Transmission system) is designed to always use LAN/Wi-Fi network interface when available to save mobile data usage. The secondary network interface provides resilience and reliability during mains power failure.

Setup ATS in Transceiver of Receiving Center

Steps:

- 1. Login to the web client of the alarm receiver.
- 2. Click **Configuration** \rightarrow **IP Reception**, and create a receiving server as shown below.

🛿 Traffic 🛛 🛷 Status and Log	Server Details	× ≗ Administrator DT42 ◄
	SIADC09 7	Create
Server 1	Port	
Server 2	6666	
Server 3	Protocol	
Server 4		
Server 5	Allow All panels to connect Yes	
<u>Server 6</u>	Encryption Key Size	
Server 7	128	
<u>+</u>	Encryption Key 12345678901234567890123456789012	→
	Close	

3. Click Alarms and Accounts -> Accounts Management, and assign an account for the panel as



show below.

🛿 Traffic 🛛 😙 Status and Log	gs 👻 🚺 💿 Alarms and Accounts 👻	🕸 Configuration 👻	음 Administrator DT42 👻
\	Create Account		×
Order by Account Number	General Information	Account Phones	
Filter by : Account Number	# Account Number	Phone Number 1	2 Create
123 fff	3 Name	Phone Number 2	
1004 xxsc	test	Phone Number 2	
1020 zxt_test	Address	Contact	
1021 gjt_test	Address	Responsible Name	
1070	Address	Responsible Name	
	City	Responsible Phone	
1105 test1	City	Responsible Phone	
1106 Wmr	Province	Responsible Email	HINA HZ CHINA
1111 еп_уух	Province Country	Responsible Email	HINA HZ CHINA
1224 zjf7	Country		

Setup ATS in Transceiver of the Panel Steps:

A

- 1. Login using installer account from local web client.
- 2. Click **Communication**→ **Alarm Receiving Center (ARC)**, and enable **Alarm Receiving Center 1**.

arm Receiver Center1		
Enable		
Protocol Type	*ADM-CID -	
Address Type	IP -	
Server Address	115.236.50.3	
Port No.	6666	
Account Code	2297	
Transmission Mode	TCP -	
Impulse Counting Time	20	s
Attempts	3	⊘
Polling Rate	60	📀 s 🗹 Enable
Encryption Arithmetic	AES -	
Password Length	128 -	
Secret Key	123456789012345678901234567 💿	

• = Protocol Setting =

Protocol	Туре
	- ADM-CID
	- SIA-DCS
	— *ADM-CID
	— *SIA-DCS
	Select token supported by the receiver in the ARC. Choose the token with "*" mark to



improve the communication security.

• = Server Setting =

Address Type

- IP
 - Domain Name

Server Address / Domain Name

Port No.

Input IP address or domain name by which the transceiver of receiving center could be reached. Input port number of the server provided by the ARC

• = Account Setting =

Account Code

Input the assigned account provided by the ARC.

• = SIA DC-09 Protocol Setting =

	Tra —	nsmission Mode TCP
		UDP
	Bot star	h TCP and UDP are supported for transmission. UDP is recommended by the SIA DC-09 ndard.
	Со	nnection Setting
	0	Impulse Counting Time / Retry Timeout Period
		Setup the timeout period waiting for receiver to respond. Re-transmission will be arranged if the transceiver of receiving center is timeout.
	0	Attempts
		Setup the maximum number that re-transmission will be tried.
	0	Polling Rate
		Setup the interval between 2 live polling if enable is checked.
•	Er	ncryption Setting
	0	Encryption Arithmetic
		— AES
	0	Password Length
		— 128
		— 192
		— 256
	0	Secret Key
		Setup the encryption key length and input the key provided by the ARC.

Signaling Test



Activate a panic alarm from the control panel.

Login to Receiver. Click Traffic to review all the messages received.





Chapter 6 General Operations

6.1 Arming

You can use keypad, keyfob, Tag, client software, mobile client to arm your system. After the arming command is sending to AX PRO, the system will check the detector status. If the detector is in fault, you will need to choose whether to arm the system with fault. While the system is armed, the AX PRO will prompt the result in 5s, and upload the arming report.



Access level of Arming

The user in level 2 or 3 has the permission to arm or partly arm the system.

Arming Indication

The arming/disarming indicator keeps solid blue for 5s.

Reason of Arming Failure

- Intrusion detector triggered (excepts the detector on the exit route).
- Panic alarm device triggered.
- Tampering alarm occurred.
- Communication exception
- Main power supply exception



- Backup battery exception
- Alarm receiving fault
- Sounder fault
- Low battery of the keyfob
- Others

Arming with Fault

While the arming is stopped with fault, user in level 2 has the permission to arm the system with fault (forced arming).

Forced arming only takes effect on the current arming operation.

The forced arming operation will be record in the event log.

6.2 Disarming

You can disarm the system with keypad, keyfob, Tag, client software, or mobile client.

Disarming Indication

The arming/disarming indicator flashes 30s while the user successfully disarm the system through the entry/exit route.

The system will report the disarming result after the operation completed.

Entry Delay Duration

Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.

Early Alarm

If either the intrusion or tampering alarm occurs on the enter/exit route when the AX PRO is in the status of entry delay, the AX PRO then enters the early alarm mode.

The early alarm duration can be set (> 30s).

The AX PRO will reports the alarm only if the alarm event lasts over the duration of early alarm with the addition of entry delay.

6.3 SMS Control

You can control the security system with SMS, and the command is shown below. SMS format for Arming/disarming/silencing alarm:

{Command} + {Operation Type} + {Target}

Command: 2 digits, 00- Disarming, 01- Away arming, 02- Stay arming, 03- Silencing alarm Operation type: 1- Area Operation

Target: No more than 3 digits, 0-Operation for all areas, 1-Operation for area 1(zone1), and the rest can be deduced by the analogy.



A. Trouble Shooting

A.1 Communication Fault

A.1.1 IP Conflict

Fault Description:

IP that the panel automatically acquired or set is same as other devices, resulting in IP conflicts. Solution:

Search the current available IP through ping. Change the IP address and log in again.

A.1.2 Web Page is Not Accessible

Fault Description:

Use browser to access web pages and display Inaccessible. Solutions:

- 1. Check whether the network cable is loose and the panel network is abnormal.
- 2. The panel port has been modified. Please add a port to the web address for further access.

A.1.3 Hik-Connect is Offline

Fault Description: The web page shows that the Hik-Connect is offline. Solution: Network configuration of the panel is error, unable to access extranet.

A.1.4 Network Camera Drops off Frequently

Fault Description: System reports multiple event logs of IPC disconnection and connection. Solution: Check whether the network communication or camera live view is proper.

A.1.5 Failed to Add Device on APP

Fault Description:

When using APP to add devices, it is prompted that the device fails to be added, the device could not be found, etc.

Solution:



Check the web page: whether the Hik-Connect is offline.

A.1.6 Alarm Information is Not Reported to APP/4200/Alarm Center

Fault Description:

After the alarm is triggered, the app/4200/ alarm center does not receive the alarm message. Solution:

"Message push" - "alarm and tamper-proof notice" is not enabled. You should enable "alarm and tamper-proof notice".

A.2 Mutual Exclusion of Functions

A.2.1 Unable to Enter Registration Mode

Fault Description:

Click the panel function key, and prompt key invalid.

Solution:

The panel is in "Hotspot" mode. Switch the panel to "station" mode, and then try to enter the registration mode again.

A.3 Zone Fault

A.3.1 Zone is Offline

Fault Description: View status of zones which displays offline. Solution: Check whether the detector reports undervoltage. Replace the detector battery

A.3.2 Zone Tamper-proof

Fault Description: View status of zones which displays tamper-proof. Solution: Make tamper-proof button of the detector holden.

A.3.3 Zone Triggered/Fault

Fault Description:



View status of zones which displays triggered/fault. Solution: Reset the detector.

A.4 Problems While Arming

A.4.1 Failure in Arming (When the Arming Process is Not Started)

Fault Description:

When the panel is arming, prompt arming fails.

Solution:

The panel does not enable "forced arming", and when there is a fault in the zone, the arming will fail. Please turn on the "forced arming" enable, or restore the zone to the normal status.

A.5 Operational Failure

A.5.1 Failed to Enter the Test Mode

Fault Description: Failed to enable test mode, prompting "A fault in the zone". Solution: Zone status, alarm status or zone power is abnormal.

A.5.2 The Alarm Clearing Operation on the Panel Does Not Produce the Alarm Clearing Report

Fault Description: The alarm clearing operation on the panel does not produce the alarm clearing report. Solution:

In the absence of alarm, no report will be uploaded for arm clearing.

A.6 Mail Delivery Failure

A.6.1 Failed to Send Test Mail

Fault Description: when configure the mail information, click "test inbox" and prompt test fails.



Solution:

Wrong configuration of mailbox parameters. Please edit the mailbox configuration information, as shown in table 1/1.

A.6.2 Failed to Send Mail during Use

Fault Description:

Check the panel exception log. There is "mail sending failure".

Solution:

The mailbox server has restricted access. Please log in to the mailbox to see if the mailbox is locked.

A.6.3 Failed to Send Mails to Gmail

Fault Description:

The receiver's mailbox is Gmail. Click "Test Inbox" and prompt test fails.

1. Google prevents users from accessing Gmail using apps/devices that do not meet their security standards.

Solution:

Log in to the website (https://www.google.com/settings/security/lesssecureapps), and "start using access of application not safe enough". The device can send mails normally.

2. Gmail does not remove CAPTCHA authentication.

Solution: Click the link below, and then click "continue"

(https://accounts.google.com/b/0/displayunlockcaptcha).

A.6.4 Failed to Send Mails to QQ or Foxmail

Fault Description:

The receiver's mailbox is QQ or foxmail. Click "Test Inbox" and prompt test fails.

1. Wrong QQ account or password.

Solution:

the password required for QQ account login is not the password used for normal login. The specific path is: Enter the email account \rightarrow device \rightarrow account \rightarrow to generate the authorization code, and use the authorization code as the login password.

2. SMTP login permission is needed to open.

A.6.5 Failed to Send Mails to Yahoo

Fault Description:

The receiver's mailbox is yahoo. Click "test inbox" and prompt test fails.

1. The security level of mailbox is too high.

Solution:

Go to your mail account and turn on "less secure sign-in".



A.6.6 Mail Configuration

Table A-1 Mail Configuration

Mail Type	Mail Server	SMTP Port	Protocols Supported
Gmail	smtp.gmail.com	587	TLS/STARTTLS (TLS)
Outlook	smtp.office365.com	587	STARTTLS (TLS)
Hotmail	smtp.office365.com	587	STARTTLS (TLS)
QQ	smtp.qq.com	587	STARTTLS (TLSv1.2)
Yahoo	smtp.mail.yahoo.com	587	STARTTLS (TLSv1.2)
126	smtp.126.com	465	SSL/TLS
Sina	smtp.sina.com	25/465/587	SSL/TLS/STARTTLS (SSL/TLS)

iNote

About mail configuration:

• SMTP portDefault to use port 25 without encryption, or using port 465 if SSL/TLS is used. Port 587 is mainly used for STARTTLS protocol mode.

The STARTTLS protocol mode that is usually used by default when selecting TLS.

• User nameUser name of Outlook and Hotmail require full names, and other email require a prefix before @.



B. Input Types

Table B-1 Input Types

Input Types	Operations	
	The system will immediately alarm when it detects triggering event after system armed.	
Instant Zone	Audible Response Trigger the system sound and sounder.	
	Voice Prompt: Zone X alarm.	
	The system will immediately alarm when it detects triggering event after system armed.	
Perimeter Zone	Audible Response: Trigger the system sound and sounder. There is a configurable interval between alarm and sounder output, which allows you to check the alarm and cancel the sounder output during the interval.	
	Voice Prompt: Zone X perimeter alarm.	
	The system provides you time to leave through or enter the defense area without alarm.	
Delayed Zone	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X alarm.	
Follow Zone	The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.	
	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X follow alarm.	
24H Silonco Zono	The zone activates all the time without any sound/sounder output when alarm occurs.	
24H Silence Zone	Audible Response: No system sound (voice prompt or sounder).	
	The zone activates all the time.	
Panic Zone	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X panic alarm.	
Fire Zone	The zone activates all the time with sound/sounder output when alarm occurs.	



Input Types	Operations	
	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X fire alarm.	
	The zone activates all the time with sound/sounder output when alarm occurs.	
Gas Zone	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X gas alarm.	
	The zone activates all the time with beep confirmation when alarm occurs.	
Medical Zone	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X medical alarm.	
Timeout Zone	The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired (1 to 599) seconds.	
Disabled Zono	Alarms will not be activated when the zone is triggered or tampered.	
Disabled Zone	Audible Response: No system sound (voice prompt or sounder).	
	The system will immediately alarm when it detects triggering event after system armed.	
Virtual Zone (Keypad/Keyfob)	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Buzzer beeps.	
	The system will immediately alarm when it detects triggering event after system armed.	
Tamper Alarm	Audible Response: Trigger the system sound and sounder.	
	Voice Prompt: Zone X tampered.	
Link	Trigger the linked device when event occurs.	
	e.g. The output expander linked relays will be enabled when the AX PRO is armed.	
	When armed: Voice prompt for fault. You can handle the fault according to the voice prompt.	
Arm	 System sound for arming with Tag or keyfob. Voice prompt for fault. You can handle the fault according to the voice prompt. 	



Fault event displays on client. You can handle the fault via client software or mobile client.

Voice Prompt: Armed/Arming failed.



C. Output Types

Table C-1 Output Types

Output Types	Active	Restore
Arming	Arm the AX PRO	After the configured output delay
Disarming	Disarm the AX PRO	After the configured output delay
Alarm	When alarm event occurs. The alarm output will be activated after the configured exit/enter delay.	After the configured output delay, disarm the AX PRO or silence alarm
Zone Linkage	When alarm event occurs, the linked relay will output alarm signal.	After the configured output duration
Manual Operation	Enable relays manually	Over the triggering time or disable the relays manually



D. Event Types

Table D-1 Event Types

Event Types	Custom	Default 1 (client software notification)	Default 2 (alarm receiving center 1/2)	Default 3 (mobile client)	Default 4 (telephone)
Alarm and Tamper	×/v	V	V	V	V
Life Safety Event	×/√	V	V	V	V
System Status	×/v	V	×	×	×
Panel Management	×/√	V	×	×	×



E. Access Levels

Level	Description
1	Access by any person; for example the general public.
2	User access by an operator and administrator; for example customers (systems users).
3	User access by an installer; for example an alarm company professional.

Table E-1 Permission of the Access Level

Function	Permission		
	1	2	3
Arming	No	Yes	Yes
Disarming	No	Yes	Yes
Restoring/Clearing Alarm	No	Yes	Yes
Entering Walk Test Mode	No	Yes	Yes
Bypass(zone)/Disabling/Force Arming	No	Yes	Yes
Adding/Changing Verification Code	No	Yes ^d	Yes ^d
Adding/Editing Level 2 User and Verification Code	No	Yes	Yes
Adding/Editing Configuration Data	No	No	Yes
Replacing software and firmware	No	No	No

iNote

^a By the condition of being accredited by user in level 2.
 ^bBy the condition of being accredited by user in level 2 and level 3.
 ^dUsers can only edit their own user code.

- The user level 2 can assign the login permission of the controller to the user level 3 in the settings page.
- The user level 2 should assign permissions to the user level 3 if the user level 3 wants to login the controller remotely.
- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.



- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.
- The user level 4 can login the controller only when the user level 2 or level 3 has assigned permissions to the user level 4.



F. Signalling

Detection of ATP/ATS Faults

ATP (Alarm Transmission Path) faults will be detected when network interface of the control panel disconnected or the transmission path to the transceiver of receiving center located in ARC blocked somewhere in between. An ATS (Alarm Transmission System) fault will be reported when ATP faults are detected on both transmission paths.

ATP restore will be detected as soon as network interface connected and the transmission path to the transceiver of receiving center restored. ATS restore will be reported when ATP restore of any transmission path is detected.

The timing performance of detecting ATP faults and restores shows in the table below.

	TN	Maximum timing of detection
Primary ATP failure/restore	LAN/WiFi	10 min
Secondary ATP failure/restore	GPRS	60 min
	3G/4G LTE	20 min (when primary ATP failed)

Signalling will be always transmitted from primary ATP when it is operational. Otherwise it will be automatically switched to secondary transmission path that is operational at the moment. Both primary and secondary ATP fault and restore events will be reported to ARC when there is an ATP left to work. They will also be recorded to mandatory log memory with capacity of 1000 records allocated in non-volatile flash memory storage, as well as the ATS fault record. The detail of reports and log records are listed in the table below.

	Event code when signalling	Event log description
Primary ATP failure/restore	E351/R351	LAN Path Failed/LAN Path Recovery
Secondary ATD failure/restore	E352/R352	Mobile Net Path Failed/Mobile Net Path
Secondary ATP failure/restore		Recovery
ATS failure/restore	N/A	ATS Failed
Primary network interface failure/restore	E351/R351	LAN Path Failed/LAN Path Recovery
Secondary notwork interface failure (restore	E352/R352	Mobile Net Path Failed/Mobile Net Path
Secondary network interface failure/restore		Recovery

ATS Category

The ATS category of AXPRO is DP2. While the alarm receiving center is enabled. The control panel will upload alarm report to the receiver center via the main path (LAN or Wi-Fi) or the back-up path (3G/4G). If the control panel is properly connected to the LAN or Wi-Fi, the main path is selected as the transmission path. If the main path connection is failed, the path will be switched to 3G/4G. And if the main path connection is restored, the path will be switched back to LAN or Wi-Fi. The control panel checks the connection status continuously, and generates logs transmission fault for any of the path. While both of the paths are invalid, the control panel determines ATS fault.



G. SIA and CID Code

iNote

The code below is for transmitting from the security control panel to ARC via DC09 protocol.

SIA Code	CID Code	Description
MA	1100	Medical Alarm
МН	3100	Medical Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	Burglary Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	Burglary Alarm Restored
FA (Heat Detector: KA)	1111 (Heat Detector: 1114)	Fire Alarm
FH (Heat Detector: KH)	3111 (Heat Detector: 3114)	Fire Alarm Restored
НА	1121	Duress alarm
НА	1122	Silent Panic Alarm
НН	3122	Silent Panic Alarm Restored
AA	1123	Audible Panic Alarm
СН	3123	Audible Panic Alarm Restored
	1133	24H Alarm
	3133	24H Alarm Restored
	1133	24H Alarm
	3133	24H Alarm Restored
ВА	1130	Timeout Alarm
вн	3130	Timeout Alarm Restored
РА	1120	Audible Panic Alarm
РН	3120	Audible Panic Alarm Restored
ВА	1130	Burglary Alarm
ВН	3130	Burglary Alarm Restored
ВА	1131	Perimeter Breached

Table F-1 SIA and CID Code



SIA Code	CID Code	Description
вн	3131	Perimeter Restored
AD	1132	Interior Burglary Alarm
СК	3132	Interior Burglary Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	24H Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	24H Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	Burglary Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	Burglary Alarm Restored
ТА	1137	Lid Opened
TR	3137	Lid Restored
BV	1139	Confirmed Alarm
BW	3139	Confirmed Alarm Restore
		BUS Open-circuit Alarm
		BUS Open-circuit Restored
AF	1142	BUS Short-circuit Alarm
CN	3142	BUS Short-circuit Restored
ТА	1144	External Probe Disconnected
TR	3144	External Probe Connected
AG	1148	Device Motion Alarm
СО	3148	Device Motion Alarm Restored
	1149	Masking Alarm
	3149	Masking Alarm Restored
GA	1162	Gas Leakage Alarm
GH	3162	Gas Leakage Alarm Restored
АН	1207	Zone Early-Warning
СР	3207	Zone Early-Warning Dismissed
AT	1301	Mains Power Lost
AR	3301	Mains Power Restored



SIA Code	CID Code	Description
YT	1302	Battery Low
YR	3302	Battery Voltage Restored
ZY	1305	Reset to defaults
YM Transmitter battery missing ID range: 301~	1311 Transmitter battery missing ID range: 301~	Battery Disconnected
YR Transmitter battery missing ID range: 301~	3311 Transmitter battery missing ID range: 301~	Battery Reconnected
YI	1312	Overcurrent Protection Triggered
YJ	3312	Overcurrent Protection Restored
ҮР	1319	Overvoltage Protection Triggered
YQ	3319	Overvoltage Protection Restored
AI	1333	Expander Exception
CQ	3333	Expander Restored
AJ	1336	Printer Disconnected
CR	3336	Printer Connected
ХТ	1384	Battery Low
XR	3384	Battery Voltage Restored
		Expander Low Voltage
		Normal Expander Voltage
YP	1301	Mains Power Lost
YQ	3301	Mains Power Restored
YM	1311	Battery Disconnected
YR	3311	Battery Reconnected
TA (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	1144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Lid Opened
TR (The serial number of output module starts from 1,	3144 (The serial number of output module starts from 1,	Lid Restored


SIA Code	CID Code	Description
of keypad starts from 101, of tag reader starts from 201)	of keypad starts from 101, of tag reader starts from 201)	
YP transmitter AC power down ID range: 301~	1301 transmitter AC power down ID range: 301~	Expander AC Power Loss
YQ transmitter AC power down ID range: 301~	3301 transmitter AC power down ID range: 301~	Expander AC Power Loss Restored
ТА	1144	Lid Opened
TR	3144	Lid Restored
ТА	1144	Lid Opened
TR	3144	Lid Restored
XL	1381	Device Offline
XC	3381	Device Restored
TA (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	1144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Lid Opened
TR (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Lid Restored
XT (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	1384 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Battery Low
XR (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3384 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Battery Voltage Restored
XL (The serial number of output module starts from 1,	1381 (The serial number of output module starts from 1,	Device Offline



SIA Code	CID Code	Description
of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	
XC (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Restored
LT	1351	Main Signalling Path Fault
LR	3351	Main Signalling Path Restored
LT	1352	Backup Signalling Path Fault
LR	3352	Backup Signalling Path Restored
AM	1354	Telephone Line Disconnected
CU	3354	Telephone Line Connected
AN	1382	BUS Supervision Fault
CV	3382	BUS Supervision Restored
ТА	1144	Lid Opened
TR	3144	Lid Restored
		Zone Open-circuit Alarm
		Zone Short-circuit Alarm
OP	1401	Disarmed
CL	3401	Armed
OA	1403	Auto Disarmed
CA	3403	Auto Armed
BC	1406	Alarm Silenced
CW	3408	Instant Arming
CS	1409	Keyswitch Zone Disarming
OS	3409	Keyswitch Zone Arming
NL	3441	Armed in home mode
СХ	3442	Forced Arming
		Turn On Output by Schedule



SIA Code	CID Code	Description
		Turn Off Output by Schedule
СТ	1452	Late to Disarm
CD	1455	Auto Arming Failed
		Turning On Output Failed
		Turning Off Output Failed
		Auto Disarming Failed
		Network Change
QB	1570	Bypassed
QU	3570	Bypass Restored
AU	1574	Group Bypass
CZ	2574	Group Bypass Restored
AV	1601	Manual Report Test
RP	1602	Periodic Report Test
TS	1607	Walk Test Enabled
TE	3607	Walk Test Disabled
AW	1617	Telephone Connection Test
LB	1627	Programming mode
LX	1628	Exit Programming
ВА	1131	Intrusion Detection
вн	3131	Intrusion Detection Restored
ВА	1131	Cross-Zone Alarm
вн	3131	Cross-Zone Alarm Restored
		PIR Alarm
		PIR Alarm Restored
AY	1775	Sudden Increase of Sound Intensity Alarm
DE	3775	Sudden Increase of Sound Intensity Alarm Restored
AZ	1776	Sudden Decrease of Sound Intensity Alarm
DF	3776	Sudden Decrease of Sound Intensity Alarm Restored



SIA Code	CID Code	Description
		Audio Input Fault
		Audio Input Restored
ВА	1131	Line Crossing Alarm
ВН	3131	Line Crossing Alarm Restored
ВА	1134	Region Entrance Detection
EA	1134	Alarm Restored
FA	1112	Fire Source Alarm
FH	3112	Fire Source Alarm Restored
KS	1158	High Temperature Pre-Alarm
KR	3158	High Temperature Pre-Alarm Restored
ZS	1159	Low Temperature Pre-Alarm
ZR	3159	Low Temperature Pre-Alarm Restored
КА	1158	High Temperature Alarm
КН	3158	High Temperature Alarm Restored
ZA	1159	Low Temperature Alarm
ZH	3159	Low Temperature Alarm Restored
EA	1134	Region Exiting Detection
PA (The user No. of keypad starts from 101, of keyfob starts from 901)	1120 (The user No. of keypad starts from 101, of keyfob starts from 901)	Audible Panic Alarm
FA	1110	Keypad/Keyfob Fire Alarm
		Keypad/Keyfob Burglary Alarm
CI	1454	Arming Failed
МА	1100	Keypad/Keyfob Medical Alarm
DK	1501	Keypad Locked
DO	3501	Keypad Unlocked
		Absence Alarm
BE	1910	Keypad Disconnected
DH	3910	Keypad Connected



SIA Code	CID Code	Description
BF	1911	KBUS Relay Disconnected
DI	3911	KBUS Relay Connected
		KBUS GP/K Disconnected
		KBUS GP/K Connected
		KBUS MN/K Disconnected
		KBUS MN/K Connected
DK	1501	Tag Reader Locked
DO	3501	Tag Reader Unlocked
BD	1865	Unregistered Tag
XL	1381	Device Offline
XC	3381	Device Restored
ХТ	1384	Battery Low
XR	3384	Battery Voltage Restored
XL (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	1381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Device Offline
XC (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	3381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Device Restored
XL	1381	Device Offline
XC	3381	Device Restored
BI	1918	Radar Transmitter Fault
DL	3918	Radar Transmitter Restored
ХТ	1384	Battery Low
XR	3384	Battery Voltage Restored
NT	1350	Cellular Fault
NR	3350	Cellular Restored
NT	1350	SIM Card Exception
NR	3350	SIM Card Restored
NT	1350	Network Fault
NR	3350	Network Restored



SIA Code	CID Code	Description
XQ	1344	Jamming Detected
ХН	3344	Jamming Restored
NT	1350	Data limitation Reached
ХТ	1384	Battery Low
XR	3384	Battery Voltage Restored
NT	1350	IP Address Already Used
NR	3350	Normal IP address
NT	1350	Network Fault
NR	3350	Network Restored
ВА	1131	Motion Detection Alarm Started
ВН	3131	Motion Detection Alarm Stopped
BJ	1941	Device Blocked
DM	3941	Device Blocking Alarm Restored
		Video Signal Loss
		Video Signal Restored
		Input/Output Format Unmatched
		Input/Output Format Restored
		Video Input Exception
		Video Input Restored
		Full HDD
		Free HDD
		HDD Exception
		HDD Restored
		Upload Picture Failed
BQ	1948	Email Sending Failed
BR	1949	Network Camera Disconnected
DS	3949	Network Camera Connected
		Duty Checking
		Post Response
BU	1962	Fire Alarm Consulting



SIA Code	CID Code	Description
DT	3962	Fire Alarm Consulting Over
BV	1963	Duress Alarm Consulting
DU	3963	Duress Alarm Consulting Over
BW	1964	Emergency Medical Alarm Consulting
DV	3964	Emergency Medical Alarm Consulting Over
DW	3250	Patrol Signing
ВХ	1970	BUS Query
ВҮ	1971	BUS Registration
BZ	1973	Single-Zone Disarming
DX	3973	Single-Zone Arming
СА	1974	Single-Zone Alarm Cleared
СВ	1306	Device Deleted
DY	3306	Device Enrolled
сс	1976	Business Consulting
DZ	3976	Business Consulting Over
CD	1306	Device Deleted
EA	3306	Device Enrolled
CE	1306	Device Deleted
EB	3306	Device Enrolled
CF	1306	Device Deleted
EC	3306	Device Enrolled
CG	1306 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Deleted
ED	3306 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Enrolled



SIA Code	CID Code	Description
JA	1461	Incorrect Password
NT	1350	Device Offline
YM	1311	Power Depletion



H. Communication Matrix and Operation Command

Please scan the OR code for communication matrix and operation command





AXPRO Communication Matrix

AXPRO Operation Command

User Privacy Statement

• The debug or zhimakaimen command is used to control access to the file system to ensure device security. To obtain this permission, you can contact technical support.

• The device has admin, installer, maintenance, operator account. You can use these accounts to access and configure the device.

Password	The password for the device account, used to log in to the device.
Username	The username for the device account, used to log in to the device.
Device IP and port	The device IP and port are used to support network service
	communication. For details, refer to Communication Matrix.
Log	Used to record information such as device operating status and
-0	operation records.
Database information	Used to record information.

User Privacy Information Description



