

The HIKVISION logo is presented within a red horizontal bar. The word "HIKVISION" is written in a white, bold, italicized sans-serif font. To the left of the text, there is a white diagonal slash that extends from the top-left corner of the bar towards the center.

HIKVISION

AX HYBRID PRO

Manual de usuario

Legal Information

©2022 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

About this Manual

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (<https://www.hikvision.com/>).

Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

Trademarks

HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.

Other trademarks and logos mentioned are the properties of their respective owners.

Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

YOU ACKNOWLEDGE THAT THE NATURE OF INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR

PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.




Data Protection

During the use of device, personal data will be collected, stored and processed. To protect data, the development of Hikvision devices incorporates privacy by design principles. For example, for device with facial recognition features, biometrics data is stored in your device with encryption method; for fingerprint device, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.

As data controller, you are advised to collect, store, process and transfer data in accordance with the applicable data protection laws and regulations, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and assessments of the effectiveness of your security controls.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.
 Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Note	Provides additional information to emphasize or supplement important points of the main text.

Note

- Please update firmware to the latest version.
- For installers, it is recommended to install and maintain devices via Hik-Partner Pro.

Regulatory Information

EN 50131-3:2009

EN 50131-10:2014

EN 50136-2:2013

Security Grade (SG): 2

EN 50136-1:2012+A1:2018

Environmental Class (EC) : II


EN 50131-6:2017

SP4




EN 50131-1:2006+A1:2009+A2:2017+A3:2020

EN 50130-4:2011+A1:2014

EN 50130-5:2011

 **Note** EN50131 compliance labeling should be removed if non-compliant configurations are used.

EU Conformity Statement

	<p>This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, RE Directive 2014/53/EU, the RoHS Directive 2011/65/EU</p>
	<p>2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info</p>
	<p>2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info</p>

Contenido

Capitulo 1 Introduccion	1
System Descripcion.....	1
Capitulo 2	
Inicio.....	3
2.1 Activacion via WEB	3
2.2 Activacion via APP.....	3
Chapter 3 Configuracion	11
3.1 Configuración con el cliente web.....	11
3.1.1 Gestión de usuarios.....	11
3.1.2 Gestión de dispositivos	12
3.1.3 Ajustes del sistema	24
3.1.4 Configuración de comunicación.....	30
3.1.5 Mantenimiento.....	39
3.1.6 Seguridad.....	42
3.2 Configuración con Hik-Partner Pro.....	44
3.3 Configuración con Hik-Connect	66
3.4 Reportar a CRA (Centro Receptor de Alarmas)	89
Configurar ATS en el transceptor del centro receptor.....	89
Configurar ATS en Transceptor del Panel	90
Prueba de señalizacion.....	92
Capitulo 4 Operaciones Generales.....	93
4.1 Entradas de acceso	93
4.2 Armado.....	93
4.3 Desarmado	95
4.4 SMS Control	95
A. Solución de problemas.....	96
A.1 Fallo de comunicación.....	96
A.1.1 Conflictos IP	96
A.1.2 La página web no es accesible.....	96
A.1.3Hik-Connect está desconectado	96

A.1.4 La cámara de red se cae con frecuencia.....	96
A.1.5 No se pudo agregar el dispositivo en la APP.....	96
A.1.6 La información de alarma no se envía a APP/4200/Centro de alarmas.....	97
A.2 Exclusión mutua de funciones	97
A.2.1 No se puede ingresar al modo de inscripción	97
A.3 Falla de zona.....	97
A.3.1 Zone Fuera de linea	97
A.3.2 Zona a prueba de manipulaciones/tapa abierta	97
A.3.3 Zona activada/falla	97
A.4 Problemas Mientras se arma.....	98
A.4.1 Fallo en el armado (cuando no se inicia el proceso de armado).....	98
A.5 Fallo operativo	98
A.5.1 No se pudo ingresar al modo de prueba	98
A.5.2 La operación de borrado de alarma en el panel no produce el borrado de alarma Reporte	98
A.6 Error de envío.....	98
A.6.1 No se pudo enviar el correo de prueba	98
A.6.2 No se pudo enviar el correo durante el uso.....	99
A.6.3 No se pudieron enviar correos a Gmail.....	99
A.6.4 No se pudieron enviar correos a QQ o Foxmail	99
A.6.5 No se pudieron enviar correos a Yahoo	99
A.6.6 Configuración del Mail.....	100
B. Tipos de entrada	101
C. Tipos de salida.....	104
D. Tipos de evento.....	105
E. Niveles de acceso.....	106
F. Señalización	108
Detección de Fallas ATP/ATS.....	108
ATS Categorías.....	108
G. Códigos SIA and CID Code	109

Capítulo 1 Introducción

Descripción del sistema

El panel de control AX HYBRID PRO es un panel de control de intrusión cableado con detectores inalámbricos y capacidad de acceso a periféricos. Es el primer panel de control que admite Bus Speed-X de alta velocidad, que es una tecnología creativa y se utiliza para transmitir vídeo/imagen de verificación desde PIR-CAM. Además, este panel de control híbrido admite una biblioteca de voz personalizada, que está diseñada para que los usuarios carguen archivos de voz personalizados. Estos archivos de voz se reproducirán mediante una llamada telefónica de alarma cuando se active la alarma. En cuanto a las funciones básicas, admite métodos de comunicación Wi-Fi, PSTN, TCP/IP y GPRS/3G/4G. También es compatible con Hik-Partner Pro, Hik-Connect, Hik IP Receiver, Hik IP Receiver Pro y Hik-Central, que es aplicable a escenarios de mercado, hotel, supermercado, almacén, oficina, casa (especialmente con cables preinstalados). etc.

 **Note**

ISUP5.0: a privacy internet protocol that is used for accessing the third-party platform, which supports alarm report uploading, AX HYBRID PRO management, and short video uploading. The prioritization of the message and indications are the same. The AXPRO uploads messages and gives indications synchronously.

 **Note**

Standard DC-09 Protocol:

ADM-CID: The data presenting method of DC-09 is CID, which is not encrypted and only for uploading alarm report.

*ADC-CID: The data presenting method of DC-09 is CID, which is encrypted and only for uploading alarm report.

SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is not encrypted and only for uploading alarm report.

*SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is encrypted and only for uploading alarm report.

Capítulo 2 Puesta en marcha

2.1 Activación via WEB

Utilice el navegador web para activar el dispositivo. Utilice el software SADP o el cliente de PC para buscar el dispositivo en línea para obtener la dirección IP del dispositivo y activar el dispositivo en la página web.

Antes de que empieces

Asegúrese de que su dispositivo y su PC se conecten a la misma LAN.

Pasos

1. Abra un navegador web e ingrese la dirección IP del dispositivo.

Nota

Si conecta el dispositivo a la PC directamente, deberá cambiar la dirección IP de su PC a la misma subred que el dispositivo. La dirección IP predeterminada del dispositivo es 192.0.0.64.

2. Cree y confirme la contraseña de administrador. (El nombre de usuario predeterminado de la cuenta de administrador es admin).

Caution

SE RECOMIENDA UNA CONTRASEÑA FUERTE: le recomendamos encarecidamente que cree una contraseña segura de su elección (utilizando un mínimo de 8 caracteres, incluidas letras mayúsculas, minúsculas, números y caracteres especiales) para aumentar la seguridad de su producto. Y le recomendamos que restablezca su contraseña con regularidad, especialmente en el sistema de alta seguridad. Restablecer la contraseña mensual o semanalmente puede proteger mejor su producto..

3. Click **OK** to completar la activación.

Nota

- El nombre de usuario predeterminado de la cuenta de administrador es admin.
 - Primero debe iniciar sesión en la cuenta de administrador para habilitar el instalador.
 - La contraseña predeterminada del instalador es installer12345.
-

2.2 Activación via APP

Al inicializar el dispositivo con Hik-Partner Pro o Hik-Connect, debe habilitar Hik-Connect a través de SADP y agregar primero una cuenta de instalador a AX HYBRID PRO. La cuenta de instalador invitará y transferirá la propiedad a la cuenta de administrador más tarde, después de finalizar toda la configuración y prueba inicial. Siga los pasos a continuación para inicializar el sistema de alarma híbrido.

Step1 Activate via SADP

Before You Start


- Get the SADP software from the supplied disk or the official website <http://www.hikvision.com/en/>, and install the SADP according to the prompts.
 - The device and the PC that runs the SADP tool should be within the same subnet.
1. Run the SADP software and search the online devices.
 2. Find and select your device in online device list.
 3. Input new password (admin password) and confirm the password.

Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

4. Check **Enable Hik-Connect**.

5. Click Activate to start activation. Status of the device becomes **Active** after successful activation.



The screenshot shows the SADP software interface. On the left, a table lists online devices with columns for ID, Device Type, Status, IPv4 Address, Port, Enhanced SDK Service Port, Software Version, IPv4 Gateway, and HT. The 'Refresh' button is highlighted with a red box. On the right, the 'Activate the Device' dialog box is shown. It features a blue padlock icon and the text 'The device is not activated.' Below this, a blue box states 'You can modify the network parameters after the device activation.' The 'Activate Now' button is highlighted with a red box. The 'New Password' field is filled with dots, and the 'Confirm Password' field shows '3' dots. The 'Enable Hik-Connect' checkbox is checked and highlighted with a red box. The 'Activate' button at the bottom is also highlighted with a red box.

Note

- Only AX Hybrid PRO V1.0.4 and above need the step1. Lower version can skip this step.

Step2 Create a site (Only for HPP)


Download the Hik-Partner Pro and login with the installer account.

A site is the place where the alarm system deployed. Create a site where the device can be added to with its site name and address. The owner of the site would be an end user, usually regarded as administrator.


Step3 Configure the Network on APP

1. Download Hik-Connect/Hik-Partner Pro and log in.
2. Power on the AX HYBRID PRO.
3. Turn the Wi-Fi mode switch to HOTSPOT.
4. Connect your phone to your home Wi-Fi. Make sure that this Wi-Fi can access the Internet normally and the signal is stable.
5. Open the HC or HPP, tap +, and select **Scan QR Code**. Scan the QR code of the AX HYBRID and wait for the result.


Or you can tap **Manual Adding** and enter the serial No.




6. Tap **Next**.




7. Tap **Wireless Connection**, and tap **Next**.




8. The APP will automatically fill in the home Wi-Fi currently used by the mobile phone into the page, as shown in the figure below. After confirming the Wi-Fi password, tap **Next**.



9. Tap **Connect to a Network**.




10. Enter the device verification code and tap **OK**. (The verification code is on the device label.)



11. The APP will search the device Wi-Fi automatically. Check whether the connected Wi-Fi is belonged to the target device and tap **Connect**. As shown in the figure below, the Wi-Fi connected

to the mobile phone should with name "HAP_serial number" (AX HYBRID PRO serial number)



12. Follow the prompts: turn the Wi-Fi mode switch to WLAN.




12. Wait for connection.




13. Wait for the device to join the home Wi-Fi and log in the Cloud.


(1) When the home Wi-Fi signal is good, the control panel will successfully log in to cloud and complete the binding before the countdown ends.



(2) When the home Wi-Fi signal is unstable, the control panel may not be connected to the cloud before the countdown ends, and the following page will appear:



If you make sure that the home Wi-Fi password is correct and quality is good, tap **Refresh Network**, the control panel will enter a new countdown. You can wait for the connection. If you want to change the home Wi-Fi, you should change the home Wi-Fi connected to the mobile phone first, then press the **RESET** button of the control panel (marked in the figure below) for 10 seconds. Tap **Retry**. The interface will jump back step 8, you can configure the network again.



Capitulo 3 Configuracion

3.1 Set-up with the Web Client

Steps

1. Connect the device to the Ethernet.
2. Search the device IP address via the client software and the SADP software.
3. Enter the searched IP address in the address bar.
4. Enter the user name and password to login.



Only the admin and the installer can login to the web client.

You can view the area, zone, device, and network information on the overview page.

3.1.1 User Management

The administrator and the installers can manage users. If you are the administrator, you can add, edit, and delete users, and assign different permissions to the newly-added users.

Click **User Management** to enter the page.



There are three types of users for the AX PRO, including administrator (or owner), operator, and installer (or setter). Different types of users have different permissions for accessing the functionality of the AX PRO.

Add User

Steps

1. Click **User Management** to enter the page.
2. Click **+Add**.
3. Configure the user parameters in the pop-up window on the right.

Disposable User

-**Permanent:** Permanent use. Configurable with full user permission.

-**One-Time User:** Expired after arming or disarming once, or automatically expires after 24 hours. No duress code permission. No keyfobs and tags permission.


Duress Code

After entering the duress code, the system will upload the duress alarm to the alarm receiving center. No audible or visual alarm.

4. Click **Save** to add the user.

Edit User

Steps

1. Click **User Management** to enter the page.
2. Click  to the right of a user to edit user parameters.

User Parameters

You can configure linked areas, the keypad password, the duress code and user permissions.


Keyfob&Tag

You can add, delete, enable or disable keyfobs and tags.

3. Click **Save**.

Delete User

Steps

1. Click **User Management** to enter the page.
2. Click  to the right of a user to delete user parameters. You can also check users in the list and click **Delete** to delete users in batch.

Note

The administrator and the installer cannot be deleted.


3.1.2 Device Management


You can manage the enrolled peripherals including detector, sounder, keypad, etc. in this section.

Area

You can set the area parameters on the page.

Steps

1. Click **Device Management** → **Area** to enter the page.
2. Select an area and click  to enable the area.
3. Click **Away Arm**, **Stay Arm**, **Disarmed** and **Silence Alarm** to change the area status.

4. Click  to edit parameters.

Late to Disarm Notification

Enable the function and set the time. If the alarm is triggered after the configured time, the person will be considered as late.

Enable Auto Arm

Enable the function and set the arming start time (Time Schedule). The zone will be armed according to the configured time.

Note

The auto arming time and the auto disarming time cannot be the same.

- Force Arm When System has Faults:

While the function is enabled, faults will be ignored when the system is automatically armed.

- Count Down Sound Prompt:

After enabled, the buzzer beeps slowly 2 minutes before the auto arming starts, and beeps rapidly 1 minute before the auto arming starts. After disabled, the buzzer will not beep before auto arming.

Enable Auto Disarm

Enable the function and set the disarming start time (Time Schedule). The zone will be disarmed according to the configured time.

Note

The auto arming time and the auto disarming time cannot be the same.

- Weekend Exception:

Enable the function and the zone will not be armed in the weekend.

- Holiday Exception:

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling. Up to 12 holiday groups can be set.

5. Click **Save**.

6. Click **Linked Zone/Detector** to enter the page. Click **Bypass** or **Bypass Restored** to edit linkages of the area.

Quick Adding

Enroll peripherals.

Scan Adding

Steps

1. Click **Device Management** → **Mount Device** → **Quick Add Device** → **Scan Adding** to enter the page.

2. Select **Scan Mode**.

Continuous Scan

Add devices from a continuous address range.

Discrete Scan

Add devices from several discrete addresses.

3. Set **Address Range** or select address.



Please enter a number in the range 0 to 63.
The address range should be continuous.

4. Click **OK**. Scanned peripherals will be listed.



The scan takes 1 minute.
If the peripheral and the control panel has different frequency, the peripheral cannot be enrolled. Click **Scan Updating** to select the frequency supported by the current control panel.

5. Tick the checkbox in front of the peripheral. Multiple selection is possible.

6. Click **Batch Add to Control Panel** to add peripherals.



Up to 32 peripherals can be enrolled.

Device Enroll Mode

Steps



















1. Click **Device Management** → **Mount Device** → **Quick Add Device** → **Device Enroll Mode** to enter the page.
2. Drag the slider to enable wireless device enrollment mode.
3. Select main device type and name.
4. Click **OK**. Wireless peripherals will be enrolled.

Zone

You can set the zone parameters on the zone page.

Steps

1. Click **Device Management** → **Mount Device** → **Zone** to enter the Zone page.

Zone	Device Information	Main Device	Channel No.	Zone Type	Silent Alarm	Chime	Linked Area	Linked Camera	Operation
<input type="checkbox"/> 1	 Zone 1 Device Number: 5  Disarmed	Zones Built-in	1	Instant	Disable	Disable	Area 1	/	   
<input type="checkbox"/> 2	 Zone 2 Device Number: 7  Disarmed	Zones Built-in	2	Instant	Disable	Disable	Area 2	/	   
<input type="checkbox"/> 3	 Zone 3 Device Number: 8  Disarmed	Zones Built-in	3	Instant	Disable	Disable	Area 3	/	   

2. Click **Add** to add a zone.


3. Select **Relate Mode**.

Wireless

Enter **Serial Number**, and select **Detector Type**. Select **Main Device Type** and **Main Device Name**. Click **Next**, it will start enrolling. Power on the device and configure basic settings and zone parameters. Click **Save** to add a wireless zone.

Wired

Select **Main Device Type**. Select **Main Device Name** and **Channel**. Click **Next**, it will start enrolling. Configure basic settings and zone parameters. Click **Save** to add a wired zone.

4. Select a zone and click  to enter the Zone Settings page.

Basic Settings

*Name

Detector Type

*Linked Area

Zone Parameter

Zone Type

Detector Contact Mode

Wiring Mode No EOL SEOL DEOL TEOL

Pulse Sensitivity 30ms 100ms 1000ms

Stay Arm Bypass

Forbid Bypass on Arming

Chime

Silent Alarm

Sounder Delay Time

Double Knock

Cross Zone

Link Pircam

Link Camera

Dual Zone

5. Edit the zone name.
6. Select the detector type and linked areas.

 **Note**

- Only enabled areas will be listed.
 - The newly added peripheral is linked to area 1 by default.
-

7. Select a zone type and detector contact mode.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

-Exit Delay: Exit Delay provides you time to leave through the zone without alarm.

Arm with faults is enabled: You should confirm faults first, and then the zone is in arming

process. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered and the zone will be armed.

Arm with faults is disabled: Immediately armed. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered.

-Entry Delay: Entry Delay provides you time to enter the zone to disarm the system without alarm.

After triggering, if the zone is not disarmed or silenced before the entry delay time ends, the zone will alarm.

-Stay Arm Delay Time: Stay arming uses Stay Arm Delay Time to count down.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keypad for users.

Note

- You can set 2 different time durations in **System Options** → **Schedule & Timer**.
 - Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
 - You can set Stay Arm Delay Time for the delay zone.
-

Panic Zone

24-hour active zone, whether armed or not. Report panic alarm after triggering. It is usually used in the sites equipped with panic button, smoke detector and glass-break detector.

Medical Alarm

24-hour active zone, whether armed or not. Report medical alarm after triggering.

Fire Zone

24-hour active zone, whether armed or not. Report fire alarm after triggering.

Gas Zone

24-hour active zone, whether armed or not. Report gas alarm after triggering.

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

Keyswitch Zone

-By Trigger Time: Change the arming and disarming status after each trigger. For example, in the disarmed status, if the zone is triggered, the linked area will be armed. Trigger the zone again and the area will be disarmed.

-By Zone Status: You need to choose to arm or disarm the linked area after the zone is triggered.

In the case of the tampering alarm, the arming and disarming operation will not be triggered.

Disabled Zone

Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-hour Zone

The zone activates all the time with sound/light output when alarm occurs, whether it is armed or not. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. When this zone has been triggered or restored and exceeds the set time, an alarm will be generated.

It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

-Not-Triggered Zone Alarm: If the zone is not triggered for the set time, it will alarm.

-Alarm on Zone Activated: If the zone is triggered for the set time, it will alarm.

-Retry Time Period: Set the timeout period.

8. Enable other functions according to your detector types and actual needs.



Note

The configurable functions vary in different detectors and zones. Refer to the actual zone to set the function.

Wiring Mode

Select the resistor wiring mode of the control panel.

Pulse Sensitivity

Select the sensitivity change ability for different pulse signals.

Stay Arm Bypass

The zone will be automatically bypassed in stay arming.

Forbid Bypass on Arming

After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or

continuously in a period of time, the alarm will be triggered.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.

If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.


If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.



Dual Zone


After enabled, when multi transmitter detects that the entire zone circuit of the local zone and the extended zone is open circuit, both zones trigger lid opened alarms.

9. If required, link a PIRCAM or a camera for the zone.

10. Click **Save**.

11. Click  to delete the zone.

12. Click  or  to bypass or restore bypass.

13. Click  to view the added zones' status, and click **Refresh** to view the latest status.

Network Camera

You can add network cameras in the system.

Steps

1. Click **Device Management** → **Mount Device** → **Network Camera** to enter the network camera management page.



Channel	Device Information	IP Address	Device Channel	Port	Operation
1	IPC 1 Device Number: 10 Disconnected	10.2.3.4	1	8000	  




2. Click **Add**, and enter the basic information of the camera, such as IP address and port No., and select the protocol type.

3. Enter the user name and password of the camera.

SADP Scanning

Scan all network cameras in the same LAN. A list will pop up after scanning. You can directly check to add cameras in the list.

4. Click **Next**, change the camera name and select linked areas.


5. Configure camera parameters such as zone type, stay arm bypass, chime, silent alarm, cross zone, etc. according to your actual needs.
6. Click **Save**.
7. **Optional:** Click  or  to edit or delete the selected camera.
8. **Optional:** Click  to configure video parameters.
9. **Optional:** Click **Refresh** to view the latest device information.




Sounder

Set sounder parameters.

Steps

1. Click **Device Management** → **Mount Device** → **Sounder** to enter the Sounder page.



Sounder	Device Information	Main Device	Sounder Type	Linked Area	Alarm Volume	Operation
1	Sounder 1 Device Number: 11 ● Online	Sounder Built-in	/	Area 1	/	  

2. Click **Add** to add a sounder.
3. Select the relate mode.

Wireless

Add wireless sounder. Enter the device serial No., select the sounder model, and check main device type and name. Click **Next**.





Wired

Add wired sounder. Check main device type and name. Click **Next**.

4. Check the linked area.

Note

- Only enabled areas will be listed.
 - The newly added peripheral is linked to area 1 by default.
-


5. Enter the alarm duration.
6. Enable **Sounder Tamper Alarm**.
7. Click **Save**.
8. **Optional:** Click  or  to edit or delete the selected sounder.
9. **Optional:** Click  to enable find me mode.
10. **Optional:** Click  to view the added sounders' status, and click **Refresh** to view the latest status.








Automation

You can set the parameters of the relay outputs that is enrolled.

Steps

1. Click **Device Management** → **Mount Device** → **Automation** to enter the page.



Automation	Device Information	Main Device	Channel No.	Linked Area	Link Event	Operation
<input type="checkbox"/>	Relay 1 Device Number: 6 Off	Outputs Built-in	1	Area 1	Manual	   
<input type="checkbox"/>	Relay 2 Device Number: 12 Off	Outputs Built-in	2	Area 1	Manual	   

2. Click **Add** to add relay output.
3. Select the relate mode.

Wireless

Add wireless relay output. Enter the device serial No., select the sounder model, and check main device type and name. Click **Next**.

Wired

Add wired relay output. Check main device type and name. Click **Next**.

4. Set the relay name.
5. Select the linked area.

Note

- Only enabled areas will be listed.
 - The newly added peripheral is linked to area 1 by default.
 - The function varies according to different relay types
-

6. Set event type and its parameters:

Secondary Event

The sub-event type of alarm, arm, disarm and fault event.

Activation Mode

Latched: Continue the output until the relay is manually closed or opened.

Pulsed: The relay will be closed/open after the set duration.






Contact Status

Normally Open: Under normal conditions, the relay is open. When the event is triggered, the relay will be closed.

Normally Closed: Under normal conditions, the relay is closed. When the event is triggered, the relay will be open.

Schedule

You can set the close/open time for the relay.


7. Click **Save**.
8. **Optional:** Click  or  to edit or delete the selected relay.
9. **Optional:** Click  or  to enable or disable the relay.
10. **Optional:** Click  to view the added relays' status, and click **Refresh** to view the latest status.


Keypad

You can set the parameters of the keypad that is enrolled to the AX HYBRID PRO .

Steps

1. Click **Device Management** → **Mount Device** → **Keypad** to enter the page.



2. Click  to enter the Keypad Settings page.
3. Set the keypad name.
4. Check linked areas.
5. Enable the function buttons.
6. Select the keypad mode.

Standard Mode

Area selection and fault confirmation are supported when swiping tag to arm or disarm.

Simple Mode

No Area selection and fault confirmation when swiping tag to arm or disarm.

7. Enable the function according to your actual needs.

Authorization

Only standard mode has this function. You can select the authorization method.

Arming Without Password

If enabled, the Arming Process function will be unavailable when you arm areas.

Area Status

Display area status and alarm information in the keypad main page.

Backlight

Enable the backlight of the keypad. You can set the backlight off time.

Alarm Buzzer / Button Buzzer

If enabled, when alarm or button is triggered, the device will beep.

Active on Entry Delay

When someone enters the delay zone, the screen and backlight of the keypad will be on.
This function can indicate the keypad position for those who enter the delay zone at night.

Keypad Arming Light

Enable the arming indicator of the keypad.

Silent Panic Alarm / Silent Medical Alarm

Panic alarm / Medical alarm do not sound.

Text1 / Text2

The text displayed on the main page when waking up. Customizable content.



Note

- Only enabled areas will be listed.
 - The newly added peripheral is linked to area 1 by default.
 - For detailed information, refers to the keypad user manual.
-


7. Click **Save**.

Note

- You can set the keypad password on the page of **User** → **User Management** → **Operation**.
-

8. **Optional:** Click  or  to edit or delete the selected keypad.

9. **Optional:** Click  to enable find me mode.

10. **Optional:** Click  to view the added keypads' status, and click **Refresh** to view the latest status.

Keyfob

You can set the parameters of the keyfob.



Steps



1. Click **Device Management** → **Mount Device** → **Keyfob** to enter the page.


2. Click **Add** to add a keyfob.

3. Enter the serial No., select main device type and name. Click **Next**.

4. Select a linked user. Configure the functions of the buttons according to your actual needs.

5. **Optional:** Click  or  to edit or delete the selected keyfob.

9. **Optional:** Click  or  to enable or disable the keyfob.


10. **Optional:** Click  to view the added keyfobs' status, and click **Refresh** to view the latest status.

Module

Set module parameters.

Steps

1. Click **Device Management** → **Mount Device** → **Expander** to enter the page.

2. Click  to edit the parameters.
3. Select linked areas.
4. **Optional:** Enable **AUX** according to your needs. It will enable the auxiliary power output of the module. (Only for input expanders and output expanders.)
5. Click **Save**.

3.1.3 System Settings

Basic Information

Click **System** → **System Settings** → **Basic Information** to enter the page.

You can edit the device name and view model, serial No., version, number of zones and areas.

Time Settings

You can set the device time zone, synchronize device time, and set the DST time. The device supports time synchronization via Hik-Connect server.

Time Management

Click **System** → **System Settings** → **Time Management** to enter the page.

Device Time 2023-09-11 09:26:58

Time Zone

Time Synchronization mode NTP Manual

Set Time

You can select a time zone from the drop-down list.

You can synchronize the device time automatically with NTP. Check the check box of **NTP Time Sync.**, enter the server address and port No., and set the synchronization interval.

You can synchronize the device time manually. Or check **Sync. with Computer Time** to synchronize the device time with the computer time.

Note

While you synchronize the time manually or with the computer time, the system records the log “SDK Synchronization”.

DST Management

Click **System** → **System Settings** → **Time Management** to enter the Time Management page.

DST

Start Time

End Time

DST Bias 30Minute(s) 60Minute(s) 90Minute(s) 120Minute(s)

Save

You can enable the DST and set the DST bias, DST start time, and DST end time.

Option Management

Set the authority options.

Click **Configuration** → **Control Panel Option** → **Option Management** to enter the page.

Forced Arming

Forced Auto Arm

System Alarm Duration s

Audible Tamper Alarm

Polling Loss Times

Bypass On Re-Arm
The bypassed zone will back to arm if fault restored.
The system will not be compliant with the Europe EN50131-1 standard after you enable this configuration option.

Jamming Sensitivity Settings High Low Disable
The system will not be compliant with the Europe EN50131-1 standard after you enable this configuration option.

System Status Report

Motion Detector Restore Disable
 Immediate After Alarm
 After Disarm

Keypad logout min

Panel Lockup Button

Forced Arming

After enabled, when manual arming starts, if there are active faults in a zone, the zone will be automatically bypass.

You can use keyfobs, tags, and keypads to arm zones, or manually arm zones on APP. Single, multiple or all areas can be selected for arming.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are active faults in a zone, the zone will be automatically bypass.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

System Alarm Duration

Set the duration of the buzzer after the alarm is triggered.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm. Regardless of whether it is enabled or not, the tamper alarm will be normally pushed to Cloud (for APP) and ARC.

Polling Loss Times

Set the maximum number of times for polling loss of peripherals and detectors. The system will report fault if the time is over the limit. The status of these peripherals and detectors will be shown as offline.

Bypass on Re-Arm

While enabled, after the detector is bypassed, if its faults are restored and the linked area is armed, the detector will automatically arm.

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.

System Status Report

While enabled, system status will be uploaded and you can check the status.

Motion Detector Restore

Motion detectors include all PIR detectors.

-Disable: No automatic restore.

-Immediate After Alarm: Motion detectors automatically restores immediately after the alarm and reports to Cloud (for APP) and ARC.

-After Disarm: Motion detectors automatically restores after disarming and reports to Cloud (for APP) and ARC

Keypad Logout

After the keypad enters the programming page, if there is no key operation, it will exit the programming page after reaching this time.

Panel Lockup Button

All functions of AX HYBRID PRO will be frozen after it is enabled. This function can only be enabled by users with installer permission.

Fault Check

The fault check here is only for the control panel in the normal status.

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Click **Configuration** → **Control Panel Option** → **Panel Fault Check** to enter the page.

Type	Detected	Report Delay
IP Camera Disconnection	<input checked="" type="checkbox"/>	/
Panel Battery Fault Check	<input checked="" type="checkbox"/>	/
LAN Lost	<input checked="" type="checkbox"/>	180 <small>s</small> <input type="text"/>
Panel Mains Power Lost	<input checked="" type="checkbox"/>	20 <small>s</small> <input type="text"/>

Save

IP Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered.

Panel Battery Fault Check

If the option is enabled, when battery is disconnected or in low battery status, the device will upload events.

LAN Lost

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

LAN Lost Delay

The system checks the fault after the configured time duration after the wired network disconnect.

Panel Mains Power Lost

If the option is enabled, an alarm will be triggered when the control panel main supply is disconnected.

Panel Mains Power Loss Delay

The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

Arming Options

This function is for the whole alarm system, to inform the user of the current system status before arming. If it is enabled, there will be a fault prompt and confirmation process for keypads, keyfobs, and APP. If it is not enabled, there will be no fault detection before arming.

Click **Configuration** → **Control Panel Option** → **Arming Options** to enter the page.

Arming Detection

Fault Checklist when Arming

Detection Configuration During Arming

Type	Detected
Device Lid Opened	<input checked="" type="checkbox"/> Arm With Faults
Zone/Peripherals Polling Failure/Offline	<input type="checkbox"/> Arm With Faults
Zone/Peripherals Low Battery	<input checked="" type="checkbox"/> Arm With Faults
Zone Triggered/Fault	<input checked="" type="checkbox"/> Arm With Faults
Panel Mains Power Lost	<input checked="" type="checkbox"/> Arm With Faults
IP Camera Disconnection	<input checked="" type="checkbox"/> Arm With Faults
Panel Battery Fault Check	<input checked="" type="checkbox"/> Arm With Faults
LAN Lost	<input checked="" type="checkbox"/> Arm With Faults
ARC Connection Fault	<input checked="" type="checkbox"/> Arm With Faults
Jamming Check	<input checked="" type="checkbox"/> Arm With Faults
Wi-Fi Lost	<input checked="" type="checkbox"/> Arm With Faults
Cellular Lost	<input checked="" type="checkbox"/> Arm With Faults

Early Alarm

Enable

Early Alarm Time 30 s

You can set the following parameters:

Arm with Fault


Check the faults in the Arm with Fault list, and the device will not stop the arming process when faults occurred.

Fault Checklist when Arming


The system will check if the device has the faults in the checklist during the arming process.

Early Alarm

A delay zone is triggered first, and the area is in the "Entry Delay" stage. During the delay time period, an instant zone is triggered. At this time, the area enters the early alarm stage. There are control panel voice alarm and local sounder alarm, but no alarm message is pushed. If the zone is disarmed or silence before both the early alarm and entry delay end, the alarm message will not be reported. Otherwise, both the delayed zone and the instant zone will alarm.



OR



Regional Certification

Click **Configuration** → **Control Panel Option** → **Regional Certification** to enter the page.

Enable

PD6662 is applicable to the UK market. If this function is enabled, the arming function and alarm logic of the control panel will change.

Communication Fault Sending Delay s

The configuration is for the delay time while the ATP communication fault reports to ARC.
PD6662 configuration

Save

Enable PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Communication Fault Sending Delay

Set the delay time while the ATP communication fault reports to ARC.

3.1.4 Communication Settings

Wired Network


You can set the device IP address and other network parameters.

Steps



Functions varied depending on the model of the device.

1. Click **Network** → **Network Settings** → **TCP/IP** to enter the page.



The screenshot shows a network configuration interface. At the top, there is a 'DHCP' toggle switch which is currently turned off. Below it are several input fields: '* IPv4 Address', '* Subnet Mask', and '* IPv4 Default Gateway'. Further down is a 'MAC Address' field. A section titled 'DNS Server' contains two more input fields: '* Preferred DNS Server' and '* Alternate DNS Server'. At the bottom center, there is a red 'Save' button.

2. Set the parameters.
 - Automatic Settings: Enable **DHCP**.
 - Manual Settings: Disabled **DHCP** and set **IPv4 Address, Subnet Mask, IPv4 Default Gateway, DNS Server Address**.
3. **Optional**: Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
4. Click **Save**.

HTTP

Steps

1. Click **Network** → **Network Service** → **HTTP(S)** to enter the page.
2. Set the HTTP port.
3. Click **Save** to complete the settings.


NAT

Universal Plug and Play (UPnP™) is a networking architecture that provides compatibility among networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps

4. Click **Network** → **Network Service** → **NAT** to enter the page.



The screenshot shows the NAT configuration interface. At the top, there is a toggle switch for 'Enable UPnP™' which is turned on. Below it is a dropdown menu for 'Port Mapping Mode' set to 'Auto'. A table titled 'Port Mapping List' contains two rows of port mappings. Below the table is a red 'Save' button.

Port Mapping List	Port Type	External Port	External IP Address	Internal Port	UPnP Status
	HTTP	80	0.0.0.0	80	Inoperative
	Server Port	8000	0.0.0.0	8000	Inoperative

2. Drag the slider to enable UPnP.

3. **Optional:** Select the port mapping mode as **Manual** and set the HTTP port and the service port.

4. Click **Save** to complete the settings

Cloud Service

If you want to register the device to the mobile client for remote configuration, you should set the mobile client registration parameters.

Before You Start

- Connect the device to the network via wired connection, dial-up connection, or Wi-Fi connection.
- Set the device IP address, subnet mask, gateway and DNS server in the LAN.

Steps

1. Click **Network** → **Device Access** → **Cloud Service** to enter the page.


Enable

The Hik-Connect service will require internet access. Please read the "[Terms of Service](#)" and "[Privacy Policy](#)" before enabling the service.


Hik-Connect Connection Status ✔ Online [Refresh](#)

Server Address

Custom

*Verification Code 

The code should contain 6 to 12 characters (it is recommended to be more than 8 characters and the combination of numeric and letter).

Network Mode 

Network Priority: LAN > Wi-Fi > Cellular Network

Periodic Test

*Periodic Test Interval s

2. Drag the slider to enable Hik-Connect service.

 **Note**

By default, the device Hik-Connect service is enabled.

You can view the device status in the Hik-Connect server (www.hik-connect.com).

3. You can view the Hik-Connect connection status, and click **Refresh** to view the latest status.
4. Enable **Custom Server Address**.
The server address is already displayed in the Server Address text box.
4. Select a network mode from the drop-down list according to the actual device communication method.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Auto

The system will select communication mode automatically.

5. Optional: Change the verification code.
-

 **Note**

- By default, the verification code is displayed in the text box.
- The verification code should contain 6 to 12 letters or digits. For security reasons, an 8-character password is suggested, which containing two or more of the following character

types: uppercases, lowercases, and digits.

6. Enable **Periodic Test**. Enter the periodic test interval.
7. Click **Save**.

Alarm Center

You can set the alarm center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. Click **Alarm Communication** → **Alarm Receiving Center** to enter the page.
2. Drag the slider to enable the selected alarm receiver center.
3. Select the connection type as **IP**, and select the **Protocol Type** as **ADM-CID**, **ISUP**, **SIA-DCS**, ***SIA-DCS**, ***ADM-CID**, or **CSV-IP** to set uploading mode.

Alarm Receiving Center 1 2 3 4

Enable

Connection Type IP serialPort

Protocol Type

GMT

Address Type(Alarm Receiver Server) IP Domain Name

*Server Address(Alarm Receiver S...

*Port No.(Alarm Receiver Server)

*Account Code

Transmission Mode

Impulse Counting Time s

Attempts

Enable Heartbeat Cycle

Polling Rate s

Periodic Test

Period Test Interval s

Companies None
 Hungary-Multi Alarm Receiving Company
 French Alarm Receiving Company

Intruder Verification as a Service

 **Note**

Standard DC-09 Protocol

ADM-CID: The data presenting method of DC-09 is CID, which is not encrypted and only for uploading alarm report.

*ADM-CID: The data presenting method of DC-09 is CID, which is encrypted and only for uploading alarm report.

SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is not encrypted and only for uploading alarm report.

*SIA-DCS: The data presenting method of DC-09 is DCS (also called SIA protocol), which is encrypted and only for uploading alarm report.

ADM-CID or SIA-DCS: You should select the **Address Type** as **IP** or **Domain name**, and enter the Server address, port number, account code, impulse counting time, attempts, polling rate, etc.

 **Note**

Set the polling rate with the range from 10 to 3888000 seconds.

ISUP, CSV-IP: You do not need to set the protocol parameters.

***SIA-DCS** or ***ADM-CID** You should select the **Address Type** as **IP** or **Domain name**, and enter the IP address, port number, account code, impulse counting time, attempts, polling rate, encryption arithmetic, password length, etc.

 **Note**

Set the polling rate with the range from 10 to 3888000 seconds.

ADM-CID, SIA-DCS, *SIA-DCS, *ADM-CID, CSV-IP: You can enable **Intruder Verification as a Service**.

 **Note**

When enabled, the SDK returns the URL address of the video storage after the PIRCAM composite video is uploaded to the cloud. The control panel will add this URL in the additional field when reporting the intruder verification to ARC. After receiving the URL, ARC can download the video.

The alarm video can be stored in the cloud for up to 7 days.

You can select companies. When you select it as **French Alarm Receiving Company**, set PIRCAM picture upload mode as video or picture. Set HTTP data transmission parameters, and click **Test** to ensure the service is available. Click **Restore Default** to restore the parameters to the default value.

4. Select the connection type as **serialPort**, and select the **Protocol Type** to set uploading mode.

Alarm Receiving Center 1 2 3 4

Enable

Connection Type IP serialPort

Protocol Type

Note

FSK Module: The control panel communicates with the third-party modules through the reserved serial port. You can select **Baud Rate**, **Data Bits**, **Parity** and **Stop Bits**. When FSK is uploaded, it will convert to the ADM-CID format.

Only one center of the serial port in the ARC can be configured with FSK or RDC, and the center cannot be used as a standby channel.

5. Click **Save**.

Notification Push

When an alarm is triggered, if you want to send the alarm notification to the client, alarm center, cloud or mobile phone, you can set the notification push parameters.

Steps

1. Click **Alarm Communication** → **Event Notification**.

Push Event Type	Event Type	Enable
	Zone Alarm	<input checked="" type="checkbox"/>
	Peripherals Lid Opened	<input checked="" type="checkbox"/>
	Panel Lid Opened	<input checked="" type="checkbox"/>
	Panic Alarm	<input checked="" type="checkbox"/>
	Medical Alarm	<input checked="" type="checkbox"/>
	Fire Alarm	<input checked="" type="checkbox"/>
	Gas Alarm	<input checked="" type="checkbox"/>
	Panel Status	<input checked="" type="checkbox"/>
	Zone Status	<input checked="" type="checkbox"/>
	Peripherals Status	<input checked="" type="checkbox"/>
	Panel Operation	<input checked="" type="checkbox"/>
	Smart Alarm Event ⓘ	<input checked="" type="checkbox"/>

Save

2. Enable the target notification.

Zone Alarm

The device will push notifications when the zone alarm (on web client, software client or mobile client) is triggered or the zone peripherals alarm is triggered or restored.

Peripherals Lid Opened

The device will push notifications when lid opened alarm of any peripheral is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened alarm of the control panel is triggered or restored.

Panic Alarm

The device will push notifications when panic alarm on keypads or keyfobs is triggered or restored.

Medical Alarm

The device will push notifications when medical alarm on keypads is triggered.

Fire Alarm

The device will push notifications when fire alarm on keypads is triggered or a user presses the fire alarm key on the keypad.

Gas Alarm

The device will push notifications when gas alarm on keypads is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when any zone status is changed.

Peripherals Status

The device will push notifications when any peripheral status is changed.

Panel Operation

The device will push notifications when the user operate the control panel.

Smart Alarm Event

The device will push notifications when alarm is triggered in network cameras.

3. **Optional:** For **Alarm Receiving Center**, you need to select center number before settings.
4. **Optional:** If you want to send the alarm notifications to the mobile client, you should set **APP** parameters.

Notification by Email

You can send the alarm video or event to the configured email.

Steps

1. Click **Alarm Communication** → **Notification by Email** to enter the page.

Enable

When enabled, event video will be emailed to this mailbox.

Sender Name

Sender's Address

SMTP Server Address

SMTP Port

Encryption Type None SSL TLS

Server Authentication

User Name

Password

Confirm Password

Receiver Name

Recipient Address

2. Enable **Video Verification Events** and **Server Authentication**.
3. Enter the sender's information.

Note

It is recommended to use Gmail and Hotmail for sending mails.
Only if the zone is linked with a network camera, the alarm email will be attached with alarm video.

4. Enter the receiver's information.
5. Select the encryption type.
6. Click **Receiver Address Test** and make sure the address is correct.
7. Click **Save**.

FTP

You can configure the FTP server to save alarm video.

Steps

1. Click **Alarm Communication** → **FTP** to enter the page.

FTP Type Main FTP Standby FTP

Enable FTP

Protocol Type FTP SFTP

Server Type IP Domain Name

* Server Address

* Port

Enable Anonymity

* User Name

* Password

* Confirm Password

Directory Structure Save in the root directory
 Save in the parent directory
 Save in the child directory

2. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.

Server Type

IP and Domain Name are selectable. Set corresponding FTP server address or domain name, and set port number.

User Name and Password

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can drag the slide to **Enable Anonymity** to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server.

3.1.5 Maintenance

Maintenance and Upgrade

Reboot device, upgrade device version and restore device parameters.


Reboot Device

Click **Maintenance and Security** → **Maintenance** → **Restart**.

Click **Restart** to restart the device.

Upgrade

Click **Maintenance and Security** → **Maintenance** → **Control Panel Upgrade**.

Click  and select the upgrade file from your local PC. Click **Upgrade** to start upgrading.

Click **Maintenance and Security** → **Maintenance** → **Detector & Peripheral Upgrade**.

Select upgrade type and peripheral, Click  and select the upgrade file from your local PC.

Click **Upgrade** to start upgrading.



Do not power off during the upgrading.

Restore Parameters

Click **Maintenance and Security** → **Maintenance** → **Backup and Reset**.

Click **Default**, the device will restore to the default settings, except for the network parameters and the user information.

Click **Restore All**, all parameters will be restored to the factory settings. You should activate the device before usage.

Import and Export Parameters

Click **Maintenance and Security** → **Maintenance** → **Backup and Reset**.


Click **Export** to export the device parameters.

Click  and select the file to import. Click **Import** to start import configuration file.

Local Log Search

You can search the log on the device.

Click **Maintenance and Security** → **Maintenance** → **Log** to enter the page.




No logs. Search first.

Select a primary event and a secondary event from the drop-down list, set the log start time and end time and click **Search**. All filtered log information will be displayed in the list.


You can also click **Reset** to reset all search conditions.

Security Audit Log

You can add the Security Audit Server to the system. The device will upload web logs to the server.


Steps

1. Click **Maintenance and Security** → **Maintenance** → **Security Audit Log** to enter the page.



2. Drag the slider to **Enable Log Upload Server**.

3. Enter log server IP and port.

4. Click  to select a certificate.

Note

Formats include ca.crt、ca-chan.crt、private.txt are allowed.

5. Click **Import**.

6. Click **Save**.

Test

The AX HYBRID PRO supports walk test function.

Steps

1. Click **Maintenance and Security** → **Maintenance** → **Walk Test** to enter the page.

Enable

Test Mode

Zone No.	Zone Name	Test Result
1	Zone 1	Invalid zone.
2	Zone 2	Invalid zone.
3	Zone 3	Invalid zone.

Note

Only when all the detectors are without fault, you can enter the mode TEST mode.

2. Drag the slider to start walk test.
3. Click **Save** to complete the settings.
4. Trigger the detector in each zone.
5. Check the test result. Click **Refresh** to view the latest status.

Device Debugging

You can set device debugging parameters.

Steps

1. Click **Maintenance and Security** → **Maintenance** → **Device Debugging** to enter the page.

SSH

Enable SSH

Debug Log

Debugging Log

File Format

HPP Login

Tamper Alarm on HPP Login

If enabled, when logging in to HPP, the system will give an alarm when the device tamper is triggered.

2. You can set the following parameters.

Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

Debug Log

You can click **Export** to export log.

HPP Login

If enabled, when logging in to HPP, the system will give an alarm when the device tamper is triggered.

3.1.6 Security

Locking User Settings

The device will be locked 90 s after 3 failed credential attempts (can be set in Retry Time before Auto-Lock) in a minute.

You can view the locked user or unlock a user and set the user locked duration.




Note

To compliant the EN requirement, the system will only record the same log 3 times continuously.

Steps

1. Click **Maintenance and Security** → **Security** → **User Lockout Attempts** to enter the Locking User Settings page.



The screenshot shows the 'Locking User Settings' page. At the top, there are two input fields: 'Retry Times Before Auto-lock' with a value of 3 and 'Auto-lock Time' with a value of 1800. Below these fields is a red 'Save' button. Underneath the 'Save' button is a section titled 'Locked User List'. This section contains a table with columns for 'No.', 'IP Address', and 'Unlock'. The table is currently empty, displaying 'No data.' in the center.

2. Set the following parameters.

Retry Times Before Auto-Lock

If the user continuously input the incorrect password for more than the configured times, the account will be locked.

Note

The administrator has two more attempts than the configured value.

Auto-lock Time

Set the locking duration when the account is locked.

Note

The available locking duration is 5s to 1800s.


3. Click  to unlock the account or click **Unlock All** to unlock all locked users in the list.
4. Click **Save**.


Module Lock Settings

Set the module locking parameters, including the Max Failure Attempts, and locked duration. The module will be locked for the programmed time duration, once the module authentication has failed for the amount of configured times.

Steps

1. Click **Maintenance and Security** → **Security** → **Module Locking Settings** to enter the Module Lock Settings page.



2. Select a module from the list, and click the  icon.
3. Set the following parameters of the selected module.

Retry Times before Auto-Lock

If a user continuously tries to authentication a password for more than the configured attempts permitted, the keypad will be locked for the programmed duration.

Auto-lock Time

Set the locking duration when the keypad is locked. After the configured duration, the keypad will be unlocked.

4. Click **OK**.
5. Optional: Click  to unlock the locked module. Click **Refresh** to view the latest user status.

3.2 Set-up with Hik-Partner Pro

The installer can use the Hik-Partner Pro to configure the AX HYBRID PRO, such as activation, device enrollment etc.

3.2.1 Download and Login the Hik-Partner Pro

Download the Hik-Partner Pro mobile client and login the client before operating the AX HYBRID PRO.

Steps

1. Download Hik-Partner Pro mobile client.
2. Optional: Register a new account if it is the first time you use the Hik-Partner Pro mobile client.

Note

- For details, see *User Manual of Hik-Partner Pro Mobile Client*.
 - You need an invitation code for registration. Please ask technical supports.
-

3. Run and login the client.

3.2.2 Add AX HYBRID PRO to the Mobile Client

Add AX HYBRID PRO to the mobile client before other operations.

Steps

1. Power on the AX HYBRID PRO.
2. Create or search a site.
 - Tap **+**, set site name, time zone, address, city, state/province/region and tap **OK** to create a site.
 - Enter site name in the search area and tap **Search Icon** to search a site.
3. Tap **Add Device**.
 - Tap **Scan QR Code** to enter the Scan QR code page. Scan the QR code on the AX HYBRID PRO.

Note

Normally, the QR code is printed on the label stuck on the back cover of the AX HYBRID PRO.

Tap **Manual Adding** to enter the Add Device page. Enter the device serial No. and verification code to add the device.

4. Activate the **Device**.

3.2.3 Add Peripheral to the AX HYBRID PRO

Add peripheral to the AX HYBRID PRO.

Steps

1. Select a control device (AX HYBRID PRO).
2. Tap +.


Scan Bus Device

- Select scan mode. Continuous scan means adding devices from a continuous address range. You can set the minimum and maximum range of the address. Discrete Scan means adding devices from several discrete addresses. You can tick several discrete address.
- Tap **Scan**. Tick devices in the bus device list, and Tap **Add**.

Add Wired Device

- Enter the device serial No. and select the channel No. to add the device.


Add Wireless Device

- Scan the QR code on the peripheral.
- Tap  to enter the Manually Input page. Enter the device serial No. and select the device type to add the device.

3.2.4 Main Page

You can view faults, arm and disarm areas, view device status, etc.

On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.



Enable Alarm

Tap  to select **Audible Panic Alarm** or **Silent Panic Alarm**.

View Faults

Tap  to view faults.

Area Management

Tap + to add an area.


Tap Area to enter the area management page. Refers to **3.2.15 Set Arming/Disarming Schedule** for details.



Arm/Disarm the Area

Arm or disarm the area manually as you desired.


On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the Area page.






Operations for a Single Area



- **Away Arming:** Tap  to away arm a single area. When all people in the detection area leave, turn on the away mode to arm all zones in all areas after the defined dwell time.
- **Stay Arming:** Tap  to stay arm a single area. When all people stays inside the detection area, turn on the stay mode to enable all perimeter theft detection set in all zones of all areas.


Operations for Multiple Areas




- **Select Areas:** Tap  to select areas you want to operate. If you do not select areas, following operations will take effect for all areas.
- **Away Arming:** Tap  to away arm a single area. When all people in the detection area leave, turn on the away mode to arm all zones in all areas after the defined dwell time.
- **Stay Arming:** Tap  to stay arm all areas. When people stays inside the detection area, turn on the stay mode to enable all perimeter theft detection (such as perimeter detector, magnetic contacts, and curtain detector in the balcony) set in all zones of all areas. At the meantime, the detectors inside the detection area are bypassed (such as PIR detectors). People can move inside the area and alarm will not be triggered.
- **Disarming:** Tap  to disarm all areas. In disarm mode, all zones of all areas will not trigger alarm, no matter alarm events happen or not.
- **Silent Alarm:** Tap  to silent alarms for all areas.

3.2.5 Zone Management

1. Tap **Device** to view linked zones.



2. Tap + to add a new zone.
3. Tap a zone to enter the management page. You can view device status (e.g. temperature, battery status, signal strength, etc.).
4. Tap  on the upper right corner to enter the zone settings page.
5. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

-Exit Delay: Exit Delay provides you time to leave through the zone without alarm.

Arm with faults is enabled: You should confirm faults first, and then the zone is in arming process. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered and the zone will be armed.

Arm with faults is disabled: Immediately armed. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered.

-Entry Delay: Entry Delay provides you time to enter the zone to disarm the system without alarm.

After triggering, if the zone is not disarmed or silenced before the entry delay time ends, the zone will alarm.

-Stay Arm Delay Time: Stay arming uses Stay Arm Delay Time to count down.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keypad for users.

 **Note**

- You can set 2 different time durations in **System Options** → **Schedule & Timer**.
 - Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
 - You can set Stay Arm Delay Time for the delay zone.
-

Panic Zone

24-hour active zone, whether armed or not. Report panic alarm after triggering. It is usually used in the sites equipped with panic button, smoke detector and glass-break detector.

Medical Alarm

24-hour active zone, whether armed or not. Report medical alarm after triggering.

Fire Zone

24-hour active zone, whether armed or not. Report fire alarm after triggering.

Gas Zone

24-hour active zone, whether armed or not. Report gas alarm after triggering.

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

Keyswitch Zone

-**By Trigger Time:** Change the arming and disarming status after each trigger. For example, in the disarmed status, if the zone is triggered, the linked area will be armed. Trigger the zone again and the area will be disarmed.

-**By Zone Status:** You need to choose to arm or disarm the linked area after the zone is triggered.

In the case of the tampering alarm, the arming and disarming operation will not be triggered.

Disabled Zone

Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-hour Zone

The zone activates all the time with sound/light output when alarm occurs, whether it is armed or not. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. When this zone has been triggered or restored and exceeds the set time, an alarm will be generated.

It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

-**Not-Triggered Zone Alarm:** If the zone is not triggered for the set time, it will alarm.

-**Alarm on Zone Activated:** If the zone is triggered for the set time, it will alarm.

-**Retry Time Period:** Set the timeout period.

7. Enable other functions according to your detector types and actual needs.

Note

The configurable functions vary in different detectors and zones. Refer to the actual zone to set the function.

Arm Mode

If the zone is a public zone (the zone belongs to more than one areas), you can set arm mode.

And: When all linked areas are armed, the zone will arm. When any of linked areas is disarmed, the zone will disarm.

Or: When any of the linked areas is armed, the zone will arm. When all linked areas are disarmed, the zone will disarm. When the zone is in alarm, the disarmed areas linked with the zone cannot be armed.

Stay Arm Bypass

The zone will be automatically bypassed in stay arming.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.

If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.

Forbid Bypass on Arming

After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or continuously in a period of time, the alarm will be triggered.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

Final Door Exit

Only magnetic contacts have this option.

After enabling, when the user use keypads or tags to arm:

- Arm With Faults is enabled: During the arming countdown, if the magnetic contact is triggered and then restored, the arming process will be terminated immediately after restoring, and the arming is completed.
- Arm With Faults is disabled: If the magnetic contact is triggered and then restored, the linked area immediately arms the delayed zone.

Dual Zone

After enabled, when multi transmitter detects that the entire zone circuit of the local zone and the extended zone is open circuit, both zones trigger lid opened alarms.

Timer With Restart

During the Exit Delay process, the exit delay time will be re-timed at the time when the second delay zone was triggered.

3.2.6 User Management

The installers (user of Hik-Partner Pro) can manage users. If you are the administrator, you can add, edit, and delete users, and assign different permissions to the newly-added users.

Steps

Note

There are four types of users for the AX HYBRID PRO, including administrator (or owner), operator, and installer (or setter). Different types of users have different permissions for accessing the functionality of the AX HYBRID PRO.

1. Enter the site, tap the AX HYBRID PRO and then log in to the device (if required) to enter the AX HYBRID PRO page.
 2. Tap **Next** to invite the user.
-

Note

The recipient need to accept the invitation.

3. Tap  → **User Management** → **User**.
4. Tap a user to enter the User Management page.

5. Optional: Perform the following operations if required.

User Permission You can tap the target user on the user list and then tap **Edit Icon** to set the permissions authorized to the target user.

 **Note**

Only the administrator can do such an operation.

Set Linked Areas If the target user is an operator, tap the target user on the user list and then tap **Linked Areas** to set the area linked to the target user.

 **Note**

Only the administrator can do such an operation.

Change Keypad Password If the target user is an administrator, an installer, or an operator, you can tap the target user on the user list and then tap **Change Keypad Password** to set the keypad password to the target user.

Change Duress Password If the target user is an administrator or an operator, you can tap the target user on the user list and then tap **Change Duress Password** to set the duress password to the target user.

 **Note**

If under duress, you can enter the duress code on the keyboard to arm and disarm area(s) and upload a duress alarm.

Automation Control An administrator, an installer or an operator can control the relay module, wall switch and smart plug.

 **Note**

- Configuration items and user permission will vary according to the user type.
 - You can view linked cards/tags and keyfobs of the user but you do not have permission to configure them.
 - You can only change your own keypad password.
-

3.2.7 Card/Tag Management


After adding cards/tags to the wireless AX HYBRID PRO, you can swipe the card/tag to arm or

disarm all the detectors added to specific area(s) of the AX HYBRID PRO, and silence alarms.

 **Note**

The tag ID/PIN is a 32 bit long integer, and the variant could be 42949672956.

Steps

1. Enter the site, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
 2. Tap  → **User Management** → **Card/Tag** to enter the Card/Tag page.
 3. Tap **+** to add a tag.
 4. When hearing the voice prompt "Swipe Tag", you should present the tag on the AX HYBRID PRO tag presenting area.
 - When hearing a beep sound, the tag is recognized.
 - The tag will be displayed on the tag page.
 5. Optional: Tap a Tag to enter the Setting Page.
 6. Tap **Edit Icon** to edit the Tag name.
-

 **Note**

- If you log in as an installer, skip this step. Editing tag name is only available to administrator.
 - The name should contain 1 to 32 characters.
-

7. Slide **Enable Tag**.
 8. Select a linked user.
 9. Select the tag type
-

 **Note**

Different linked users have different tag permissions.

Operation Tag

You can swipe the tag to arm or disarm.

Patrol Tag


When you swipe the tag, the system will upload a record.

10. Optional: Tap **Delete** to delete the tag.

3.2.8 Device Information

You can change language and select time zone.


Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **Configuration** to enter the page.

3. Select device language and time zone.

3.2.9 System Management

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **System Management** to enter the page.

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are active faults in a zone, the zone will be automatically bypass.

You can go to **System** → **System Options** → **Schedule & Time** to set the auto arming/disarming schedule and linked areas.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

Forced Arming

After enabled, when manual arming starts, if there are active faults in a zone, the zone will be automatically bypass.

You can use keyfobs, tags, and keypads to arm zones, or manually arm zones on APP. Single, multiple or all areas can be selected for arming.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

System Status report

If the option is enabled, the device will upload report to Cloud (for APP) and ARC automatically when the AX HYBRID PRO status is changed.

Voice Prompt

If the option is enabled, the AX HYBRID PRO will enable the voice prompt.

- Fault Prompts on Arming: Voice prompt of faults when arming.
- Fault Prompts When Armed: Voice prompt of faults when the system is armed.
- Fault Prompts on Disarming: Voice prompt of faults when disarming
- Fault Prompts When Disarmed: Voice prompt of faults when the system is disarmed.
- Voice Prompts on Alarm: Voice prompt of faults when an alarm is triggered.

System Volume

The available system volume range is from 0 to 10.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm. Regardless of whether it is enabled or not, the tamper alarm will be normally pushed to Cloud (for APP) and ARC.

Panel Lockup Button

All functions of AX HYBRID PRO will be frozen after it is enabled. This function can only be enabled by users with installer permission.

Alarm Duration

Set linked alarm voice prompt lasting time.

Wireless Supervision Loss

Detectors and peripherals whose heartbeat loss times exceed the set value will be shown as offline.

Bypass on Re-Arm

While enabled, after the detector is bypassed, if its faults are restored and the linked area is armed, the detector will automatically arm.

Motion Detector Restore

Motion detectors include all PIR detectors.

-Disable: No automatic restore.

-Immediate After Alarm: Motion detectors automatically restores immediately after the alarm and reports to Cloud (for APP) and ARC.

-After Disarm: Motion detectors automatically restores after disarming and reports to Cloud (for APP) and ARC

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.

Enable PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Keypad Logout

After the keypad enters the programming page, if there is no key operation, it will exit the programming page after reaching this time.


3.2.10 Fault Check

The fault check here is only for the control panel in the normal status.

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.

2. Tap  → **System** → **System Options** → **System Fault Check** to enter the page.

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered. The delay time of network camera disconnection detection is the same as that of LAN.

Panel Battery Fault Check

If the option is enabled, when panel battery is disconnected or in low battery status, the device will upload events.

LAN Lost

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

WiFi Lost

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Lost

If the option is enabled, when the cellular data network is disconnected or with other faults, the alarm will be triggered.

Panel Mains Power Lost

If the option is enabled, an alarm will be triggered when the control panel main supply is disconnected.


Panel Mains Power Loss Delay

The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

3.2.11 Arm Options

This function is for the whole alarm system, to inform the user of the current system status before arming. If it is enabled, there will be a fault prompt and confirmation process for keypads, keyfobs, and APP. If it is not enabled, there will be no fault detection before arming.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **Arm Options** to enter the page.


You can set the following parameters:

Arm with Fault


Check the faults in the Enable Arming with Fault list, and the device will not stop the arming procedure when faults occurred.

Early Alarm

A delay zone is triggered first, and the area is in the "Entry Delay" stage. During the delay time period, an instant zone is triggered (only for the first triggered instant zone). At this time, the area enters the early alarm stage. There are control panel voice alarm and local sounder alarm, but no alarm message is pushed. If the zone is disarmed or silence before both the early alarm and entry delay end, the alarm message will not be reported. Otherwise, both the delayed zone and the instant zone will alarm.




OR



3. Tap **Save**.

3.2.12 Enrollment Mode


Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **Enrollment Mode** to enter the page.
3. Tap **Enter the Enrollment Mode**. You can enroll the peripheral by triggering it.

3.2.13 Network Camera

Add Cameras to the AX HYBRID PRO


Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Network Camera** → **Network Camera Channel** to enter the page.
3. Tap **Add Channel**.

4. Enter IP address, port, the user name and password of the camera.
5. Tap **Save Icon**.
6. Optional: tap **Edit** or **Delete** to edit or delete the selected camera.

3.2.14 Set Video Parameters

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Network Camera** → **Event Video Settings** to enter the page.
3. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality.

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output.

Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.

Before Alarm


The recording time length before the alarm.

After Alarm

The recording time length after the alarm.

3.2.15 Set Arming/Disarming Schedule

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **Area** to enter the page.
3. Tap an area in the list, enable the area and select linked devices.
4. Set parameters:

Auto Arm

Enable the area to automatically arm itself in a specific time point.

Auto Arm Time

Set the schedule for the area to automatically arm itself.

Auto Disarm

Enable the area to automatically disarm itself in a specific time point.

Auto Disarm Time

Set the schedule for the area to automatically disarm itself.

Auto Arming Sound Prompt

After disabled, the buzzer will not beep before auto arming.

Late to Disarm

Enable the device to push a notification to the phone or tablet to remind the user to disarm the area when the area is still armed after a specific time point.



You should enable the Panel Management Notification function on the Web Client of **Communication Parameters** → **Event Communication** before enabling the Late to Disarm function.

Late to Disarm Time

Set the time point mentioned in **Late to Disarm**.

Weekend Exception

If enabled, **Auto Arm**, **Auto Disarm**, and **Late to Disarm** are disabled on the weekend.

Holiday Excepted

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling.




Up to 6 holiday groups can be set.

3.2.16 Communication

Wired Network


Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Wired Network** to enter the page.
3. Set the parameters.
 - Automatic Settings: Enable **DHCP** and set the HTTP port.
 - Manual Settings: Disabled **DHCP** and set **IP Address**, **Subnet Mask**, **Gateway Address**, **DNS Server Address**.

4. **Optional:** Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
5. Click **Save**.


Wi-Fi Configuration

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Wi-Fi Configuration** to enter the page.
3. Tap a Wi-Fi to connect in the list.

Cellular Data Network

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Cellular Data Network Settings** to enter the page.
3. Enable **Cellular Data Network**.
4. Tap to select a SIM card. Tap **Parameter Configuration** → **Edit Icon** and set parameters including the user name, access password, APN, MTU and PIN code.
5. Tap **Save Icon**.
6. Enable **Data Usage Limit**.
7. Edit **Data Used This Month** and **Data Limited per Month**.

Access Number

Input the operator dialing number.

Note

Only the private network SIM card user needs to enter the access number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Limited per Month

You can enable the function and set the data threshold every month. If data usage is more than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.


Data Used This Month

The used data will be accumulated and displayed in this text box.

Push Notifications

When an alarm is triggered, if you want to send the alarm notification to the mobile phone, you can set the notification push parameters.

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Push Notification(s)** to enter the page.
3. Enable the target notification.

Zone Alarm/Lid Opened

The device will push notifications when the zone alarm is triggered or the zone lid opened is triggered or restored.

Note

You need to set event filtering interval time for phone calling.

Peripherals Lid Opened

The device will push notifications when lid opened of any peripherals is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened of the control panel is triggered or restored.

Panic Alarm

The device will push notifications when panic alarm is triggered or restored by zones, keypads or keyfobs.

Medical Alarm

The device will push notifications when medical alarm is triggered.

Fire Alarm

The device will push notifications when fire alarm is triggered.

Gas Alarm

The device will push notifications when gas alarm is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when the zone status is changed.

Peripherals Status

The device will push notifications when any peripheral status is changed.

Panel Operation

The device will push notifications when the user operates the AX HYBRID PRO.

Smart Alarm Event

The device will push notifications when the alarm is triggered in thermal cameras.

4. Tap **Phone Call and SMS**.
5. Tap **+ Add Phone Number** to enter the phone number.
6. Tap the added phone number to enable **Phone Call and SMS** according to your need.
(For Phone Call) Set Numbers of Calling.
(For SMS) Set Arming Permission, Disarming Permission and Alarm Clearing Permission for areas.

Common Message

You can enter message content. When the alarm is triggered, your customized content will be added at the beginning of the message sent by the system.

Common Voice

You can import a new audio. When the alarm is triggered, your customized voice will be added at the beginning of the content of the phone dialed by the system. You can also tap Clear to delete audios




Only WAV format is supported, up to 512 KB and 15 s.

7. Check notifications.

Alarm Receiving Center (ARC)

You can set the alarm receiving center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Alarm Receiving Center (ARC)** to enter the page.
3. Select an ARC and enable it.

Connection Type

Select the Connection Type as IP, serialPort or PSTN to set connection mode.

Protocol Type

Select the Protocol Type as ADM-CID, ISUP, SIA-DCS, *SIA-DCS, *ADM-CID, CSV-IP, FSK Module, RDC Module, PSTN-CID, RDC Module-CID or FSK Module-CID to set uploading mode.

GMT

Enable the Greenwich Mean Time.

Address Type

Select the Address Type as IP Address and Domain Name. Enter server address/domain name, port number and account code.

Transmission Mode

Select the Transmission Mode as TCP or UDP. UDP is recommended by the SIA DC-09 standard.

Impulse Counting Time

After the selected time, the system will retry to transmit.

Attempts

Set the number of retry attempts.

Polling Option

Set the polling rate with the range from 10 to 3888000 seconds. The system will report fault if the time is over the limit. The status of device will be shown as offline.

Periodic Test

After enabling, you can set the time interval, setting how often to send a test event to the ARC to ensure the connection.

Companies


Select the support company as None, Hungary-Multi Alarm Receiving Company or French Alarm Receiving Company.

Intruder Verification as a Service

The SDK returns the URL address of the video storage after the PIRCAM composite video is uploaded to the cloud. The control panel will add this URL in the additional field when reporting the intruder verification to ARC. After receiving the URL, ARC can download the video. The alarm video can be stored in the cloud for up to 7 days.

Cloud Service Settings

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Cloud Service Settings** to enter the page.
3. Select the **Communication Mode**.

Auto

The system will select the communication mode automatically according to the sequence of, wired network, Wi-Fi network, and cellular data network. Only when the current network is disconnected, will the device connect to other network.

Wired Network & Wi-Fi Priority

The connection priority order from high to low is: wired network, Wi-Fi, cellular data network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

4. Enable **Periodic Test**. Enter the periodic test interval.


Periodic Test

After enabling, you can set the time interval, setting how often to send a test event to the ARC to ensure the connection.

5. Tap **Save**.

Notification by Email

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Notification by Emails** to enter the page.
3. Enable **Email 1**.
4. Enter the sender name, sender email address, SMTP server address, SMTP port, user name and password.



Note


It is recommended to use Gmail and Hotmail for sending mails.

Only if the zone is linked with a network camera, the alarm email will be attached with alarm video.

5. Select the encryption type as **None**, **SSL** or **TLS**.
6. Enable **Server Authentication**.
7. Enter receiver name and receiver email address. Tap **Test Receiver Email Address** to test whether the email address is correct.
8. Tap **Save**.

FTP Settings

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **FTP Settings** to enter the page.
3. Select **Preferred FTP** or **Alternated FTP**, and enable FTP.

4. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.

Server Address and Port

The FTP server address and corresponding port.

User Name & Password/Anonymity

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can enable Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server.


4. Tap **Save**.

NAT

Universal Plug and Play (UPnP™) is a networking architecture that provides compatibility among networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.


Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **NAT** to enter the page.
3. Drag the slider to enable UPnP.
4. **Optional**: Select the mapping type as **Manual** to set the HTTP port and the service port.
5. Click **Save** to complete the settings.


3.2.17 Device Maintenance

Walk Test

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Maintenance** → **Device Maintenance** to enter the maintenance page.
3. Tap **Test**, and tap **Start Walk Test** to test the whether the device works properly or not.

Maintenance

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Maintenance** → **Maintenance**.

Tamper Alarm on HPP Login

If enabled, an alarm will be triggered when the device is tampered after you log in to HPP.

Reboot Device



The AX HYBRID PRO will reboot.

Log

View device logs.


Device Upgrade

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Maintenance** → **Device Upgrade** to upgrade the control panel, or tap  → **Maintenance** → **Detector & Peripheral Upgrade** to upgrade detectors and peripherals.

Remote Log Collection

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Maintenance** → **Remote Log Collection** to enable the function.

Remote Log Collection is for getting logs relating to the device. When this is enabled, our technical support will be able to collect logs relating to the device remotely and upload them to our server for troubleshooting. You can set the validity period according to actual needs. This function will be disabled after the set validity period.

3.3 Set-up with Hik-Connect

The operator can use the Hik-Connect to control the device, such as general arming/disarming operation, and user management etc.

3.3.1 Download and Login the Mobile Client

Download the Hik-Connect mobile client and login the client before operating the AX HYBRID PRO.

Steps

1. Download Hik-Connect mobile client.
2. Optional: Register a new account if it is the first time you use the Hik-Connect mobile client.

 **Note**

For details, see *User Manual of Hik-Connect Mobile Client*.

3. Run and login the client.

3.3.2 Add AX HYBRID PRO to the Mobile Client

Add an AX HYBRID PRO to the mobile client before other operations.





Steps

1. Power on the AX HYBRID PRO.
2. Select adding type.
- Tap + → **Scan QR Code** to enter the Scan QR code page. Scan the QR code on the AX HYBRID PRO.

 **Note**

Normally, the QR code is printed on the label stuck on the back cover of the AX HYBRID PRO.

Tap + → **Manual Adding** to enter the Add Device page. Enter the device serial No. with the Hik-Connect Domain adding type.

3. Tap  to search the device.
4. Tap **Add** on the Results page.
5. Enter the verification code and tap **OK**.
6. After adding completed, enter the device alias and tap **Save**.
7. Optional: Tap  → **Delete Device** to delete the device.
8. Optional: Tap  →  to edit the device name.

3.3.3 Add Peripheral to the AX HYBRID PRO

Add peripheral to the AX HYBRID PRO.

Steps

1. Select a control device (AX HYBRID PRO).
2. Tap +.

Scan Bus Device


- Select scan mode. Continuous scan means adding devices from a continuous address range. You can set the minimum and maximum range of the address. Discrete Scan means adding devices from several discrete addresses. You can tick several discrete address.
- Tap **Scan**. Tick devices in the bus device list, and Tap **Add**.

Add Wired Device

- Enter the device serial No. and select the channel No. to add the device.

Add Wireless Device


- Scan the QR code on the peripheral.

- Tap  to enter the Manually Input page. Enter the device serial No. and select the device type to add the device.

3.3.4 Main Page

You can view faults, arm and disarm areas, view device status, etc.

On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.



Enable Alarm

Tap  to select **Audible Panic Alarm** or **Silent Panic Alarm**.

View Faults

Tap  to view faults.

Area Management

Tap **+** to add an area.

Tap **Area** to enter the area management page. Refers to **3.2.15 Set Arming/Disarming**


Schedule for details.



Arm/Disarm the Area

Arm or disarm the area manually as you desired.


On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the Area page.






Operations for a Single Area



- **Away Arming:** Tap  to away arm a single area. When all the people in the detection area leave, turn on the Away mode to arm all zones in the area after the defined dwell time.
- **Stay Arming:** Tap  to stay arm a single area. When all the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection set in all the zones of all areas.


Operations for Multiple Areas




- **Select Areas:** Tap  to select areas you want to operate. If you do not select areas, following operations will take effect for all areas.
- **Away Arming:** Tap  to away arm selected areas. When all the people in the detection area leave, turn on the Away mode to arm all zones in all areas after the defined dwell time.
- **Stay Arming:** Tap  to stay arm all areas. When the people stays inside the detection area, turn on the Stay mode to arm all the perimeter burglary detection (such as perimeter detector, magnetic contacts, curtain detector in the balcony) set in all the zones of all areas. At the meantime, the detectors inside the detection area are bypassed (such as PIR detectors). People can move inside the area and alarm will not be triggered.
- **Disarming:** Tap  to disarm all areas. In Disarm mode, all the zones of all areas will not trigger alarm, no matter alarm events happen or not.
- **Silent Alarm:** Tap  to silent alarms for all areas.

3.3.5 Zone Management

1. Tap **Device** to view linked zones.



2. Tap + to add a new zone.
3. Tap a zone to enter the management page. You can view device status (e.g. temperature, battery status, signal strength, etc.).
4. Tap  on the upper right corner to enter the zone settings page.
5. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delay Zone

-Exit Delay: Exit Delay provides you time to leave through the zone without alarm.

Arm with faults is enabled: You should confirm faults first, and then the zone is in arming process. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered and the zone will be armed.

Arm with faults is disabled: Immediately armed. If the delay zone is triggered within the exit delay time but it restores before the time ends, the alarm will not be triggered.

-Entry Delay: Entry Delay provides you time to enter the zone to disarm the system without alarm.

After triggering, if the zone is not disarmed or silenced before the entry delay time ends, the zone will alarm.

-Stay Arm Delay Time: Stay arming uses Stay Arm Delay Time to count down.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keypad for users.

 **Note**

- You can set 2 different time durations in **System Options** → **Schedule & Timer**.
 - Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.
 - You can set Stay Arm Delay Time for the delay zone.
-

Panic Zone

24-hour active zone, whether armed or not. Report panic alarm after triggering. It is usually used in the sites equipped with panic button, smoke detector and glass-break detector.

Medical Alarm

24-hour active zone, whether armed or not. Report medical alarm after triggering.

Fire Zone

24-hour active zone, whether armed or not. Report fire alarm after triggering.

Gas Zone

24-hour active zone, whether armed or not. Report gas alarm after triggering.

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

Keyswitch Zone

-By Trigger Time: Change the arming and disarming status after each trigger. For example, in the disarmed status, if the zone is triggered, the linked area will be armed. Trigger the zone again and the area will be disarmed.

-By Zone Status: You need to choose to arm or disarm the linked area after the zone is triggered.

In the case of the tampering alarm, the arming and disarming operation will not be triggered.

Disabled Zone

Zone disabled ignoring any alarm event. It is usually used to disable faulty detectors.

24-hour Zone

The zone activates all the time with sound/light output when alarm occurs, whether it is armed or not. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Timeout Zone

The zone activates all the time. When this zone has been triggered or restored and exceeds the set time, an alarm will be generated.

It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door).

-Not-Triggered Zone Alarm: If the zone is not triggered for the set time, it will alarm.

-Alarm on Zone Activated: If the zone is triggered for the set time, it will alarm.

-**Retry Time Period**: Set the timeout period.

7. Enable other functions according to your detector types and actual needs.

Note

The configurable functions vary in different detectors and zones. Refer to the actual zone to set the function.

Arm Mode

If the zone is a public zone (the zone belongs to more than one areas), you can set arm mode.

And: When all linked areas are armed, the zone will arm. When any of linked areas is disarmed, the zone will disarm.

Or: When any of the linked areas is armed, the zone will arm. When all linked areas are disarmed, the zone will disarm. When the zone is in alarm, the disarmed areas linked with the zone cannot be armed.

Stay Arm Bypass

The zone will be automatically bypassed in stay arming.

Cross Zone

PD6662 is not enabled: You need to set the combined time interval.

When the first zone is triggered, the system will start timing after the zone is restored. If the second zone is triggered within the set time, both zones will give alarms. Otherwise, no alarm will be triggered.

If the first zone is not be restored, both zones will give alarms when the second zone is triggered, regardless of whether the set time has elapsed.

PD6662 is enabled: You need to set the combined time interval.

The first zone will give an alarm when triggered. If the first zone is not restored and the second zone is triggered, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is triggered within the set time, the system will report the alarm confirmation.

If the first zone is restored, the system will start timing. If the second zone is not triggered within the set time, no information will be reported.

Forbid Bypass on Arming

After enabled, you cannot bypass zones when arming.

Chime

Enable the doorbell. Usually used for door magnetic detectors.

Silent Alarm

After enabled, when an alarm is triggered, only the report will be uploaded and no sound is emitted.

Double knock

After enabled, the time interval can be set. If the same detector is triggered twice or continuously in a period of time, the alarm will be triggered.

Sounder Delay Time

The sounder will be triggered immediately (0s) or after the set time.

Final Door Exit

Only magnetic contacts have this option.

After enabling, when the user use keypads or tags to arm:

- Arm With Faults is enabled: During the arming countdown, if the magnetic contact is triggered and then restored, the arming process will be terminated immediately after restoring, and the arming is completed.
- Arm With Faults is disabled: If the magnetic contact is triggered and then restored, the linked area immediately arms the delayed zone.

Dual Zone

After enabled, when multi transmitter detects that the entire zone circuit of the local zone and the extended zone is open circuit, both zones trigger lid opened alarms.

Timer With Restart

During the Exit Delay process, the exit delay time will be re-timed at the time when the second delay zone was triggered.

3.3.6 User Management

The installers (user of Hik-Connect) can manage users. If you are the administrator, you can add, edit, and delete users, and assign different permissions to the newly-added users.

Steps

Note

There are four types of users for the AX HYBRID PRO, including administrator (or owner), operator, and installer (or setter). Different types of users have different permissions for accessing the functionality of the AX HYBRID PRO.

1. Enter the site, tap the AX HYBRID PRO and then log in to the device (if required) to enter the AX HYBRID PRO page.
 2. Tap **Next** to invite the user.
-

Note

The recipient need to accept the invitation.

3. Tap  → **User Management** → **User**.
4. Tap a user to enter the User Management page.

5. Optional: Perform the following operations if required.

User Permission You can tap the target user on the user list and then tap **Edit Icon** to set the permissions authorized to the target user.

 **Note**

Only the administrator can do such an operation.

Set Linked Areas If the target user is an operator, tap the target user on the user list and then tap **Linked Areas** to set the area linked to the target user.

 **Note**

Only the administrator can do such an operation.

Change Keypad Password If the target user is an administrator, an installer, or an operator, you can tap the target user on the user list and then tap **Change Keypad Password** to set the keypad password to the target user.

Change Duress Password If the target user is an administrator or an operator, you can tap the target user on the user list and then tap **Change Duress Password** to set the duress password to the target user.

 **Note**

If under duress, you can enter the duress code on the keyboard to arm and disarm area(s) and upload a duress alarm.

Automation Control An administrator, an installer or an operator can control the relay module, wall switch and smart plug.

 **Note**

- Configuration items and user permission will vary according to the user type.
 - You can view linked cards/tags and keyfobs of the user but you do not have permission to configure them.
-

6. Optional: (Only for the administrator) Click + to add a user. You can select to add the operator, one-time user or temporary user.

 **Note**

- The operator can configure arming, disarming and control output permissions.
- The one-time user's keypad password will become invalid after one arming and disarming or

after 24 hours.

- The temporary user can set usage duration through time settings.
 - You can only change your own keypad password.
-

3.3.7 Card/Tag Management


After adding cards/tags to the wireless AX HYBRID PRO, you can swipe the card/tag to arm or disarm all the detectors added to specific area(s) of the AX HYBRID PRO, and silence alarms.



Note

The tag ID/PIN is a 32 bit long integer, and the variant could be 42949672956.

Steps

1. Enter the site, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
 2. Tap  → **User Management** → **Card/Tag** to enter the Card/Tag page.
 3. Tap **+** to add a tag.
 4. When hearing the voice prompt "Swipe Tag", you should present the tag on the AX HYBRID PRO tag presenting area.
 - When hearing a beep sound, the tag is recognized.
 - The tag will be displayed on the tag page.
 5. Optional: Tap a Tag to enter the Setting Page.
 6. Tap **Edit Icon** to edit the Tag name.
-



Note

- If you log in as an installer, skip this step. Editing tag name is only available to administrator.
 - The name should contain 1 to 32 characters.
-

7. Slide **Enable Tag**.
 8. Select a linked user.
 9. Select the tag type
-



Note

Different linked users have different tag permissions.

Operation Tag

You can swipe the tag to arm or disarm.

Patrol Tag


When you swipe the tag, the system will upload a record.

10. Optional: Tap **Delete** to delete the tag.

3.3.8 Device Information


You can change language and select time zone.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **Configuration** to enter the page.
3. Select device language and time zone.

3.3.9 System Management

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **System Management** to enter the page.

Forced Auto Arm

After enabled, when the timed automatic arming starts, if there are active faults in a zone, the zone will be automatically bypass.

You can go to **System** → **System Options** → **Schedule & Time** to set the auto arming/disarming schedule and linked areas.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

Forced Arming

After enabled, when manual arming starts, if there are active faults in a zone, the zone will be automatically bypass.

You can use keyfobs, tags, and keypads to arm zones, or manually arm zones on APP. Single, multiple or all areas can be selected for arming.

Note

You should disable the Arm With Faults in the Arm Options page. Or the Forced Auto Arm/Forced Arming function cannot be valid.

System Status report

If the option is enabled, the device will upload report to Cloud (for APP) and ARC automatically when the AX HYBRID PRO status is changed.

Voice Prompt

If the option is enabled, the AX HYBRID PRO will enable the voice prompt.

-Fault Prompts on Arming: Voice prompt of faults when arming.

- Fault Prompts When Armed: Voice prompt of faults when the system is armed.
- Fault Prompts on Disarming: Voice prompt of faults when disarming
- Fault Prompts When Disarmed: Voice prompt of faults when the system is disarmed.
- Voice Prompts on Alarm: Voice prompt of faults when an alarm is triggered.

System Volume

The available system volume range is from 0 to 10.

Audible Tamper Alarm

While enabled, the system will alert with buzzer for the tamper alarm. Regardless of whether it is enabled or not, the tamper alarm will be normally pushed to Cloud (for APP) and ARC.

Panel Lockup Button

All functions of AX HYBRID PRO will be frozen after it is enabled. This function can only be enabled by users with installer permission.

Alarm Duration

Set linked alarm voice prompt lasting time.

Wireless Supervision Loss

Detectors and peripherals whose heartbeat loss times exceed the set value will be shown as offline.

Bypass on Re-Arm

While enabled, after the detector is bypassed, if its faults are restored and the linked area is armed, the detector will automatically arm.

Motion Detector Restore

Motion detectors include all PIR detectors.

-Disable: No automatic restore.

-Immediate After Alarm: Motion detectors automatically restores immediately after the alarm and reports to Cloud (for APP) and ARC.

-After Disarm: Motion detectors automatically restores after disarming and reports to Cloud (for APP) and ARC

Jamming Sensitivity Settings

The device will detect RF interference and push messages when the RF interference interferes with communication. You can adjust the detection sensitivity.

Enable PD6662

Enable PD6662 standard. Functions that do not meet the standard will not take effect.

Keypad Logout


After the keypad enters the programming page, if there is no key operation, it will exit the programming page after reaching this time.

3.3.10 Fault Check

The fault check here is only for the control panel in the normal status.

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **System Fault Check** to enter the page.

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered. The delay time of network camera disconnection detection is the same as that of LAN.

Panel Battery Fault Check

If the option is enabled, when panel battery is disconnected or in low battery status, the device will upload events.

LAN Lost

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

WiFi Lost

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Lost

If the option is enabled, when the cellular data network is disconnected or with other faults, the alarm will be triggered.

Panel Mains Power Lost

If the option is enabled, an alarm will be triggered when the control panel main supply is disconnected.

Panel Mains Power Loss Delay


The system checks the fault after the configured time duration after AC power down. To compliant the EN 50131-3, the check time duration should be 10 s.

3.3.11 Arm Options

This function is for the whole alarm system, to inform the user of the current system status before arming. If it is enabled, there will be a fault prompt and confirmation process for keypads, keyfobs,

and APP. If it is not enabled, there will be no fault detection before arming.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **Arm Options** to enter the page.


You can set the following parameters:

Arm with Fault


Check the faults in the Enable Arming with Fault list, and the device will not stop the arming procedure when faults occurred.

Early Alarm

A delay zone is triggered first, and the area is in the "Entry Delay" stage. During the delay time period, an instant zone is triggered (only for the first triggered instant zone). At this time, the area enters the early alarm stage. There are control panel voice alarm and local sounder alarm, but no alarm message is pushed. If the zone is disarmed or silence before both the early alarm and entry delay end, the alarm message will not be reported. Otherwise, both the delayed zone and the instant zone will alarm.




OR



3. Tap **Save**.

3.3.12 Enrollment Mode


Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **System** → **System Options** → **Enrollment Mode** to enter the page.
3. Tap **Enter the Enrollment Mode**. You can enroll the peripheral by triggering it.

3.3.13 Network Camera


Add Cameras to the AX HYBRID PRO

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Network Camera** → **Network Camera Channel** to enter the page.
3. Tap **Add Channel**.
4. Enter IP address, port, the user name and password of the camera.
5. Tap **Save Icon**.
6. Optional: tap **Edit** or **Delete** to edit or delete the selected camera.

3.3.14 Set Video Parameters

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Network Camera** → **Event Video Settings** to enter the page.
3. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality.

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output.

Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.

Before Alarm


The recording time length before the alarm.

After Alarm

The recording time length after the alarm.

3.3.15 Set Arming/Disarming Schedule

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **Area** to enter the page.
3. Tap an area in the list, enable the area and select linked devices.
4. Set parameters:

Auto Arm

Enable the area to automatically arm itself in a specific time point.

Auto Arm Time

Set the schedule for the area to automatically arm itself.

Auto Disarm

Enable the area to automatically disarm itself in a specific time point.

Auto Disarm Time

Set the schedule for the area to automatically disarm itself.

Auto Arming Sound Prompt

After disabled, the buzzer will not beep before auto arming.

Late to Disarm

Enable the device to push a notification to the phone or tablet to remind the user to disarm the area when the area is still armed after a specific time point.



You should enable the Panel Management Notification function on the Web Client of **Communication Parameters** → **Event Communication** before enabling the Late to Disarm function.

Late to Disarm Time

Set the time point mentioned in **Late to Disarm**.

Weekend Exception

If enabled, **Auto Arm**, **Auto Disarm**, and **Late to Disarm** are disabled on the weekend.

Holiday Excepted

Enable the function and the zone will not be armed/disarmed in the holiday. You should set the holiday schedule after enabling.




Up to 6 holiday groups can be set.

3.3.16 Communication


Wired Network

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Wired Network** to enter the page.
3. Set the parameters.
 - Automatic Settings: Enable **DHCP** and set the HTTP port.
 - Manual Settings: Disabled **DHCP** and set **IP Address, Subnet Mask, Gateway Address, DNS Server Address**.
4. **Optional:** Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.
5. Click **Save**.


Wi-Fi Configuration

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Wi-Fi Configuration** to enter the page.
3. Tap a Wi-Fi to connect in the list.

Cellular Data Network

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Cellular Data Network Settings** to enter the page.
3. Enable **Cellular Data Network**.
4. Tap to select a SIM card. Tap **Parameter Configuration** → **Edit Icon** and set parameters including the user name, access password, APN, MTU and PIN code.
5. Tap **Save Icon**.
6. Enable **Data Usage Limit**.
7. Edit **Data Used This Month** and **Data Limited per Month**.

Access Number

Input the operator dialing number.

Note

Only the private network SIM card user needs to enter the access number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Limited per Month

You can enable the function and set the data threshold every month. If data usage is more than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.


Data Used This Month

The used data will be accumulated and displayed in this text box.

Push Notifications

When an alarm is triggered, if you want to send the alarm notification to the mobile phone, you can set the notification push parameters.

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Push Notification(s)** to enter the page.
3. Enable the target notification.

Zone Alarm/Lid Opened

The device will push notifications when the zone alarm is triggered or the zone lid opened is triggered or restored.

Note

You need to set event filtering interval time for phone calling.

Peripherals Lid Opened

The device will push notifications when lid opened of any peripherals is triggered or restored.

Panel Lid Opened

The device will push notifications when lid opened of the control panel is triggered or restored.

Panic Alarm

The device will push notifications when panic alarm is triggered or restored by zones, keypads or keyfobs.

Medical Alarm

The device will push notifications when medical alarm is triggered.

Fire Alarm

The device will push notifications when fire alarm is triggered.

Gas Alarm

The device will push notifications when gas alarm is triggered.

Panel Status

The device will push notifications when the control panel system status is changed.

Zone Status

The device will push notifications when the zone status is changed.

Peripherals Status

The device will push notifications when any peripheral status is changed.

Panel Operation

The device will push notifications when the user operates the AX HYBRID PRO.

Smart Alarm Event

The device will push notifications when the alarm is triggered in thermal cameras.

4. Tap **Phone Call and SMS**.

5. Tap **+ Add Phone Number** to enter the phone number.

6. Tap the added phone number to enable **Phone Call and SMS** according to your need.

(For Phone Call) Set Numbers of Calling.

(For SMS) Set Arming Permission, Disarming Permission and Alarm Clearing Permission for areas.

Common Message

You can enter message content. When the alarm is triggered, your customized content will be added at the beginning of the message sent by the system.

Common Voice

You can import a new audio. When the alarm is triggered, your customized voice will be added at the beginning of the content of the phone dialed by the system. You can also tap Clear to delete audios




Only WAV format is supported, up to 512 KB and 15 s.

7. Check notifications.

Alarm Receiving Center (ARC)

You can set the alarm receiving center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Alarm Receiving Center (ARC)** to enter the page.
3. Select an ARC and enable it.

Connection Type

Select the Connection Type as IP, serialPort or PSTN to set connection mode.

Protocol Type

Select the Protocol Type as ADM-CID, ISUP, SIA-DCS, *SIA-DCS, *ADM-CID, CSV-IP, FSK Module, RDC Module, PSTN-CID, RDC Module-CID or FSK Module-CID to set uploading mode.

GMT

Enable the Greenwich Mean Time.

Address Type

Select the Address Type as IP Address and Domain Name. Enter server address/domain name, port number and account code.

Transmission Mode

Select the Transmission Mode as TCP or UDP. UDP is recommended by the SIA DC-09 standard.

Impulse Counting Time

After the selected time, the system will retry to transmit.

Attempts

Set the number of retry attempts.

Polling Option

Set the polling rate with the range from 10 to 3888000 seconds. The system will report fault if the time is over the limit. The status of device will be shown as offline.

Periodic Test

After enabling, you can set the time interval, setting how often to send a test event to the ARC to ensure the connection.

Companies


Select the support company as None, Hungary-Multi Alarm Receiving Company or French Alarm Receiving Company.

Intruder Verification as a Service

The SDK returns the URL address of the video storage after the PIRCAM composite video is uploaded to the cloud. The control panel will add this URL in the additional field when reporting the intruder verification to ARC. After receiving the URL, ARC can download the video. The alarm video can be stored in the cloud for up to 7 days.

Cloud Service Settings

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Cloud Service Settings** to enter the page.
3. Select the **Communication Mode**.

Auto

The system will select the communication mode automatically according to the sequence of, wired network, Wi-Fi network, and cellular data network. Only when the current network is disconnected, will the device connect to other network.

Wired Network & Wi-Fi Priority

The connection priority order from high to low is: wired network, Wi-Fi, cellular data network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

4. Enable **Periodic Test**. Enter the periodic test interval.


Periodic Test

After enabling, you can set the time interval, setting how often to send a test event to the ARC to ensure the connection.

5. Tap **Save**.

Notification by Email

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **Notification by Emails** to enter the page.
3. Enable **Email 1**.
4. Enter the sender name, sender email address, SMTP server address, SMTP port, user name and password.

Note


It is recommended to use Gmail and Hotmail for sending mails.

Only if the zone is linked with a network camera, the alarm email will be attached with alarm video.

5. Select the encryption type as **None**, **SSL** or **TLS**.
6. Enable **Server Authentication**.
7. Enter receiver name and receiver email address. Tap **Test Receiver Email Address** to test whether the email address is correct.
8. Tap **Save**.

FTP Settings

Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **FTP Settings** to enter the page.
3. Select **Preferred FTP** or **Alternated FTP**, and enable FTP.
4. Configure the FTP parameters

FTP Type

Set the FTP type as preferred or alternated.

Protocol Type

FTP and SFTP are selectable. The files uploading is encrypted by using SFTP protocol.

Server Address and Port

The FTP server address and corresponding port.

User Name & Password/Anonymity

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can enable Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server.


4. Tap **Save**.

NAT

Universal Plug and Play (UPnP™) is a networking architecture that provides compatibility among networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps





1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Communication Parameters** → **NAT** to enter the page.
3. Drag the slider to enable UPnP.
4. **Optional**: Select the mapping type as **Manual** to set the HTTP port and the service port.

5. Click **Save** to complete the settings.

3.3.17 Device Maintenance

You can reboot the device.


Steps

1. In the site, tap the AX HYBRID PRO and then log in to the device (if required).
2. Tap  → **Maintenance** → **Reboot Device**. to enter the maintenance page.
The AX HYBRID PRO will reboot.
3. Tap  → **Maintenance** → **Device Upgrade** to upgrade the control panel, or tap  → **Maintenance** → **Detector & Peripheral Upgrade** to upgrade detectors and peripherals.
4. Optional: Tap  → **Maintenance** → **Remote Log Collection** to enable the function.
Remote Log Collection is for getting logs relating to the device. When this is enabled, our technical support will be able to collect logs relating to the device remotely and upload them to our server for troubleshooting. You can set the validity period according to actual needs. This function will be disabled after the set validity period.

3.3.18 Wi-Fi Connection

You can make the AX HYBRID PRO connect to Wi-Fi through APP.

Steps

1. On the device list page, tap the AX HYBRID PRO and then log in to the device (if required) to enter the page.
2. Tap  → **Configure Wi-Fi Network**.
3. Follow the instructions on the page and change the AX HYBRID PRO to the AP mode. Tap **Next**.
4. Select a stable Wi-Fi for the device to connect.
5. Back to configuration page to enter the Wi-Fi password and tap **Next**.
6. Tap **Connect to a network** and wait for connection.
After the connection is completed, the AX HYBRID PRO will prompt to exit AP mode and automatically switch to STA mode.

3.3.19 Check Alarm Notification

When an alarm is triggered, and you will receive an alarm notification. You can check the alarm information from the mobile client.


Before You Start

- Make sure you have linked a zone with a detector.
- Make sure the zone is not bypassed.
- Make sure you have not enabled the silent zone function.


Steps

1. Tap **Notification** in the mobile client to enter the page.
All alarm notifications are listed in Notification page.

2. Select an alarm and you can view the alarm details.



3. **Optional:** If the zone has linked a camera, you can view the playback when the alarm is triggered.

4. **Optional:** Tap  to search events by dates or devices.


3.4 Report to ARC (Alarm Receiver Center)

AX HYBRID PRO wireless control panel is designed with transceiver built in following the guidance of EN 50131-10 and EN 50136-2. Category DP2 is provided with primary network interface of LAN/Wi-Fi and secondary network interface of GPRS or 3G/4G LTE. ATS (Alarm Transmission system) is designed to always use LAN/Wi-Fi network interface when available to save mobile data usage. The secondary network interface provides resilience and reliability during mains power failure.


Setup ATS in Transceiver of Receiving Center

Steps:

1. Login to the web client of the alarm receiver.
2. Click **Configuration**→ **IP Reception**, and create a receiving server as shown below.



3. Click **Alarms and Accounts** → **Accounts Management**, and assign an account for the panel as show below.



Setup ATS in Transceiver of the Panel

Steps:

1. Login using installer account from local web client.
2. Click **Communication** → **Alarm Receiving Center (ARC)**, and enable **Alarm Receiving Center 1**.

Alarm Receiver Center1

Enable	<input checked="" type="checkbox"/>
Protocol Type	*ADM-CID
Address Type	IP
Server Address	115.236.50.3
Port No.	6666
Account Code	2297
Transmission Mode	TCP
Impulse Counting Time	20 s
Attempts	3 <input checked="" type="checkbox"/>
Polling Rate	60 <input checked="" type="checkbox"/> Enable
Encryption Arithmetic	AES
Password Length	128
Secret Key	123456789012345678901234567 <input type="checkbox"/>

● = Protocol Setting =

Protocol Type

- ADM-CID
- SIA-DCS
- *ADM-CID
- *SIA-DCS

Select token supported by the receiver in the ARC. Choose the token with “*” mark to improve the communication security.

● = Server Setting =

■ **Address Type**

- IP
- Domain Name

■ **Server Address / Domain Name**

■ **Port No.**

Input IP address or domain name by which the transceiver of receiving center could be reached. Input port number of the server provided by the ARC

● = Account Setting =

■ **Account Code**

Input the assigned account provided by the ARC.

● = SIA DC-09 Protocol Setting =

■ **Transmission Mode**

- TCP
- UDP

Both TCP and UDP are supported for transmission. UDP is recommended by the SIA DC-09

standard.

- **Connection Setting**

- **Impulse Counting Time / Retry Timeout Period**

Setup the timeout period waiting for receiver to respond. Re-transmission will be arranged if the transceiver of receiving center is timeout.

- **Attempts**

Setup the maximum number that re-transmission will be tried.

- **Polling Rate**

Setup the interval between 2 live polling if enable is checked.

- **Encryption Setting**

- **Encryption Arithmetic**

— AES

- **Password Length**

— 128

— 192

— 256

- **Secret Key**

Setup the encryption key length and input the key provided by the ARC.

Signaling Test

Activate a panic alarm from the control panel.

Login to Receiver. Click **Traffic** to review all the messages received.

The screenshot shows the 'Traffic' page in a web interface. The top navigation bar includes 'Traffic', 'Status and Logs', 'Alarms and Accounts', and 'Configuration'. The user is logged in as 'Administrator DT42'. The main heading is 'Traffic' with a 'Refresh In 16' indicator. Below the heading, there are controls for 'Order by' (set to 'Reception Time') and 'Filter by' (set to 'Event ID'). The main content area displays a table of events. The first event, 'Event 580777', is highlighted with a red box. Its details are: Account: 2297, Zone: 1, Description: Panic Alarm / 001, Partition: 01, Receiver #: 1, Code: E120, Line #: 0, and timestamp: 2020-03-28 12:01:42. A second event, 'Event 580776', is partially visible below it with a timestamp of 2020-03-28 12:01:36.

Event ID	Account	Zone	Description	Partition	Receiver #	Code	Line #	Timestamp
Event 580777	2297	1	Panic Alarm / 001	01	1	E120	0	2020-03-28 12:01:42
Event 580776								2020-03-28 12:01:36

Capítulo 4 Operaciones Generales

4.1 Access Entries

The installer and operators of the AX HYBRID PRO were assigned different access levels which define the system functions that an individual user can perform. Various user entries are provided for different user roles with particular access level.

Access entries for Installers (Access Level 3)

- **Hik-Partner Pro Service**
Hik-Partner Pro is a service for installers that is used to manage customers' alarm systems located in various sites remotely. Control panels can be added to an installer account on the Hik-Partner Pro Service and be managed in sites.
- **Local Web Client**
Visit the device IP address that can be found out with SADP tool. The installer can login with Hik-Partner Pro service account after the panel was added.
- **Other entries**
Keypad PINs and tags can be also assigned with installer user at particular access level to perform essential operations.


Access Entries for the Administrator and Operators (Access Level 2)

- **Hik-Connect Service**
The Hik-Connect service can be used for end users to access and manage the devices.
- **Local Web Client (for the administrator)**
As soon as the panel was added to the end user account on Hik-Connect Service, the Hik-Connect account can be used to login to the web client build in.

Operators cannot login the web client.
- **Other entries**
Keypad PINs and tags can be also assigned with end user at particular access level to perform essential operations.

4.2 Arming

You can use keypad, keyfob, tag, client software, mobile client to arm your system. After the arming command is sending to AX HYBRID PRO, the system will check the detector status. If the detector is in fault, you will need to choose whether to arm the system with fault. While the system is armed, the AX HYBRID PRO will prompt the result in 5s, and upload the arming report.



Access level of Arming

The user in level 2 or 3 has the permission to arm or partly arm the system.

Arming Indication

The arming/disarming indicator keeps solid blue for 5s.

Reason of Arming Failure

- Intrusion detector triggered (excepts the detector on the exit route).
- Panic alarm device triggered.
- Lid opened (tamper) alarm occurred.
- Communication exception
- Main power supply exception
- Backup battery exception
- Alarm receiving fault
- Sounder fault
- Low battery of the keyfob
- Others

Arming with Fault

While the arming is stopped with fault, user in level 2 has the permission to arm the system with fault (forced arming).

Forced arming only takes effect on the current arming operation.

The forced arming operation will be record in the event log.

4.3 Disarming

You can disarm the system with keypad, keyfob, Tag, client software, or mobile client.

Disarming Indication

The arming/disarming indicator flashes 30s while the user successfully disarm the system through the entry/exit route.

The system will report the disarming result after the operation completed.

Entry Delay Duration

Ensure that timer is no longer than 45 seconds in order to comply with EN50131-1.

Early Alarm

If either the intrusion or tampering alarm occurs on the enter/exit route when the AX HYBRID PRO is in the status of entry delay, the AX HYBRID PRO then enters the early alarm mode.

The early alarm duration can be set (> 30s).

The AX HYBRID PRO will reports the alarm only if the alarm event lasts over the duration of early alarm with the addition of entry delay.

4.4 SMS Control

You can control the security system with SMS, and the command is shown below.

SMS format for Arming/disarming/silencing alarm:

{Command} + {Operation Type} + {Target}

Command: 2 digits, 00- Disarming, 01- Away arming, 02- Stay arming, 03- Silencing alarm

Operation type: 1- Area Operation

Target: No more than 3 digits, 0-Operation for all areas, 1-Operation for area 1(zone1), and the rest can be deduced by the analogy.

A. Solución de problemas

A.1 Communication Fault

A.1.1 IP Conflict

Fault Description:

IP that the panel automatically acquired or set is same as other devices, resulting in IP conflicts.

Solution:

Search the current available IP through ping. Change the IP address and log in again.

A.1.2 Web Page is Not Accessible

Fault Description:

Use browser to access web pages and display Inaccessible.

Solutions:

1. Check whether the network cable is loose and the panel network is abnormal.
2. The panel port has been modified. Please add a port to the web address for further access.

A.1.3 Hik-Connect is Offline

Fault Description:

The web page shows that the Hik-Connect is offline.

Solution:

Network configuration of the panel is error, unable to access extranet.

A.1.4 Network Camera Drops off Frequently

Fault Description:

System reports multiple event logs of IPC disconnection and connection.

Solution:

Check whether the network communication or camera live view is proper.

A.1.5 Failed to Add Device on APP

Fault Description:

When using APP to add devices, it is prompted that the device fails to be added, the device could not be found, etc.

Solution:

Check the web page: whether the Hik-Connect is offline.

A.1.6 Alarm Information is Not Reported to APP/4200/Alarm Center

Fault Description:

After the alarm is triggered, the app/4200/ alarm center does not receive the alarm message.

Solution:

"Message push" - "alarm and tamper-proof notice" is not enabled. You should enable "alarm and tamper-proof notice".

A.2 Mutual Exclusion of Functions

A.2.1 Unable to Enter Enrollment Mode

Fault Description:

Click the panel function key, and prompt key invalid.

Solution:

The panel is in "Hotspot" mode. Switch the panel to "station" mode, and then try to enter the enrollment mode again.

A.3 Zone Fault

A.3.1 Zone is Offline

Fault Description:

View status of zones which displays offline.

Solution:

Check whether the detector reports undervoltage. Replace the detector battery

A.3.2 Zone Tamper-proof/Lid-opened

Fault Description:

View status of zones which displays tamper-proof/lid-opened.

Solution:

Make tamper-proof button of the detector holden.

A.3.3 Zone Triggered/Fault

Fault Description:

View status of zones which displays triggered/fault.

Solution:

Reset the detector.

A.4 Problems While Arming

A.4.1 Failure in Arming (When the Arming Process is Not Started)

Fault Description:

When the panel is arming, prompt arming fails.

Solution:

The panel does not enable "forced arming", and when there is a fault in the zone, the arming will fail. Please turn on the "forced arming" enable, or restore the zone to the normal status.

A.5 Operational Failure

A.5.1 Failed to Enter the Test Mode

Fault Description:

Failed to enable test mode, prompting "A fault in the zone".

Solution:

Zone status, alarm status or zone power is abnormal.

A.5.2 The Alarm Clearing Operation on the Panel Does Not Produce the Alarm Clearing Report

Fault Description:

The alarm clearing operation on the panel does not produce the alarm clearing report.

Solution:

In the absence of alarm, no report will be uploaded for arm clearing.

A.6 Mail Delivery Failure

A.6.1 Failed to Send Test Mail

Fault Description:

When configure the mail information, click "test inbox" and prompt test fails.

Solution:

Wrong configuration of mailbox parameters. Please edit the mailbox configuration information, as shown in table 1/1.

A.6.2 Failed to Send Mail during Use

Fault Description:

Check the panel exception log. There is "mail sending failure".

Solution:

The mailbox server has restricted access. Please log in to the mailbox to see if the mailbox is locked.

A.6.3 Failed to Send Mails to Gmail

Fault Description:

The receiver's mailbox is Gmail. Click "Test Inbox" and prompt test fails.

1. Google prevents users from accessing Gmail using apps/devices that do not meet their security standards.

Solution:

Log in to the website (<https://www.google.com/settings/security/lesssecureapps>), and "start using access of application not safe enough". The device can send mails normally.

2. Gmail does not remove CAPTCHA authentication.

Solution: Click the link below, and then click "continue"

(<https://accounts.google.com/b/0/displayunlockcaptcha>).

A.6.4 Failed to Send Mails to QQ or Foxmail

Fault Description:

The receiver's mailbox is QQ or foxmail. Click "Test Inbox" and prompt test fails.

1. Wrong QQ account or password.

Solution:

The password required for QQ account login is not the password used for normal login. The specific path is: Enter the email account → device → account → to generate the authorization code, and use the authorization code as the login password.

2. SMTP login permission is needed to open.

A.6.5 Failed to Send Mails to Yahoo

Fault Description:

The receiver's mailbox is yahoo. Click "test inbox" and prompt test fails.

1. The security level of mailbox is too high.

Solution:

Go to your mail account and turn on "less secure sign-in".

A.6.6 Mail Configuration

Table A-1 Mail Configuration

Mail Type	Mail Server	SMTP Port	Protocols Supported
Gmail	smtp.gmail.com	587	TLS/STARTTLS (TLS)
Outlook	smtp.office365.com	587	STARTTLS (TLS)
Hotmail	smtp.office365.com	587	STARTTLS (TLS)
QQ	smtp.qq.com	587	STARTTLS (TLSv1.2)
Yahoo	smtp.mail.yahoo.com	587	STARTTLS (TLSv1.2)
126	smtp.126.com	465	SSL/TLS
Sina	smtp.sina.com	25/465/587	SSL/TLS/STARTTLS (SSL/TLS)

 **Note**

About mail configuration:

- SMTP portDefault to use port 25 without encryption, or using port 465 if SSL/TLS is used. Port 587 is mainly used for STARTTLS protocol mode. The STARTTLS protocol mode that is usually used by default when selecting TLS.
- User nameUser name of Outlook and Hotmail require full names, and other email require a prefix before @.

B. Input Types

Table B-1 Input Types

Input Types	Operations
Instant Zone	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X alarm.</p>
Perimeter Zone	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and sounder. There is a configurable interval between alarm and sounder output, which allows you to check the alarm and cancel the sounder output during the interval.</p> <p>Voice Prompt: Zone X perimeter alarm.</p>
Delayed Zone	<p>The system provides you time to leave through or enter the zone without alarm.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X alarm.</p>
Follow Zone	<p>The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X follow alarm.</p>
24H Silence Zone	<p>The zone activates all the time without any sound/sounder output when alarm occurs.</p> <p>Audible Response: No system sound (voice prompt or sounder).</p>
Panic Zone	<p>The zone activates all the time.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X panic alarm.</p>
Fire Zone	<p>The zone activates all the time with sound/sounder output when alarm occurs.</p>

Input Types	Operations
	<p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X fire alarm.</p>
Gas Zone	<p>The zone activates all the time with sound/sounder output when alarm occurs.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X gas alarm.</p>
Medical Zone	<p>The zone activates all the time with beep confirmation when alarm occurs.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X medical alarm.</p>
Timeout Zone	<p>The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired (1 to 599) seconds.</p>
Disabled Zone	<p>Alarms will not be activated when the zone is triggered or tampered.</p> <p>Audible Response: No system sound (voice prompt or sounder).</p>
Virtual Zone (Keypad/Keyfob)	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Buzzer beeps.</p>
Tamper Alarm (Lid Opened Alarm)	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and sounder.</p> <p>Voice Prompt: Zone X tampered.</p>
Link	<p>Trigger the linked device when event occurs.</p> <p>e.g. The output expander linked relays will be enabled when the AX HYBRID PRO is armed.</p>
Arm	<p>When armed: Voice prompt for fault. You can handle the fault according to the voice prompt.</p> <ul style="list-style-type: none"> ● System sound for arming with Tag or keyfob. ● Voice prompt for fault. You can handle the fault according to the voice prompt.

Input Types	Operations
	Fault event displays on client. You can handle the fault via client software or mobile client. <ul style="list-style-type: none">● Voice Prompt: Armed/Arming failed.

C. Output Types

Table C-1 Output Types

Output Types	Active	Restore
Arming	Arm the AX HYBRID PRO	After the configured output delay
Disarming	Disarm the AX HYBRID PRO	After the configured output delay
Alarm	When alarm event occurs. The alarm output will be activated after the configured exit/enter delay.	After the configured output delay, disarm the AX HYBRID PRO or silence alarm
Zone Linkage	When alarm event occurs, the linked relay will output alarm signal.	After the configured output duration
Manual Operation	Enable relays manually	Over the triggering time or disable the relays manually

D. Event Types

Table D-1 Event Types

Event Types	Custom	Default 1 (client software notification)	Default 2 (alarm receiving center 1/2)	Default 3 (mobile client)	Default 4 (telephone)
Alarm and Tamper	x/v	√	√	√	√
Life Safety Event	x/v	√	√	√	√
System Status	x/v	√	x	x	x
Panel Management	x/v	√	x	x	x

E. Niveles de Acceso

Level	Description
1	Access by any person; for example the general public.
2	User access by an operator and administrator; for example customers (systems users).
3	User access by an installer; for example an alarm company professional.

Table E-1 Permission of the Access Level

Function	Permission		
	1	2	3
Arming	No	Yes	Yes
Disarming	No	Yes	Yes
Restoring/Clearing Alarm	No	Yes	Yes
Entering Walk Test Mode	No	Yes	Yes
Bypass(zone)/Disabling/Force Arming	No	Yes	Yes
Adding/Changing Verification Code	No	Yes ^d	Yes ^d
Adding/Editing Level 2 User and Verification Code	No	Yes	Yes
Adding/Editing Configuration Data	No	No	Yes
Replacing software and firmware	No	No	No

Note

^a By the condition of being accredited by user in level 2.

^b By the condition of being accredited by user in level 2 and level 3.

^d Users can only edit their own user code.

- The user level 2 can assign the login permission of the controller to the user level 3 in the settings page.
- The user level 2 should assign permissions to the user level 3 if the user level 3 wants to login the controller remotely.
- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.

- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.
- The user level 4 can login the controller only when the user level 2 or level 3 has assigned permissions to the user level 4.

F. Signalling

Detection of ATP/ATS Faults

ATP (Alarm Transmission Path) faults will be detected when network interface of the control panel disconnected or the transmission path to the transceiver of receiving center located in ARC blocked somewhere in between. An ATS (Alarm Transmission System) fault will be reported when ATP faults are detected on both transmission paths.

ATP restore will be detected as soon as network interface connected and the transmission path to the transceiver of receiving center restored. ATS restore will be reported when ATP restore of any transmission path is detected.

The timing performance of detecting ATP faults and restores shows in the table below.

	TN	Maximum timing of detection
Primary ATP failure/restore	LAN/WiFi	10 min
Secondary ATP failure/restore	GPRS	60 min
	3G/4G LTE	20 min (when primary ATP failed)

Signalling will be always transmitted from primary ATP when it is operational. Otherwise it will be automatically switched to secondary transmission path that is operational at the moment. Both primary and secondary ATP fault and restore events will be reported to ARC when there is an ATP left to work. They will also be recorded to mandatory log memory with capacity of 1000 records allocated in non-volatile flash memory storage, as well as the ATS fault record. The detail of reports and log records are listed in the table below.

	Event code when signalling	Event log description
Primary ATP failure/restore	E351/R351	LAN Path Failed/LAN Path Recovery
Secondary ATP failure/restore	E352/R352	Mobile Net Path Failed/Mobile Net Path Recovery
ATS failure/restore	N/A	ATS Failed
Primary network interface failure/restore	E351/R351	LAN Path Failed/LAN Path Recovery
Secondary network interface failure/restore	E352/R352	Mobile Net Path Failed/Mobile Net Path Recovery

ATS Category

The ATS category of AXPRO is DP2. While the alarm receiving center is enabled. The control panel will upload alarm report to the receiver center via the main path (LAN or Wi-Fi) or the back-up path (3G/4G). If the control panel is properly connected to the LAN or Wi-Fi, the main path is selected as the transmission path. If the main path connection is failed, the path will be switched to 3G/4G. And if the main path connection is restored, the path will be switched back to LAN or Wi-Fi. The control panel checks the connection status continuously, and generates logs transmission fault for any of the path. While both of the paths are invalid, the control panel determines ATS fault.

G. SIA and CID Code

Note

The code below is for transmitting from the security control panel to ARC via DC09 protocol.

Table F-1 SIA and CID Code

SIA code	CID code	Description
MA	1100	Medical Alarm
MH	3100	Medical Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	Burglary Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	Burglary Alarm Restored
FA (Heat Detector: KA)	1111 (Heat Detector: 1114)	Fire Alarm
FH (Heat Detector: KH)	3111 (Heat Detector: 3114A)	Fire Alarm Restored
HA	1121	Duress alarm
HA	1122	Silent Panic Alarm
HH	3122	Silent Panic Alarm Restored
	1133	24H Alarm
	3133	24H Alarm Restored
NA	1780	Timeout Alarm
BH	3780	Timeout Alarm Restored
PA	1120	Panic Alarm
		Audible Panic Alarm
PH	3120	Audible Panic Alarm Restored
BA	1130	Burglary Alarm
BH	3130	Burglary Alarm Restored
BA	1131	Perimeter Breached
BH	3131	Perimeter Restored
AD	1132	Interior Burglary Alarm
CK	3132	Interior Burglary Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	24H Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	24H Alarm Restored
BA (Water Leak Detector: WA)	1130 (Water Leak Detector: 1154)	Burglary Alarm
BH (Water Leak Detector: WH)	3130 (Water Leak Detector: 3154)	Burglary Alarm Restored
TA	1137	Lid Opened

SIA code	CID code	Description
TR	3137	Lid Restored
BV	1139	Confirmed Alarm
BW	3139	Confirmed Alarm Restore
		BUS Open-circuit Alarm
		BUS Open-circuit Restored
AF	1142	BUS Short-circuit Alarm
CN	3142	BUS Short-circuit Restored
TA	1144	External Probe Disconnected
TR	3144	External Probe Connected
AG	1148	Device Motion Alarm
CO	3148	Device Motion Alarm Restored
	1149	Masking Alarm
	3149	Masking Alarm Restored
GA	1162	Gas Leakage Alarm
GH	3162	Gas Leakage Alarm Restored
AH	1207	Zone Early-Warning
CP	3207	Zone Early-Warning Dismissed
AT	1301	Mains Power Lost
AR	3301	Mains Power Restored
YT	1302	Battery Low
YR	3302	Battery Voltage Restored
ZY	1305	Reset to defaults
YM Transmitter battery missing ID range: 301~	1311 Transmitter battery missing ID range: 301~	Battery Disconnected
YR Transmitter battery missing ID range: 301~	3311 Transmitter battery missing ID range: 301~	Battery Reconnected
YI	1312	Overcurrent Protection Triggered
YJ	3312	Overcurrent Protection Restored
YP	1319	Overvoltage Protection Triggered
YQ	3319	Overvoltage Protection Restored
AI	1333	Expander Exception
CQ	3333	Expander Restored
AJ	1336	Printer Disconnected
CR	3336	Printer Connected
XT	1384	Battery Low
XR	3384	Battery Voltage Restored
		Expander Low Voltage
		Normal Expander Voltage
AT	1342	Mains Power Lost
AR	3342	Mains Power Restored
YM	1311	Battery Disconnected

SIA code	CID code	Description
YR	3311	Battery Reconnected
TA (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	1144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Lid Opened
TR (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	3144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Lid Restored
YP Transmitter AC power Loss ID range: 301~ Sounder AC power Loss ID range: 202~	1301 Transmitter AC power Loss ID range: 301~ Sounder AC power Loss ID range: 202~	Expander AC Power Loss
YQ Transmitter AC power Loss ID range: 301~ Sounder AC power Loss ID range: 202~	3301 Transmitter AC power Loss ID range: 301~ Sounder AC power Loss ID range: 202~	Expander AC Power Loss Restored
TA	1144	Lid Opened
TR	3144	Lid Restored
TA	1144	Lid Opened
TR	3144	Lid Restored
XL	1381	Device Offline
XC	3381	Device Restored
TA (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	1144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Lid Opened
TR (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3144 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Lid Restored
XT (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	1384 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Battery Low
XR (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3384 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Battery Voltage Restored

SIA code	CID code	Description
XL (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	1381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Offline
XC (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	3381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Restored
LT	1351	Main Signalling Path Fault
LR	3351	Main Signalling Path Restored
LT	1352	Backup Signalling Path Fault
LR	3352	Backup Signalling Path Restored
AM	1354	Telephone Line Disconnected
CU	3354	Telephone Line Connected
AN	1382	BUS Supervision Fault
CV	3382	BUS Supervision Restored
	1380	
	3380	
TA	1144	Lid Opened
TR	3144	Lid Restored
		Zone Open-circuit Alarm
		Zone Short-circuit Alarm
OP	1401	Disarmed
CL	3401	Armed
OA	1403	Auto Disarmed
CA	3403	Auto Armed
BC	1406	Alarm Silenced
CW	3408	Instant Arming
CS	1409	Keyswitch Zone Disarming
OS	3409	Keyswitch Zone Arming
NL	3441	Armed in home mode
CX	3442	Forced Arming
		Turn On Output by Schedule
		Turn Off Output by Schedule
CT	1452	Late to Disarm
CD	1455	Auto Arming Failed
		Turning On Output Failed
		Turning Off Output Failed
		Auto Disarming Failed
	1556	Network Change
QB	1570	Bypassed

SIA code	CID code	Description
QU	3570	Bypass Restored
AU	1574	Group Bypass
CZ	3574	Group Bypass Restored
AV	1601	Manual Report Test
RP	1602	Periodic Report Test
TS	1607	Walk Test Enabled
TE	3607	Walk Test Disabled
AW	1617	Telephone Connection Test
LB	1627	Programming mode
LX	1628	Exit Programming
BA	1131	Intrusion Detection
BH	3131	Intrusion Detection Restored
BA	1131	Cross-Zone Alarm
BH	3131	Cross-Zone Alarm Restored
		PIR Alarm
		PIR Alarm Restored
AY	1775	Sudden Increase of Sound Intensity Alarm
DE	3775	Sudden Increase of Sound Intensity Alarm Restored
AZ	1776	Sudden Decrease of Sound Intensity Alarm
DF	3776	Sudden Decrease of Sound Intensity Alarm Restored
		Audio Input Fault
		Audio Input Restored
BA	1131	Line Crossing Alarm
BH	3131	Line Crossing Alarm Restored
BA	1134	Region Entrance Detection
EA	1134	
FA	1112	Fire Source Alarm
FH	3112	Fire Source Alarm Restored
KS	1158	High Temperature Pre-Alarm
KR	3158	High Temperature Pre-Alarm Restored
ZS	1159	Low Temperature Pre-Alarm
ZR	3159	Low Temperature Pre-Alarm Restored
KA	1158	High Temperature Alarm
KH	3158	High Temperature Alarm Restored
ZA	1159	Low Temperature Alarm
ZH	3159	Low Temperature Alarm Restored
EA	1134	Region Exiting Detection
PA (The user No. of keyfob starts from 901)	1120 (The user No. of keyfob starts from 901)	Audible Panic Alarm

SIA code	CID code	Description
		Audible Panic Alarm
		Audible Panic Alarm
		Audible Panic Alarm
FA	1110	Keypad/Keyfob Fire Alarm
		Keypad/Keyfob Burglary Alarm
CI	1454	Arming Failed
MA (Contains user information in the text message if triggered by keyfobs.)	1100	Keypad/Keyfob Medical Alarm
DK	1501	Keypad Locked
DO	3501	Keypad Unlocked
		Absence Alarm
		Keypad Disconnected
		Keypad Connected
		KBUS Relay Disconnected
		KBUS Relay Connected
		KBUS GP/K Disconnected
		KBUS GP/K Connected
		KBUS MN/K Disconnected
		KBUS MN/K Connected
DK	1501	Tag Reader Locked
DO	3501	Tag Reader Unlocked
B D	1865	Unregistered Tag
XL	1381	Device Offline
XC	3381	Device Restored
XT	1384	Battery Low
XR	3384	Battery Voltage Restored
XL (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	1381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Device Offline
XC (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	3381 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201)	Device Restored
XL	1381	Device Offline
XC	3381	Device Restored
BI	1918	Radar Transmitter Fault
DL	3918	Radar Transmitter Restored
XT	1384	Battery Low
XR	3384	Battery Voltage Restored
NT	1350	Cellular Fault


SIA code	CID code	Description
NR	3350	Cellular Restored
NT	1350	SIM Card Exception
NR	3350	SIM Card Restored
NT	1350	Network Fault
NR	3350	Network Restored
XQ	1344	Jamming Detected
XH	3344	Jamming Restored
NT	1350	Data limitation Reached
XT	1384	Battery Low
XR	3384	Battery Voltage Restored
NT	1350	IP Address Already Used
NR	3350	Normal IP address
NT	1350	Network Fault
NR	3350	Network Restored
BA	1131	Motion Detection Alarm Started
BH	3131	Motion Detection Alarm Stopped
BJ	1941	Device Blocked
DM	3941	Device Blocking Alarm Restored
		Video Signal Loss
		Video Signal Restored
		Input/Output Format Unmatched
		Input/Output Format Restored
		Video Input Exception
		Video Input Restored
		Full HDD
		Free HDD
		HDD Exception
		HDD Restored
		Upload Picture Failed
BQ	1948	Email Sending Failed
BR	1949	Network Camera Disconnected
DS	3949	Network Camera Connected
		Duty Checking
		Post Response
BU	1962	Fire Alarm Consulting
DT	3962	Fire Alarm Consulting Over
BV	1963	Duress Alarm Consulting
DU	3963	Duress Alarm Consulting Over
BW	1964	Emergency Medical Alarm Consulting
DV	3964	Emergency Medical Alarm Consulting Over
DW	3250	Patrol Signing



SIA code	CID code	Description
BX	1970	BUS Query
BY	1971	BUS Registration
BZ	1973	Single-Zone Disarming
DX	3973	Single-Zone Arming
CA	1974	Single-Zone Alarm Cleared
CB	1306	Device Deleted
DY	3306	Device Enrolled
CC	1976	Business Consulting
DZ	3976	Business Consulting Over
CD	1306	Device Deleted
EA	3306	Device Enrolled
CE	1306	Device Deleted
EB	3306	Device Enrolled
CF	1306	Device Deleted
	3306	Device Enrolled
CG	1306 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Deleted
ED	3306 (The serial number of output module starts from 1, of keypad starts from 101, of tag reader starts from 201, of transmitter starts from 301)	Device Enrolled
JA	1461	Incorrect Password
NT	1350	Device Offline
YM	1311	Power Depletion




www.rosarioseguridad.com.ar


 ventas@rosarioseguridad.com.ar

 +54 9 341 6708000

  +54 9 341 6799822


 [rosarioseguridadok](https://www.instagram.com/rosarioseguridadok)



 Rosario Seguridad

 Rosario Seguridad

Grupo Instaladores

 <https://www.facebook.com/groups/591852618012744/>

 +54 9 341 6591429

  +54 9 341 4577532

Avenida Pellegrini 4820 - Rosario - Santa Fe - Argentina

UD27253B