

<b>Title:</b>	How to preview HDMI camera	<b>Version:</b>	v1.0	<b>Date:</b>	3/19/2019
<b>Product:</b>	Cameras			<b>Page:</b>	1 of 5

## Preparation

1. DS-2CD21x5G0-IMS.
2. Screw Driver x 1.
3. Displayer with HDMI input.
4. HDMI cable.
5. HDMI switch cable (Type D-to-Type A).

## How to preview HDMI camera

1. Loose screws to take part the bubble .



Figure 1

<b>Title:</b>	How to preview HDMI camera	<b>Version:</b>	v1.0	<b>Date:</b>	3/19/2019
<b>Product:</b>	Cameras			<b>Page:</b>	2 of 5



Figure 2



Figure 3

<b>Title:</b>	How to preview HDMI camera	<b>Version:</b>	v1.0	<b>Date:</b>	3/19/2019
<b>Product:</b>	Cameras			<b>Page:</b>	3 of 5

## 2. Wiring

Insert HDMI switch cable (Type D-to-Type A) and power on device.



Figure 4

## 3. Preview

1) We can preview the image via HDMI when device is inactive.




Figure 5



<b>Title:</b>	How to preview HDMI camera	<b>Version:</b>	v1.0	<b>Date:</b>	3/19/2019
<b>Product:</b>	Cameras			<b>Page:</b>	4 of 5

2) Connect camera to the displayer, then it will take a few seconds to show image on the displayer.



Figure 6

**Note:**

DS-2CD2125G0-IMS and DS-2CD2185G0-IMS only support 2MP HDMI output, it is not depended on resolution itself.

It allows enable/disable HDMI output and change resolution in the Image configuration.




Figure 7

<b>Title:</b>	How to preview HDMI camera	<b>Version:</b>	v1.0	<b>Date:</b>	3/19/2019
<b>Product:</b>	Cameras			<b>Page:</b>	5 of 5

## First Choice for Security Professionals **HIKVISION** Technical Support