

DS-PDP18-EG2 HIKVISION


18 m Digital PIR Detector




COPYRIGHT ©2019 Hangzhou Hikvision Digital Technology Co., Ltd. ALL RIGHTS RESERVED.
 Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou Hikvision Digital Technology Co., Ltd. or its subsidiaries (hereinafter referred to be "Hikvision"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise stipulated, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.
 About this Manual
 This Manual is applicable to the 18 m Digital PIR Detector. The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website (<http://overseas.hikvision.com/en/>). Please use this user manual under the guidance of professionals.
HIKVISION Trademarks Acknowledgement and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

EN50131-2-2:2017
 EN50131-1:2006+A1:2009+A2:2017
 Security Grade (SG) 2
 Environment Class (EC) II


1 Disassembling the Detector




2 The Printed Circuit Board (PCB)




3 Installation Method - Detector Backplane Installation




4 Installation Method - Bracket Installation




5 Installation Hints




6 The 18 m Lens




7 Resistor Wiring




8 Choose the Connection Type



9 Powering up



10 Dimension and Weight



11 Technical Specification

Lens	Maximum detection angle	85.9°
	Maximum detection distance	18 m
Key Function	PIR sensitivity	High, Auto, Low
	Tamper	Front panel supports
	Creep Zone Protection	Supported
Appearance	Anti-insect interference	Tight optical cavity structure
	LED	Status indicator, blue,
Interface	Tamper interface	2
	Alarm interface	2
Installation	Installation height	1.8 m to 2.4 m, recommended 2.2 m
	Installation mode	Wall or Ceiling
Others	Detection	0.3 ~ 2 m/s
	Operating voltage	9 to 16 VDC (Standard 12 VDC)
	Current consumption	< 20 mA (12 VDC)
	Operating temperature	-10 °C to 40 °C (14 °F to 104 °F)
	Weight	68 g (2.4 oz)
	Dimension (H × W × D)	86.8 mm × 65.4 mm × 45.5 mm (3.4" × 2.6" × 1.8")

CE This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU.

2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclingthis.info

Class B: This device is intended for mainly home use (Class B) and may be used in all areas.
 B급 기기: 이 기기는 가정용 (B급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

IC Information

CLASS B: CAN ICES-3 (B)/NMB-3(B)
 Industry Canada ICES-003 Compliance
 This device meets the CAN ICES-3 (B)/NMB-3(B) standards requirements.
 This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
 (1) this device may not cause interference, and
 (2) this device must accept any interference, including interference that may cause undesired operation of the device.
 Le présent appareil est conforme aux CNR d'industrie Canada applicables aux appareils radio-exemptés de licence. L'exploitation est autorisée aux deux conditions suivantes :
 (1) l'appareil ne doit pas produire de brouillage, et
 (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
 Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
 Conformément à la réglementation d'industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.
 This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.
 Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

FCC Information

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 —Reorient or relocate the receiving antenna.
 —Increase the separation between the equipment and receiver.
 —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 —Consult the dealer or an experienced radio/TV technician for help.
 This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.
 FCC Conditions
 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation

- Desmontaje del detector
 - Lente
 - Placa de circuito impreso
- Placa de circuito impreso
 - Sensor infrarrojo pasivo (PIR)
 - Terminales
 - Resorte de manipulación
 - Ajustes de sensibilidad
- Método de instalación - Instalación de la placa posterior del detector
 - Conectores de las resistencias de la manipulación
 - Conectores de las resistencias de la alarma
 - ENCENDIDO/APAGADO DEL LED
 - ENCENDIDO DEL LED
 - APAGADO DEL LED
 - ENCENDIDO/APAGADO DEL LED
 - AUTOMÁTICO (por defecto)
 - ALTO

Modelo de tornillo	número
PA 3,5 x 25	4

- Método de instalación. Instalación del soporte
 - Accesorio para el soporte de techo
 - Accesorio para el soporte de pared

- Consejos de instalación
- La lente de 18 m
 - Alcance de detección: 85,9° 52 zonas 4 planos
 - Altura de montaje: Intervalo de altura de montaje de 1,8 m a 2,4 m. La altura de montaje recomendada es de 2,2 m.

- Cableado de la resistencia

El detector es compatible con dos métodos para el cableado de la resistencia:

 - Uso de conectores para seleccionar la resistencia de fin línea (en función del panel de control) sobre los pines de los conectores de la ALARMA/MANIPULACIÓN.
 - Seleccionar una resistencia (en función del panel de control) y agregar la resistencia a los puertos de cableado de la ALARMA/MANIPULACIÓN del detector.

Nota: Si no usa un cableado de fin de línea, no use los conectores. Si los conectores y los pines de los conectores no son compatibles, no fuerce los conectores y seleccione el método 2 para cablear la resistencia. No utilice el método 1 y el método 2 al mismo tiempo para la ALARMA/MANIPULACIÓN.

- Resistencia de la alarma: 1K, 2K2, 4K7, 5K6 o 8K2
- Resistencia de la manipulación: 5K6, 4K7, 2K2 o 1K

- Elija el tipo de conexión
 - Normalmente cerrado
 - Panel de control de la alarma
 - Detector
 - Cableado de fin de línea simple
 - Panel de control de la alarma
 - Detector
- Conexiones mostradas en el ejemplo:
 - Normal: 1K
 - Alarma: Infinito
 - Sabotaje: 0 K
- Cableado de fin de línea doble
 - Panel de control de la alarma
 - Detector
- Conexiones mostradas en el ejemplo:
 - Normal: 1K
 - Alarma: 2K
 - Sabotaje: 0 K o infinito
- 2 detectores de fin de línea doble a una entrada
 - Panel de control de la alarma
 - Detector 1
 - Detector 2

7. Encendido
Una vez conectada la alimentación, el indicador parpadea rápidamente. Una vez completado el autodiagnóstico del detector, el indicador led se apagará hasta que el detector capte un movimiento.

NO PREPARADA ❌ PREPARADA ✅

8. Dimensiones y peso

9. Especificaciones técnicas

Lente	Ángulo de detección máximo	85,9°
	Distancia de detección máxima	18 m
	Sensibilidad del infrarrojo pasivo	Alta, automática y baja
Función clave	Sabotaje	Soportes del panel frontal
	Protección de zona de ángulo cero	Compatible
	Interferencia antinsectos	Estructura de cavidad óptica ajustada
Apariencia	LED	Indicador de estado, azul
Interfaz	Conexión de manipulación	2
	Conexión de alarma	2
Instalación	Altura de instalación	1,8 m a 2,4 m (se recomienda 2,2 m)
	Modo de instalación	Pared o techo
Otros	Detección	0,3-2,0 m/s
	Tensión de funcionamiento	9 a 16 V CC (estándar 12 V CC)
	Consumo de corriente	< 20 mA (12 V CC)
	Temperatura de funcionamiento	-10 °C a 40 °C (14 °F a 104 °F)
	Peso	68 g (2,4 oz)
	Dimensiones (alto x ancho x profundidad)	86,8 mm × 65,4 mm × 45,5 mm (3,4 in × 2,6 in × 1,8 in)



✉ ventas@rosarioseguridad.com.ar 📷 rosarioseguridadok

📞 +54 9 341 6708000

📺 Rosario Seguridad

📞 +54 9 341 6799822

📘 Rosario Seguridad

Grupo Instaladores

🌐 <https://www.facebook.com/groups/591852618012744/>

📞 +54 9 341 6591429

📞 +54 9 341 4577532

Avenida Presidente Perón 3998 - Rosario - Santa Fe - Argentina