CAMARA SOLAR WI-FI DOMO PTZ

BABY CENTINEL DW1







Table of Contents

Part 1: Before Installation	1-3
Part 2: In-App Setup	4-11
Part 3: Physical Installation	12-13
Part 4: Technical Specifications	14
Part 5: Detailed App Instructions	15-22
Part 6: How to save and delete videos	23
Part 7: FQAs	24



Warm tips before you go:

- 1. Solar camera can only be set up with 2.4g Wi-Fi network. (It's ok to use Cell phone 4G data to live viewing it after the camera was set up with 2.4g Wi-Fi network firstly.)
- 2. You may possibly need a Wi-Fi extender if your Wi-Fi signal is weak around the yard where you want to install it.
- 3. Please format the micro sd card to FAT32 format and install the card when camera powered off.(Micro sd card is not provided in the package)
- 4. Please connect the solar panel to camera and then charge the camera by connect the USB port in the solar panel or the camera. it usually takes up to 10-12 hours to fully charge it.
- 5. Make sure the distance between your phone,router and the camera is no more than 1.5 feet when you're ready to pair the camera. Ensure that the Wi-fi signal strength on your phone is good.
- 6. The PIR range is 16 feet around, the recommend camera install height is 8 feet around. To avoid too much false alarms, we suggest you do not install the camera with nearby bushes, shrubs, grasses and tree leaves coming into the PIR range.
- 7. If you install the camera on stucco, brick or concrete surface, please mark 4 holes matching the bracket and then use a drill driver to drill into the wall and insert the expansion screws to hold the camera tightly



Before Installation

Product Diagram





Package Content



1* Solar panel



1* PTZ Camera



- 1*Screw kit
- 1*Hexagon spanner
- 1*Screw driver
- 8*Screws
- 4*Tapping screw
- 1* USB charging cable



1*User manual



1*Position paper



Make sure the distance between your phone, router and the camera is no more than 1.5 feet when you're ready to pair the camera. Ensure that the Wi-fi signal strength on your phone is good.

 Download the App (works only with iOS & Android devices) Please locate the "Ubox" in your Google Play store or App store to download the Ubox App.



2. Register an account

Open the App, click "register" and then input your email, the app will send an email with verification code in a few minutes. Go to your email to get the code and input it to verification.

Set a password for your account.

Please note: Verify code mail may be classified as spam by the mailbox, Please check out the spam box.



3. Set up the installed location

Input the installed location Click"Add family" and then input the name of house, click "next step" and then input required information, and then click "finished" to save it.

ଜ	Device list	Ξ	< /	Add family		<	Add address
			Please enter your f	amily name		CHINA	
	61					Guangdong	
	\bigcirc					City(optional)	
						Address(option	al)
	click the button to add a family.					zip code (optic	inal)
6	+ Add family				-		
				Next			Finish
				- Tom			
O Device	Cloud video Album	Q Me					

4. Pairing the camera with the App

Turn on the camera: switch the power button to up to turn on the camera, Then you will hear the following voice " The camera is now ready to begin pairing".





Please connect your phone to the 2.4Ghz wifi firstly before you pair the camera, make sure your router password in mind before you start the pairing process.
1) Click "Add a device" and then choose "Setup device", click "Yes", when you hear the following voice " The camera is now ready to begin pairing".



2) Input the CORRECT WiFi password of your router, if you input a wrong password you will not be able to connect it successfully. Click the eye icon to double confirm the password you entered correct



Method 1: QR code configuration

1.1 Click the "QR code configuration", hold the QR code in front of the Solar camera, and then you will hear the following : "Pairing Information Received".



Method 2: Sound wave configuration

2.1 Enter into the "search device" page, make sure to turn up you phone's volume to the Maximum, you will hear the following voice: "Pairing Information Received".



3) You have connected the device to the App successfully. Choose a name of the devices from the drop-down choice, or you can modify one that you want. and then select the area where device is located.(you have to choose one or you cannot connect the camera to the app)

<	Add Device		<	Add Device	
Select Wi-Fi	Search Device	Add Device	Select Wi-Fi	Search Device Add	d Device
Device		<u> </u>	Front Do	or	
Select the area	where device is located.	~	Select the a	rea where device is located.	^
			House		
	Finish			Finish	

4) Congratulations! Now you can live view the camera on your phone anytime and anywhere.

If you're unable to pair the camera,Please check below suggestions:

- 1. Please reset the camera to reset the camera to default after you fully charged the camera.
- 2. Please turn up your phone volume to the maximum, since the camera pair through sound wave.
- 3. Please put the camera, phone as near as to your router (within 1.5 feet) to get a strong wifi signal strength.
- 4. Please click on the eye icon when you input your router wifi password to make sure your wifi password CORRECT.
- 5. Please make sure your router setting is DHCP enabled, otherwise your router will not send out WiFi signal for any wireless device for pairing up.



Push Mode

This icon indicate that the push mode is on, click it to turn off push mode and then you cannot receive any notifications.



Cloud storage

The video clips will save in the Cloud. Cloud video length is 8 seconds defaulted and free for 30 days. And you have to pay for the service per month or other cloud service.

<	Cloud Service	Purchase
•	Device Please select the se want to open or ren	ervice you ew :
	renew :	
Cle Up	oud Storage <mark>load video cloud st</mark> o	Free trial
\checkmark	30day	\$1.99
	180day	\$8.99
	360day	\$16.99
	Cloud Storage	(Free trial)
Closer	oud Storage Add Fac vice	ce recognition
	Open service	•

9



How to Share Your Camera with More Users

When you can use your camera properly. You can start to share your camera to your friends or family members.click ""and choose "share permissins", input the account that you want to share with.Choose a permissions from Administor, family member, Vistor, Customize



You can Customize the permissions and turn on or off every permission as you wish by clicking the blue icon" permissions"



How to unbind your camera

Please do not forget to unbind your camera from your app when your plan to return the camera,to avoid any personal information disclosure risk.

And unbind your camera as follwing steps.click " 🔅 " and then choose 'delete'





Physical Installation



If your camera get numerous motion alerts unexpected

- 1) Please adjust your camera installation angle a bit down to focus the motion area.
- 2) Please change your PIR sensitivity to Low to reduce the PIR sensitivity.
- 3) Do not install the camera with nearby bushes, shrubs, grasses and tree leaves coming into the PIR range.



Physical Installation

4 Adjust the bracket on the wall and then mark 3 holes for mounting. Fix the bracket to the wall by expansion screws.







Technical Specifications

Image Quality	Resolution	1080P		
Specifications Lens	Lens angle	FOV 160°		
	Video format	H.264		
Video Specifications	Frames per second	15fps	5	
	SD card support	8GB-Max 64GB		
Andia	Output	Built-	-in speaker	
Audio	Intput	Built-	-in microphone	
Communications	WiFi	2.4GHz		
	Battery capacity	4000	mAh	
Battery	Standby time	Max	6 months	
	Power consumption	2W(run)/ 0.012W (standby)		
Applicable	Temperature	-20°C~+60°C(-4°F-140°I		
Environment	Humidity	20%~85% (Non-condensing)		
System Suppport	Android 2.3 above/ iOS 7.0 above			
DID	PIR angle		110°	
FIR	PIR range		16ft	
Night Vision	Range		Up to 32ft	

un producto de 😿

1.click (), you could live viewing videos.







Battery charging sign

When camera exposed to sunlight,the battery will keep charging in green.

During night or fully charged, the battery will stay white.

Tips : If your battery sign will not show correct status as above,please remove the solar panel and then re install it to the camera body.



Low power indicator, please recharge the camera manually using the provided USB cable

Wifi signal strength

Tips: Please make sure your camera has a full bar of wifi strength to ensure a smooth live view speed. (A wifi extender is recommended to install beside the camera if needed)

Click here to chose the resolution to HD(1080P) OR SD(720P)



Number of users

Tips: If you have invited a second users to visit your camera.Please pay attention to below points:

- 1.Your camera password can be seen by the invited users,but it can not be modified.
- 2.The invited users can change all the camera settings, so the camera will work as per the last change made on the settings among all users.
- 3.If your camera does not work as you set before,please check the settings from the invited users' device.







SD Card Setting

- 1) Please turn on the cloud storage so that you can sync the camera time with your phone.
- 2) Please format the micro sd card before you installed it. The camera doesn't support plug and play. So please make sure to power off the camera and then install your card.



Image flip

You can choose Normal Rotate, Mirror or Mirror and rotate depends on your hardware installation way. The default is Normal.

<	Front Door	(()	< Device	settings	< Image flip	
SD	05 12:03	후 🗈 🛈 1	Device Settings		Normal	~
	Market Contraction	115	Memory card	Cloud video >	Rotate	
			Image flip	Normal >	Mirror	
1	1 CE		Scene mode	Normal >	Mirror and rotate	
Onli	ne		Detection sensitivity	High >		
12			Active time	15s >		
5			Power frequency	50Hz >		
		,	LED indicator	Enabled >		
	Activity detected Time:8s	© [*]	Device name	>		
	Front Door		Basic info			
	Activity detected Time:8s		Name	Front Door		
	Front Door		ID EU	JBHAQOEWZT7MCYSN4DA		
	Activity detected	O	Model	UB01		

Scene mode

You can choose to set it as Normal, back light compensation, night IR, High light compensation or Dynamic according to your actual light environment of installation place.

K Front Door	< Device setti	ings	K Scene mode
50 (* 1) 2020-05-05 12:03	Device Settings		Normal 🗸
	Memory card	Cloud video >	Back light compensation
	Image flip	Normal >	Night vision mode
	Scene mode	Normal >	High light compensation
Online	Detection sensitivity	High >	Dynamic
	Active time	15s >	
	Power frequency	50Hz >	7
Errort Door	LED indicator	Enabled >	
15:11 • Carlo Bole Time 8:	Device name	>	
Front Door	Basic info		
Time:8s	Name	Front Door	
Front Door	ID EUBHAG	QOEWZT7MCYSN4DA	
Time:8s	Model	UB01	

PIR Detection

You can set the PIR sensitivity as Disabled,Low,Medium and High.

- 1) When you set the PIR as Disabled, you will not record and receive any motion triggered events.
- 2) It is recommended to set the PIR Detection to High so that you could capture as more as a motion triggered from the beginning part of the event.
- Try to capture more the beginning of the triggered event, please adjust your camera angle a bit closer to your aimed spot (Check page 13 diagram).



K Front Door	C Device settings		< Detection se	insitivity
	Device Settings		Disabled	
	Memory card	Cloud video >	Low	
	Image flip	Normal >	Medium	
	Scene mode	Normal >	High	~
Online	Detection sensitivity	High >		
	Active time	158 >		
	Power frequency	50Hz >		
< 2019-12-27 >	LED indicator	Enabled >		
15:m - Control Lbor Activity detected Time:8s	Device name	>		
Front Door	Basic info			
15:50 Activity detected Time:8s	Name	Front Door		
Front Door	ID EUBHAQOE	WZT7MCYSN4DA		
14:59 • Activity detected Time:8s	Model	UB01		

Active time

- 1) This is the time you could set for the video length recorded to micro sd card.
- 2) Always: If you choose this option,you will not allow the camera enter into standby mode,the camera will keep recording all the time until battery drains out. (60 seconds per file)





LED indicator

When you choose Enable, the Blue LED will light up to indicate when you operate the camera as it should be. When you choose Disabled, the Blue LED will not light up to indicate the operations or trigger motions. It is recommended to set it as the default



Power frequency

Please choose 60 or 50HZ according to your local frequency, It's defaulted to 60HZ for united states users.





Device Name

You can set a desired name for your camera.





How to save and delete videos

1. Videos can be saved in Cloud Storage:

(1). The videos of PIR activity

You could save the videos of PIR activities in cloud storage, which can be used 30 days for free and then you have to pay for the services. and playback in the app.

2. Videos can be saved in the SD card:

- (1). The videos of PIR activity
- (2). The videos of live viewing You could playback these videos on the timeline in the App and format the SD card in the App.



3. Videos can be saved on the mobile phone album:

- (1). The videos of REC mode
- (2). The screenshot

You need to delete the videos of REC mode and the screenshots from your phone's album.



FAQs

Q1: Why do I fail to connect the camera to the App by sound wave?

- A: 1. Please reset the camera by the pin included.
 - 2. Please make sure the camera is powered on and there will be voice prompts that indicates it.
 - 3. Make sure the distance between your mobile phone and the device is no more than 30cm. And your mobile, camera and router are in the same room.
 - 4. Adjust your phone volume to maximum.
 - 5. Double check your WiFi password and make sure it is correct.

Q2: When In-App setup is done, why I could not see the live streams on my mobile?

A: First, check in App to confirm the wifi signal is strong enough. If not, we would suggest adding wifi extender in between.

Q3: Why I cannot receive any alarm after I finished connecting the camera with the App ?

- A:1. Click the 💭 in App to confirm you have turned on the push mode.
 - 2. Check your mobile settings to allow the notification.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled enviroment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

